

Qaba 344-125V00WT

Qaba Two-Story Outdoor Wooden Playhouse Instruction Manual

Model: 344-125V00WT | Brand: Qaba

INTRODUCTION

This instruction manual provides important information for the safe assembly, operation, and maintenance of your Qaba Two-Story Outdoor Wooden Playhouse. Please read this manual thoroughly before assembly and retain it for future reference. This playhouse is designed for children aged 24 months and older.

SAFETY INFORMATION

- **Adult Supervision Required:** Always supervise children while they are using the playhouse.
- **Age Recommendation:** Suitable for children aged 2 years and older.
- **Weight Capacity:** The playhouse structure supports a maximum of 396 lbs (180 kg).
- **User Capacity:** Designed to accommodate up to 6 children simultaneously.
- **Installation:** Ensure the playhouse is assembled on a level surface, away from fences, trees, or other structures. Maintain a clear safety zone around the playhouse.
- **Regular Inspection:** Periodically check all nuts, bolts, and other fasteners for tightness. Inspect for any signs of wear, damage, or splinters in the wood. Replace or repair damaged parts immediately.
- **Weather Conditions:** Do not allow children to use the playhouse during strong winds, heavy rain, or icy conditions.

PACKAGE CONTENTS

The Qaba Two-Story Outdoor Wooden Playhouse includes the following main components:

- Wooden frame components for the two-story structure

- Slide
- Ladder with flat steps
- Picnic table and bench components
- Play kitchen accessories (sink, stove, etc.)
- Blackboard panel
- All necessary hardware (screws, bolts, washers, etc.)
- Assembly tools (usually Allen wrenches, but a screwdriver may be needed)

Note: Please verify all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Qaba Two-Story Outdoor Wooden Playhouse is required. Follow the detailed step-by-step instructions provided in the separate assembly manual included with your product. Ensure all components are correctly oriented and securely fastened.

- **Preparation:** Clear a spacious, level area for assembly. Ensure the ground is soft enough to absorb impacts, such as grass or wood chips.
- **Tools:** Gather any additional tools that may be required, such as a screwdriver or wrench, as indicated in the assembly manual.
- **Teamwork:** Assembly may require two or more adults.
- **Step-by-Step:** Follow the numbered steps in the assembly manual precisely. Do not skip steps.
- **Fasteners:** Do not overtighten screws or bolts during initial assembly. Tighten all fasteners securely once the entire structure is complete.



Image: The fully assembled Qaba Two-Story Outdoor Wooden Playhouse in a backyard setting, showing children utilizing its various features like the slide, ladder, and upper platform.



Suggested User Capacity:
6 children

2-5

Recommended Age:
2-5 years



Image: A diagram illustrating the overall dimensions of the Qaba Two-Story Outdoor Wooden Playhouse, including its length, width, and height.

OPERATING INSTRUCTIONS

The Qaba Two-Story Outdoor Wooden Playhouse offers multiple play areas for children:

- **Two-Story Design:** Children can access the upper lookout platform via the ladder and descend using the slide.
- **Slide:** Ensure the landing area of the slide is clear before use. Children should slide feet first.
- **Ladder:** Encourage children to use the ladder one at a time and maintain a firm grip on the handrails.
- **Picnic Table & Bench:** Located on the lower level, this area is suitable for quiet play, snacks, or social interaction.
- **Play Kitchen:** The integrated play kitchen encourages imaginative role-play with a sink and other kitchen elements.
- **Blackboard:** A creative blackboard provides a surface for drawing and artistic expression.

ELEVATED DUAL-LEVEL FUN



Image: An annotated image highlighting key features of the playhouse, including the lookout platform, flowerpot holder, smooth slide, flat-step ladder, and picnic table & chair.

IMAGINATIVE PLAY DETAILS



Image: Children engaging in imaginative play within the playhouse, showcasing the serving window, complete kitchen set, and creative blackboard.

Your browser does not support the video tag.

Video: An official product video demonstrating various features and children playing on the Qaba Two-Story Outdoor Wooden Playhouse (Model 344-125V00WT).

MAINTENANCE

Proper maintenance ensures the longevity and safety of your playhouse:

- **Cleaning:** Clean the playhouse regularly with a damp cloth and mild soap. Avoid harsh chemicals that could damage the wood finish or plastic components.
- **Wood Care:** The playhouse is crafted from fir wood with a water-based finish. To maintain its condition, consider applying a non-toxic, child-safe wood sealant annually, especially if exposed to harsh weather.
- **Fastener Check:** Routinely check all screws, bolts, and connections. Tighten any loose fasteners to prevent instability.
- **Structural Integrity:** Inspect wooden parts for cracks, splinters, or rot. Check plastic parts (like the slide) for cracks or excessive wear. Replace any compromised parts immediately.

- **Grounding:** Ensure the playhouse remains stable on its designated spot. Re-level if necessary.



Image: A close-up view highlighting the construction quality of the playhouse, emphasizing solid fir wood, water-based paint, and a stable frame for long-lasting use.

TROUBLESHOOTING

If you encounter any issues with your Qaba Two-Story Outdoor Wooden Playhouse, refer to the following common solutions:

- **Wobbling or Instability:** Check that the playhouse is on a level surface. Inspect all connections and tighten any loose bolts or screws.
- **Squeaking Parts:** Apply a small amount of silicone-based lubricant to moving parts or joints if squeaking occurs. Avoid oil-based lubricants on wood.
- **Wood Splinters:** Carefully sand down any rough areas or splinters that may appear over time. Apply a child-safe wood sealant to protect the surface.
- **Fading Color:** Exposure to sunlight can cause colors to fade. Regular cleaning and application of a UV-protective, child-safe sealant can help mitigate this.

For issues not covered here, please contact Qaba customer support.

SPECIFICATIONS

Brand	Qaba
Model Number	344-125V00WT
UPC	196393128688
Material	Fir Wood, High Density Polyethylene
Overall Dimensions (L x W x H)	132.3 x 64.2 x 104.7 inches (336 x 163 x 266 cm)
Item Weight	176 Pounds (79.8 kg)
Recommended Age	24+ Months (2+ Years)
Suggested User Capacity	Up to 6 children
Weight Capacity	396 lbs (180 kg)
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official Qaba website. If you have questions regarding assembly, missing parts, or product functionality, please contact Qaba customer service directly.