



[Manuals.plus](#) /

- › [Christopher Knight Home](#) /
- › Christopher Knight Home Sures 5-Seater Patio Furniture Set Instruction Manual

Christopher Knight Home 380984

Christopher Knight Home Sures 5-Seater Patio Furniture Set Instruction Manual

Model: 380984

INTRODUCTION

Thank you for choosing the Christopher Knight Home Sures 5-Seater Patio Furniture Set. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new outdoor furniture set. Please read all instructions carefully before assembly and retain this manual for future reference.

Create a life you love



CHRISTOPHER KNIGHT[®]
HOME

Image: Front view of the Christopher Knight Home Sures 5-Seater Patio Furniture Set, showcasing the 3-seater sofa, two club chairs, and coffee table.

SAFETY INFORMATION

- Ensure all components are securely fastened before use. Periodically check and tighten all bolts and screws.
- Do not exceed the weight capacity of each seating unit.
- Keep children away from the assembly area. Small parts can be a choking hazard.
- Place furniture on a flat, stable surface to prevent tipping.
- Avoid placing hot items directly on the acacia wood coffee table surface without protection.
- This furniture is designed for outdoor use. Prolonged exposure to extreme weather conditions may affect its lifespan.

PACKAGE CONTENTS

Your Christopher Knight Home Sures 5-Seater Patio Furniture Set includes the following components:

- 1 x 3-Seater Sofa
- 2 x Club Chairs
- 1 x Coffee Table
- Seat and Back Cushions with removable, water-repellent covers
- All necessary assembly hardware and tools

The product is shipped in two separate packages for safety and ease of handling.

SETUP AND ASSEMBLY

Assembly is required for this furniture set. It is recommended to assemble the furniture on a soft, clean surface to prevent scratches. All necessary tools are included.

General Assembly Steps:

1. Unpack all components and verify against the parts list (not provided in this manual, refer to included documentation).
2. Attach legs to the sofa, chairs, and coffee table using the provided hardware. Ensure all connections are finger-tight initially.
3. Assemble the backrests and armrests to the seating frames.
4. Once all parts are in place, fully tighten all bolts and screws with the included tools. Do not overtighten.
5. Place cushions onto the assembled sofa and chairs.



Image: Detailed dimensions for the 3-seater sofa, club chair, and coffee table, useful for planning placement and assembly.



Image: Close-up view of the sofa armrest connection point, showing the hardware for assembly.

OPERATING INSTRUCTIONS (USAGE)

This 4-piece outdoor conversation set is designed for comfortable relaxation and social gatherings in various outdoor settings such as patios, balconies, gardens, or porches.

- **Seating:** The 3-seater sofa and two club chairs provide ample seating for up to five individuals. The thick armrests and supportive seating surfaces are designed for ergonomic comfort.
- **Coffee Table:** Use the coordinating coffee table for beverages, snacks, or decorative items.
- **Cushions:** The soft cushions enhance comfort. Their water-repellent covers offer protection against light moisture.



Image: Side view of the Christopher Knight Home Sures patio furniture set, showing the profile of the sofa and chairs.

MAINTENANCE

Proper care and maintenance will extend the life and appearance of your patio furniture set.

- **Wood Frame:** Wipe the acacia wood frame with a dry cloth regularly to remove dust and dirt. For deeper cleaning, use a damp cloth with mild soap and water, then dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The cushion covers are removable and water-repellent. For cleaning, remove the covers and hand wash with mild soap and cold water, or machine wash on a gentle cycle. Air dry only; do not tumble dry. Ensure cushions are completely dry before re-attaching to prevent mildew.
- **Weather Protection:** While acacia wood is naturally weather-resistant, it is recommended to cover the furniture during prolonged periods of rain, snow, or intense sun, or store it indoors during off-seasons to preserve its finish and structural integrity.
- **Periodic Checks:** Periodically inspect all bolts and screws and tighten them as needed to ensure stability.

Solid Acacia Wood

Premium Hardwood



Durability



Natural beauty



Resistance to
the elements



Image: Graphic highlighting the durability, natural beauty, and resistance to elements of solid acacia wood, the primary material of the furniture frame.

FILLING MATERIAL



PP cotton



Foam



High density



High resilience



Soft and breathable

Image: Diagram illustrating the cushion filling material, including PP cotton and foam, emphasizing high density, high resilience, and soft, breathable qualities.

TROUBLESHOOTING

If you encounter any issues with your furniture set, refer to the following common solutions:

- **Wobbly Furniture:** Check all bolts and screws. Loosen slightly, adjust the furniture to a level position, then retighten firmly. Ensure the furniture is on a flat surface.
- **Wood Splitting/Cracking:** Small cracks can occur in natural wood due to changes in humidity and temperature. For minor splits, wood glue and clamps can be used for repair. For significant damage, contact customer support.
- **Stains on Cushions:** For stubborn stains, a gentle fabric cleaner designed for outdoor use may be applied to the removable cushion covers. Always test on an inconspicuous area first.
- **Discoloration of Wood:** Over time, acacia wood may naturally lighten or gray when exposed to sunlight. Applying a suitable outdoor wood sealant or oil can help maintain its original color and protect the wood.

SPECIFICATIONS

Feature	Detail
Model Number	380984
Color	Natural+Beige
Material Type	Acacia Wood, Fabric
Item Weight	68.3 Pounds
Item Dimensions (Sofa)	73.23" W x 27.95" D x 26.38" H
Item Dimensions (Chair)	27.95" W x 25.98" D x 26.38" H
Item Dimensions (Coffee Table)	35.43" W x 19.69" D x 15.16" H
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
Additional Features	Removable Cushion Cover, Weather Resistant

WARRANTY INFORMATION

Christopher Knight Home products are manufactured with quality and care. For specific warranty details regarding your Sures Patio Furniture Set, please refer to the documentation included with your purchase or contact Christopher Knight Home customer support directly. Generally, warranties cover manufacturing defects under normal use.

CUSTOMER SUPPORT

Should you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Christopher Knight Home customer support:

- **Website:** christopherknighthomes.com
- **Email:** amazonvendorfeedback@gdfstudio.zendesk.com

Please have your model number (380984) and purchase information ready when contacting support.