

[Manuals.plus](#) /

› [HOSTACK](#) /

› HOSTACK 71" Tall Kitchen Pantry Storage Cabinet Instruction Manual

HOSTACK 01

HOSTACK 71" Tall Kitchen Pantry Storage Cabinet Instruction Manual

Model: 01

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your HOSTACK 71" Tall Kitchen Pantry Storage Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The HOSTACK 71" Tall Kitchen Pantry Storage Cabinet, featuring a light blue finish and bronze handles, positioned in a kitchen environment. The cabinet includes upper and lower storage sections with doors, two central drawers, and an open middle compartment suitable for a microwave.

SAFETY INFORMATION

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury or damage.

- Keep all small parts and packaging materials away from children.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all connections are securely fastened before use. Periodically check and re-tighten as necessary.
- Do not overload shelves or drawers. Refer to the Specifications section for weight capacities.
- Use the included anti-tip hardware to secure the cabinet to a wall, preventing accidental tipping.
- If any parts are missing or damaged, do not proceed with assembly. Contact customer support.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. Refer to the included step-by-step instructions and accessories kit for a complete list of parts.

- 1 x Kitchen Pantry Storage Cabinet (disassembled components)
- 1 x Step-to-Step Instructions Manual
- 1 x Accessories Kit (hardware, fasteners, etc.)

SPECIFICATIONS

Feature	Detail
Brand	HOSTACK
Model Number	01
Color	Light Blue + Bronze Handles
Material	Engineered Wood
Overall Dimensions (D x W x H)	14.2" x 31.45" x 71"
Overall Weight Capacity	Up to 450 lbs
Number of Doors	4
Number of Drawers	2
Number of Shelves	6 (including fixed and adjustable)
Additional Features	Adjustable Shelf, Cord Management Hole, Microwave Stand

PRODUCT SIZE

Load Capacity	450 lbs
Each shelf capacity	55 lbs
Each Drawer capacity	35 lbs




Image: A diagram illustrating the dimensions of the HOSTACK kitchen pantry cabinet, including overall height (71 inches), width (31.5 inches), and depth (14.2 inches). It also shows internal shelf and drawer dimensions, along with load capacities: 450 lbs total, 55 lbs per shelf, and 35 lbs per drawer.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly requires two people for optimal safety and ease. Follow the step-by-step instructions provided in the package. A Phillips head screwdriver is typically required (not included).

- Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Compare each part to the parts list in the included manual to ensure everything is present and undamaged.
- Assemble Base and Side Panels:** Begin by attaching the side panels to the base using the provided hardware. Ensure all cam locks and dowels are properly aligned and tightened.
- Install Drawer Glides:** Attach the drawer glides to the designated side panels according to the manual's diagrams. Pay attention to the orientation of the glides.
- Construct Drawers:** Assemble the two easy-glide drawers. Ensure the bottom panel is securely seated and the front panel is correctly attached.
- Attach Back Panels:** Secure the back panels to the unit. Ensure the cable management hole is correctly positioned.

if applicable.

6. **Install Shelves:** Insert the fixed shelves and adjustable shelves into their respective positions. Adjustable shelves can be customized to your storage needs.
7. **Attach Doors:** Mount the four cabinet doors using the provided hinges. Adjust hinges as needed to ensure proper door alignment and closure.
8. **Install Handles:** Attach the bronze handles to the doors and drawers.
9. **Secure to Wall:** Use the anti-tip hardware to secure the cabinet to a wall stud. This is a critical safety step to prevent tipping.

Tip: During assembly, avoid over-tightening screws to prevent damage to the engineered wood. If you encounter difficulty, refer to the detailed diagrams in your instruction manual.

OPERATING INSTRUCTIONS

The HOSTACK Kitchen Pantry Storage Cabinet is designed for versatile storage and organization.

- **Adjustable Shelves:** The cabinet features adjustable shelves in the lower sections. To adjust, remove items from the shelf, lift the shelf, and reposition the shelf pins to the desired height. Ensure all four pins are securely in place before placing items back on the shelf.
- **Drawers:** The two easy-glide drawers are suitable for storing smaller items, utensils, or linens. Pull gently to open and push firmly to close.
- **Open Compartment:** The spacious open compartment is ideal for kitchen appliances such as a microwave, coffee maker, or toaster. The integrated cable management hole helps keep cords tidy and out of sight.
- **Door Cabinets:** The four door cabinets provide enclosed storage for pantry items, dishes, or other kitchen essentials.



Extra Countertop & Deep Drawers

Image: A detailed view of the HOSTACK kitchen pantry cabinet's deep drawers and open countertop area. The drawers are shown holding plates, cups, and various food containers, demonstrating ample storage capacity. The countertop is styled with a coffee machine and decorative items.



Image: A close-up of the HOSTACK kitchen pantry cabinet, highlighting the two deep drawers and the open middle section. The drawers are shown partially open, revealing organized storage for kitchen items. The open section provides space for appliances or decorative elements.

MAINTENANCE

Proper care will ensure the longevity and appearance of your cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or moisture damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as needed.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.
- **Weight Distribution:** Distribute weight evenly across shelves and drawers to prevent warping or structural stress.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet is wobbly.	Loose fasteners; uneven floor.	Ensure all screws are tightened. Adjust floor levelers if present, or place shims under the base. Confirm anti-tip hardware is installed correctly.
Doors do not align or close properly.	Hinges are not adjusted correctly; cabinet is not level.	Adjust the screws on the hinges to align the doors. Ensure the cabinet is on a level surface.
Drawers stick or do not slide smoothly.	Drawer glides are misaligned or damaged; drawer is overloaded.	Check that drawer glides are installed correctly and are free of obstructions. Reduce the weight in the drawer.
Missing parts during assembly.	Packaging error.	Do not proceed with assembly. Contact HOSTACK customer support immediately for replacement parts.

WARRANTY INFORMATION

HOSTACK products are manufactured with quality and care. For specific warranty details regarding your 71" Tall Kitchen Pantry Storage Cabinet, please refer to the warranty card included with your purchase or visit the official HOSTACK website. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact HOSTACK customer support. You can typically find contact information on the product packaging, the included instruction manual, or the official HOSTACK website.
For online resources, visit the [HOSTACK Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GVNNWXQD>

More documents and user manuals: <https://manuals.plus/>