

[Manuals.plus](#) /

> [Garvee](#) /

> Garvee Kids Outdoor Playhouse Equipment Instruction Manual - Model 3PF-FGH4JZZNX21AR-1-HCQXZBDUP

Garvee 3PF-FGH4JZZNX21AR-1-HCQXZBDUP

Garvee Kids Outdoor Playhouse Equipment

Instruction Manual - Model: 3PF-FGH4JZZNX21AR-1-HCQXZBDUP

Brand: Garvee

IMPORTANT SAFETY INFORMATION

Read and understand all instructions before assembly and use of this product. Failure to follow these instructions may result in serious injury.

- **Adult Supervision Required:** Always supervise children when they are using the playset.
- **Age Range:** Suitable for children aged 3-8 years.
- **Weight Limit:** The playset has a maximum load-bearing capacity of 880 pounds (400 kg). Ensure this limit is not exceeded.
- **Installation:** Install the playset on level ground, at least 6 feet (1.8 meters) away from any structures or obstructions such as fences, garages, houses, overhead branches, laundry lines, or electrical wires.
- **Grounding:** Ensure the playset is properly anchored to the ground to prevent tipping.
- **Inspection:** Regularly inspect all components for wear, damage, or loose connections. Replace worn parts immediately.
- **Material Safety:** This playset is constructed from non-toxic, BPA-free PE material and galvanized steel.
- **Clothing:** Ensure children wear appropriate clothing, avoiding loose items that could get caught.

PRODUCT OVERVIEW

The Garvee Kids Outdoor Playhouse Equipment is a multi-functional playset designed to provide hours of active outdoor fun. It features a robust galvanized steel frame and high-grade PE panels, ensuring durability and resistance to various weather conditions.

Key Components:

- Turbo Tube Slide
- Saucer Swing
- Belt Swing

- Climbing Ladder
- Enclosed Sandbox Fort
- Height-Adjustable Basketball Hoop
- Shaded Upper Playhouse with Awning

The design prioritizes safety with smoothly rounded, burr-free edges and a wind-resistant structure.



Main view of the Garvee Kids Outdoor Playhouse Equipment, featuring the turbo slide, climbing structure, saucer swing, and belt swing.

SETUP & ASSEMBLY

This playset is designed for user-friendly assembly. It is recommended that two adults perform the assembly, which typically takes several hours. Detailed step-by-step instructions are included with your product to guide you through the process.


Before You Begin:

1. **Unpack All Components:** Verify that all parts listed in the packing list are present and undamaged. The playset ships in 5 boxes.
2. **Clear Assembly Area:** Choose a level, open area for assembly, ensuring sufficient clearance around the playset's final location.
3. **Tools Required:** Gather necessary tools as specified in the assembly manual (e.g., wrenches, screwdrivers, level).

Ship in 5 Boxes



Load-bearing Capacity
880 lb / 400 kg



This diagram illustrates the overall dimensions of the playset: approximately 194.25 inches in length, 83.3 inches in width, and 123.3 inches in height. It also notes that the product ships in 5 boxes and has a load-bearing capacity of 880 lbs.

OPERATING INSTRUCTIONS

The Garvee Outdoor Playhouse Equipment offers multiple play modes to engage children. Ensure children understand how to use each component safely.

Using the Swings:

The playset includes both a saucer swing and a belt swing. Ensure children sit properly on the swings and do not stand.

Always maintain a safe distance from other children while swinging.

2 Swings **Double the Fun!**



Round Swing for Lazing



Belt Swing for Gliding

Two children are shown enjoying the playset's swings: one child is relaxing on the round saucer swing, and another is actively gliding on the belt swing.

Using the Turbo Tube Slide and Climbing Ladder:

Children should slide feet first. The climbing ladder provides access to the upper playhouse and the slide entrance. Ensure hands and feet are used for climbing.

Height-adjustable Basketball Hoop



This image displays the multi-level play features: a child in the upper play area with a striped awning, another child ascending the climbing ladder, and a third child emerging from the green turbo tube slide.

Using the Sandbox Area:

The enclosed sandbox fort is located beneath the main tower. Fill with play sand (not included) for creative play. Ensure the sandbox is covered when not in use to keep it clean.



Two young children are shown happily playing in the designated sandbox area, using various sand toys.

Using the Height-Adjustable Basketball Hoop:

The basketball hoop can be adjusted in height to accommodate growing children. Adjust the hoop to a suitable height for the child using it.

Sandbox Area



A child is shown attempting to shoot a basketball into the height-adjustable hoop, which can be set between 47 and 60 inches.

Product in Use Video:

Your browser does not support the video tag.

This video demonstrates children actively playing on the Garvee Outdoor Playhouse Equipment, showcasing the slide, swings, and overall structure in use.

MAINTENANCE

Regular maintenance is crucial to ensure the longevity and safety of your Garvee playset. The galvanized steel and PE construction is designed for low maintenance.

Routine Checks:

- **Inspect Connections:** Periodically check all bolts, nuts, and other fasteners to ensure they are tight. Tighten as

necessary.

- **Check for Wear:** Examine all moving parts, such as swing chains, ropes, and hangers, for signs of wear, fraying, or damage. Replace any worn components immediately.
- **Surface Inspection:** Check for any sharp edges, burrs, or cracks on plastic components. Smooth or replace as needed.
- **Grounding:** Verify that the playset remains securely anchored to the ground.

Cleaning:

Clean the playset surfaces with mild soap and water. Avoid abrasive cleaners or harsh chemicals that could damage the materials. Rinse thoroughly with water.

Weather Resistance:

The playset is designed to be weather-resistant, anti-rust, and anti-corrosion, performing well in various conditions without peeling, water damage, or mold.

All Weather Resistance Play Set



This image illustrates the playset's all-weather resistance, showing it standing strong in both a lush green summer environment and a snowy winter landscape.

TROUBLESHOOTING

If you encounter any issues with your Garvee playset, consider the following general troubleshooting steps:

- **Loose Components:** If any part feels wobbly or unstable, re-check all assembly connections and tighten any loose bolts or fasteners.
- **Unusual Noises:** Squeaking or creaking sounds from swings may indicate a need for lubrication on the hangers or a check for wear on the chains.
- **Ground Stability:** If the playset shifts or rocks, ensure it is installed on level ground and that all anchors are properly secured.
- **Missing Parts:** If you believe parts are missing or damaged upon arrival, refer to your packing list and contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	3PF-FGH4JZZNX21AR-1-HCQXZBDUP
Brand	Garvee
Material	Alloy Steel, Polyethylene (PE)
Maximum Weight Recommendation	880 pounds (400 kg)
Item Weight	331.1 pounds
Recommended Age	3-8+ years
Overall Dimensions (Approx.)	194.25 in (Length) x 83.3 in (Width) x 123.3 in (Height)

WARRANTY & SUPPORT

Garvee products are designed for quality and durability. For any questions, concerns, or assistance with your playset, please contact Garvee Direct customer support.

- **Returns:** This product is eligible for 30-day easy returns. Please refer to your purchase documentation for specific return policies.
- **Customer Support:** For technical assistance, missing parts, or warranty inquiries, please reach out to the seller, Garvee Direct, through your purchase platform.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question