

DurayLoly B0GVRZNL18

DurayLoly 67-inch U-Shaped Computer Desk with Drawers, Power Outlets, and LED Lights (White)

Model: B0GVRZNL18

1. PRODUCT OVERVIEW

The DurayLoly 67-inch U-Shaped Computer Desk is designed to provide a spacious and functional workspace for various activities, including gaming, studying, and home office tasks. This desk features a robust metal frame, a durable wood desktop, and integrated functionalities such as LED lighting, power outlets, and six fabric storage drawers.

Key features include:

- **Spacious U-Shaped Design:** Offers an expansive work surface suitable for multiple monitors and extensive setups.
- **Integrated Power Outlets:** Includes 3 AC outlets and 2 USB ports for convenient device charging, with an interchangeable position.
- **Embedded LED Lights:** Enhances ambiance and provides customizable lighting options.
- **Six Fabric Drawers:** Provides ample storage for office supplies, documents, and accessories, helping to maintain an organized workspace.
- **Sturdy Construction:** Built with a durable metal frame and a smooth desktop surface for stability and longevity.

Product Demonstration Video

Your browser does not support the video tag.

This video provides a general overview and demonstration of the DurayLoly U-Shaped Computer Desk in a home office setting, showcasing its features and functionality.

2. SETUP AND ASSEMBLY

Carefully follow these instructions to assemble your DurayLoly U-Shaped Computer Desk. It is recommended to have a second person assist with assembly for easier handling of larger components.

Assembly Video Guide

Your browser does not support the video tag.

This video provides a detailed, step-by-step guide for assembling your DurayLoly U-Shaped Computer Desk. Please watch it carefully before beginning assembly.


Assembly Steps:

- 1. Unpack and Identify Components:** Lay out all parts and hardware. Refer to the parts list in the assembly video to ensure all components are present.
- 2. Assemble Side Frames:** Attach the adjustable feet (Part A) to the bottom of the vertical frame pieces (Parts 4, 6, 8, 9, 5). Connect the horizontal support bars (Parts 10, 11, 14) between the vertical frames using screws (Part B). Ensure the orientation of holes on Part 14 is correct, with the single hole side adjacent to Parts 6 and 5.
- 3. Attach Desktop Panels:** Place the desktop panels (Parts 1, 2, 3) onto the assembled frames. Secure them using screws (Part B) from underneath. *Note: Do not fully tighten screws until all panels are in place.* Insert wooden dowels (Part E) into the designated holes on the desktop panels for alignment.
- 4. Install Rear Support Bars:** Attach the diagonal rear support bars (Part 15) to the back of the desk frames using screws (Part D) to enhance stability.
- 5. Assemble Fabric Drawers:** Fold the fabric drawer boxes (Part 17, 18) into shape and insert the bottom panel. Attach the handles (Part F) to the front of each drawer using screws (Part G).
- 6. Insert Drawers:** Slide the assembled fabric drawers into the designated compartments within the desk frames.
- 7. Install Power Outlet Unit:** Place the power outlet unit (Part N) into the cutout on the desktop panel (Part 3). Secure it with screws (Part J). The power outlet can be installed on either the left or right side of the desktop.
- 8. Final Tightening:** Once all components are in place and aligned, fully tighten all screws. Cover any visible screw holes with caps (Part K).

Visual Aids for Assembly



Desktop thickness of 12mm for durability.



Detail of the robust metal frame connection points.



Adjustable feet to ensure desk stability on uneven floors.



Diagonal support bar for enhanced structural stability.

3. OPERATING INSTRUCTIONS

3.1. Using the LED Lights

The desk features embedded LED light strips to create a personalized ambiance. The LED lights are controlled via a convenient remote control (included). Refer to the remote control's specific instructions for changing colors, modes (20 dynamic, 30 static), and brightness settings.



The embedded LED light strips provide customizable lighting for your workspace.

3.2. Utilizing Power Outlets and USB Ports

The integrated power strip includes 3 standard AC outlets and 2 USB ports (5V-2.4A MAX) to power and charge

your electronic devices directly from your desk. The power outlet unit can be installed on either the left or right side of the desktop during assembly to best suit your setup.



The built-in power strip offers convenient access to AC outlets and USB charging ports.

3.3. Using the Fabric Drawers

The desk is equipped with six large fabric drawers (three on each side) for organized storage. These drawers are ideal for storing office supplies, letter-sized documents, A4 documents, and other accessories. Simply pull the handle to open and push to close.



The six fabric drawers provide ample storage space for various items.

4. MAINTENANCE

- **Cleaning the Desktop:** Wipe the desktop surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Cleaning Fabric Drawers:** The fabric drawers can be spot cleaned with a mild detergent and a damp cloth. Allow them to air dry completely before returning them to the desk. Do not machine wash.
- **Frame Care:** Periodically check and tighten all screws to ensure the desk remains stable. Wipe the metal frame with a dry or slightly damp cloth to remove dust.
- **Electrical Components:** Ensure the power outlets and USB ports are kept dry. Do not attempt to disassemble or repair the electrical components yourself.

5. TROUBLESHOOTING

- **Desk Wobbles:** Ensure all screws are fully tightened. Adjust the leveling feet at the bottom of the desk legs to compensate for uneven floor surfaces.
- **Power Outlets Not Working:** Check if the power cord is securely plugged into a functional wall outlet. Verify that the power strip's circuit breaker (if present) has not tripped.

- **LED Lights Not Functioning:** Ensure the LED light strip is properly connected to its power source. Check the remote control battery and ensure it is pointed directly at the receiver.
- **Drawers Not Sliding Smoothly:** Ensure the fabric drawers are correctly assembled and not overloaded. Check for any obstructions in the drawer compartments.

6. SPECIFICATIONS

Brand	DurayLoly
Model Number	B0GVRZNL18
Color	White
Shape	U-Shaped (Rectangular components)
Product Dimensions (D x W x H)	36.2"D x 66.9"W x 28.5"H
Top Material Type	Wood
Frame Material Type	Metal
Number of Drawers	6 (Fabric)
Special Features	3 AC outlets & 2 USB, 66.9-inch U-shaped desk, LED Lights
Required Assembly	Yes



Detailed product dimensions for planning your space.

7. WARRANTY AND SUPPORT

For warranty information, technical support, or to order replacement parts, please contact DurayLoly customer

service through the retailer where the product was purchased. Please have your model number (B0GVRZNL18) and purchase date available when contacting support.

You can also visit the official DurayLoly store for more information:[DurayLoly Store](#)