



[Manuals.plus](#) /

› [Garvee](#) /

› Garvee 16-Inch Tall Self-Watering Planters Instruction Manual

Garvee Planter

Garvee 16-Inch Tall Self-Watering Planters Instruction Manual

Model: Planter

INTRODUCTION

Thank you for choosing Garvee 16-Inch Tall Self-Watering Planters. This manual provides essential information for the proper setup, operation, and maintenance of your new planters. Designed for both indoor and outdoor use, these planters feature an integrated water level monitor and an automatic watering system to simplify plant care and promote healthy growth.



Image: A Garvee 16-inch tall black self-watering planter with a plant, showcasing its modern design.

PRODUCT FEATURES

- **Water Level Monitor:** Easily track water levels to prevent over or under-watering.
- **Automatic Watering System:** Plants absorb water as needed from a reservoir, reducing watering frequency to every 10-15 days.
- **Multifunctional Design:** Features a separate water inlet for convenient refilling and hidden handles on the inner bucket for easy plant movement.
- **Durable Construction:** Crafted from high-quality, weather-resistant plastic with an anti-cracking design, maintaining color and structural integrity through seasons.
- **Modern Aesthetic:** Classic round design in black, suitable for various home and commercial decor styles.

OUR SELF-ABSORBENT FLOWER POT



a combination of traditional flowerpot and automatic watering. Add water once every 10-15 days

OTHER ORDINARY DRIP IRRIGATION FLOWERPOT



Shades plants, interferes with sunlight and is not conducive to plant growth; unsightly

Image: Diagram showing the internal structure of the self-watering planter, highlighting the hidden water storage tank and advanced watering system.

PACKAGE CONTENTS

Each Garvee 16-Inch Tall Self-Watering Planter set includes the following components:

- 2 x Outer Planter Pots (Black, 16-inch height)
- 2 x Inner Planting Baskets with Drainage Holes
- 2 x Water Level Monitors
- 2 x Water Inlet Tubes

SETUP AND INSTALLATION

Follow these steps to assemble and prepare your Garvee self-watering planter:

1. **Assemble the Water Level Monitor:** Insert the float component into the transparent tube of the water level monitor. Ensure it moves freely.
2. **Attach Water Inlet Tube:** Securely attach the water inlet tube to the designated opening in the inner planting basket.
3. **Place Inner Basket:** Carefully lower the inner planting basket into the outer planter pot. Ensure it sits firmly at the bottom.
4. **Add Soil and Plant:** Fill the inner basket with appropriate potting soil and plant your desired greenery.
5. **Insert Water Level Monitor:** Place the assembled water level monitor into the designated slot in the inner basket.
6. **Initial Watering:** Water your plant from the top until the water level monitor indicates the 'MAX' line. After the initial watering, use the water inlet for future refills.

Automatic Water Absorbing Flower Pot Installation Steps



Image: Visual instructions for assembling the automatic water-absorbing flower pot, from monitor assembly to final placement.

OPERATING INSTRUCTIONS

The Garvee self-watering planter is designed for ease of use:

- **Monitoring Water Level:** Observe the water level monitor. The red indicator will rise as water is added and fall as the plant absorbs it. Maintain the water level between the 'MIN' and 'MAX' lines.
- **Adding Water:** When the water level monitor indicates low water, add water through the dedicated water inlet until the indicator reaches the 'MAX' line. Avoid overfilling.
- **Watering Frequency:** Depending on the plant type, climate, and size, you may only need to add water once every 10-15 days. Regularly check the water level monitor.
- **Nutrient Delivery:** Liquid fertilizer can be added directly into the water tank via the water inlet, allowing for consistent nutrient delivery to the plant roots.



Image: Detailed view of the water level gauge, water filling tank, and breathable space for root aeration.

MAINTENANCE

To ensure the longevity and optimal performance of your planters:

- **Cleaning:** Periodically remove the inner planting basket and clean both the inner and outer pots with mild soap and water. Rinse thoroughly.
- **Drainage:** Ensure the drainage holes in the inner basket remain clear to prevent waterlogging. The porous design facilitates water absorption and nutrient transport.
- **Material Care:** The high-quality plastic is weather-resistant and anti-cracking. For best results, avoid harsh chemicals or abrasive cleaning tools that could damage the surface.
- **Seasonal Storage:** If storing the planters during extreme weather, ensure they are clean and dry.



← **Water Level**
Water level monitoring to prevent plant depletion

Porous Design ➔

Porous design fully absorb-water and transport nutrients fully absorb water and transport nutrients



← **Inner Bucket Handle**
Effortless and convenient

Image: Close-up of the water level indicator, the porous base of the inner pot, and the integrated handle for easy lifting.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Water level monitor not moving	Float stuck or debris in tube.	Remove monitor and clean the tube and float. Ensure free movement.
Plant appears dry despite water in reservoir	Roots not yet established in the self-watering system, or drainage holes blocked.	Ensure plant roots reach the water reservoir. Check and clear any blockages in the inner basket's drainage. Water from the top initially if roots are new.
Unpleasant odor from planter	Stagnant water or lack of air circulation.	Empty and clean the water reservoir. Ensure the breathable space feature is not obstructed to allow 360° air convection.

SPECIFICATIONS

- **Brand:** Garvee

- **Model:** Planter
- **Material:** High-Quality Plastic
- **Color:** Black
- **Special Feature:** Self-Watering, Water Level Monitor, Inner Bucket, Handles
- **Shape:** Round
- **Item Dimensions (D x W x H):** 11.2" x 11.2" x 16"
- **Item Weight:** 9.04 Pounds (per set of 2)
- **Indoor/Outdoor Usage:** Both
- **Drainage:** Yes (integrated system)

PLANTER STRUCTURE AND DIMENSIONS

Sufficient Planting Space



Image: Planter structure and dimensions, indicating 15.7" height for the outer pot and 10.5" height for the inner bucket.

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Garvee 16-Inch Tall Self-Watering Planters, please refer to the retailer's return policy or contact Garvee customer service through the official website or your purchase platform. Please retain your proof of purchase for warranty claims.

