

[Manuals.plus](#) /

› [RebotAi](#) /

› RebotAi D101 10-inch Android 16 Tablet User Manual

RebotAi D101

RebotAi D101 10-inch Android 16 Tablet User Manual

Model: D101 | Brand: RebotAi

INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your RebotAi D101 10-inch Android 16 Tablet. Please read this guide thoroughly before using your device to ensure optimal performance and longevity. Keep this manual for future reference.

WHAT'S IN THE BOX

Verify that all the following items are included in your product package:

- RebotAi D101 Tablet
- USB-C Charging Cable
- User Manual (this document)
- Stylus (may be included with some configurations)



Image: Package contents including the tablet, manual, charging cable, and stylus.

DEVICE OVERVIEW

Familiarize yourself with the physical components of your RebotAi D101 tablet:

- **Top Edge:** Speaker, Volume Up Button, Volume Down Button, Power Button, Reset Button
- **Front:** Front Camera, 10.1-inch Touchscreen Display
- **Right Edge:** MicroSD Card Slot, USB-C Port
- **Rear:** Rear Camera, Flash, Speaker



Image: Detailed diagram of tablet components and their functions.

SETUP

1. Initial Power On

1. Press and hold the **Power Button** located on the top edge of the tablet until the screen lights up.
2. Follow the on-screen prompts to select your preferred language and region.

2. Wi-Fi Connection

1. During the initial setup, select your Wi-Fi network from the list of available networks.
2. Enter the Wi-Fi password if prompted and tap **Connect**.
3. To connect later, navigate to **Settings > Network & internet > Wi-Fi**

3. Google Account Setup (GMS)

Your RebotAi D101 tablet is Google GMS certified, ensuring stable access to Google services. During setup, you will be prompted to sign in with your Google account or create a new one. This allows access to the Google Play Store for downloading applications, Gmail, Google Maps, and YouTube.

4. Facial Recognition Setup

For quick and secure unlocking, set up facial recognition:

1. Go to **Settings > Security & privacy > Face unlock**
2. Follow the on-screen instructions to register your face.
3. Note: Only deactivation of facial recognition is supported after setup.




Image: Intelligent Facial Unlock in action.

OPERATING INSTRUCTIONS

Android 16 Operating System

The tablet runs on Android 16, offering advanced security features and enhanced data protection through customizable permission management. Its intuitive interface and simple menus ensure accessibility for all users. Integrated parental controls provide secure navigation for children, making it suitable for shared family use.

Gemini AI Integration


The RebotAi tablet integrates Gemini AI, which automatically optimizes photos in low light conditions within seconds. This feature combines advanced technology with ease of use, supported by AI-optimized motion and an efficient cooling system. The tablet is equipped with a high-performance A333 processor (up to 1.8 GHz).

Display

The RebotAi D101 features a 10.1-inch IPS TDDI display with a resolution of 1280 x 800 pixels. It offers wide viewing angles and a high brightness of 400 nits, providing realistic Full HD image quality and sharp details. The IPS TDDI screen ensures smooth and pleasant touch operation with excellent responsiveness.

10,1 Pouces Écran Intégré TDDI Affichage plein Écran avec Haute Sensibilité tactile

Affichage statique : Écran plein écran avec bordures fines pour des images nettes. Les produits similaires présentent des bordures plus larges, ce qui peut engendrer de légères interférences.
Expérience dynamique : Défilement fluide et faible latence tactile.



400 nits
Luminosité

INCELL
Technologie Tactile

10,1 Pouces
IPS Écran

1280 x 800
Résolution

Image: Integrated TDDI Full Screen Display with High Touch Sensitivity.

Storage

This 10-inch tablet comes with 16 GB RAM (4 GB RAM + 12 GB expandable virtual RAM) and 64 GB ROM. It supports memory expansion up to 1 TB via a microSD card (sold separately), providing excellent multitasking performance and ample space for applications, photos, and videos.

Connectivity

- **Wi-Fi 6:** Equipped with Wi-Fi 6 and an integrated dual-band chip, allowing simultaneous connection to 5 GHz and 2.4 GHz Wi-Fi networks for optimal online experience.
- **Bluetooth 5.2:** For connecting wireless accessories such as headphones and keyboards.
- **Wireless Projection:** The tablet can wirelessly project its content to a TV or monitor.



Image: Wireless screen projection in use.

Multi-Window and Split Screen

The multi-window function allows you to display several applications simultaneously for increased productivity. This feature supports split-screen and floating windows, enabling you to manage tasks and notifications efficiently.

Eye Comfort Mode

The Eye Comfort Mode reduces screen brightness, increases yellow tones, and decreases blue light emission. This

setting is compatible with digital reading applications, reducing eye fatigue and protecting vision during prolonged use.

Cameras

The tablet is equipped with a 5 MP front camera and an 8 MP rear camera, suitable for video calls and capturing everyday moments.

Audio

Experience enhanced audio with dual speakers and a 3.5mm headphone jack for private listening. The digital amplifier ensures clear sound quality.

Kids Mode

Parents can easily create a secure and reliable digital environment for their children. This mode includes settings for usage time limits, rest time parameters, and content restrictions to support stimulating learning habits.




Image: Kids Mode for child protection and development.

MAINTENANCE

Battery Care

The tablet is equipped with a 5000mAh battery. To maximize battery life:

- Avoid extreme temperatures.
- Do not let the battery fully discharge frequently.
- Use the provided USB-C charging cable.

Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials.

Software Updates

Regularly check for and install system updates to ensure your tablet has the latest features, security patches, and performance improvements. You can usually find this option in **Settings > System > System update**

TROUBLESHOOTING

Device Not Powering On

- Ensure the battery is charged. Connect the tablet to a power source using the USB-C cable and allow it to charge for at least 30 minutes before attempting to power on again.
- Press and hold the Power Button for 10-15 seconds to perform a forced restart.

Wi-Fi Connection Issues

- Restart your Wi-Fi router and the tablet.
- Go to **Settings > Network & internet > Wi-Fi** and try forgetting the network and reconnecting.
- Ensure you are within range of the Wi-Fi signal.

Slow Performance

- Close unused applications running in the background.
- Clear cache data for frequently used apps in **Settings > Apps**.
- Ensure sufficient storage space is available. Delete unnecessary files or move them to external storage.
- Restart the tablet.

SPECIFICATIONS

Feature	Specification
Brand	RebotAi
Model Name	D101
Operating System	Android 16
Processor	Allwinner A333, 1.8 GHz
RAM	16 GB (4 GB physical + 12 GB expandable)
Internal Storage (ROM)	64 GB
Expandable Storage	Up to 1 TB via microSD
Screen Size	10.1 Inches
Display Resolution	1280 x 800 Pixels (IPS TDDI)
Brightness	400 nits
Refresh Rate	60 Hz
Wi-Fi Technology	Wi-Fi 6 (802.11ax), Dual-band (2.4GHz/5GHz)
Bluetooth	Bluetooth 5.2
Battery Capacity	5000 mAh
Front Camera	5 MP

Feature	Specification
Rear Camera	8 MP
Special Features	Facial Recognition, Gemini AI, Widevine L1, Low SAR Radiation Technology
Ports	USB-C (2 total), 3.5mm Headphone Jack
Dimensions (L x W x H)	24 x 15 x 0.8 cm
Weight	454 Grams



Image: Tablet utilizing Low SAR Radiation Technology.

WARRANTY AND SUPPORT

RebotAi offers a **2-year warranty** for your tablet. We are committed to providing exceptional customer service.

Contacting Customer Support

If you encounter any technical issues or require assistance, please contact us through one of the following methods:

- Amazon Account:** Go to your Order History, select your order, and click 'Contact Seller'.
 - Official Email:** Refer to the email address provided in your product packaging or on the official RebotAi website.
- Our customer service team aims to respond within 24 hours (excluding Saturdays, Sundays, and manufacturer holidays).



Nous sommes à l'écoute de nos clients et nous nous efforçons d'améliorer constamment la qualité de nos produits et de nos services.



Garantie de deux ans

Nous contacter :

- Compte Amazon → Historique des commandes → Commandes → Contacter le vendeur
- Contactez-nous à l'adresse e-mail officielle indiquée dans le manuel d'utilisation.

Service client : Réponse sous 24 h (hors samedis, dimanches et jours fériés du fabricant)

Image: Two-year warranty information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question