

[Manuals.plus](#) /

> [VASAGLE](#) /

> VASAGLE TV Stand with Storage, Farmhouse Entertainment Center for 80" TV (Model ULTV624W201S)

VASAGLE ULTV624W201S

VASAGLE TV Stand with Storage Instruction Manual

Model: ULTV624W201S

1. INTRODUCTION

Thank you for choosing the VASAGLE TV Stand with Storage. This farmhouse-style entertainment center, featuring a rustic white and honey brown finish, is designed to accommodate televisions up to 80 inches. It provides both open and concealed storage options to help organize your living space. This manual contains important information regarding the assembly, safe use, and maintenance of your new TV stand. Please read it thoroughly before beginning assembly and retain it for future reference.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum static load capacity of 300 lb (136 kg) on the tabletop and 35 lb (16 kg) on any individual shelf. Overloading can cause instability and potential injury.
- **Anti-Tip Device:** For safety, it is highly recommended to secure the TV stand to the wall using an anti-tip device (if included) to prevent accidental tipping, especially in households with children or pets.
- **Assembly:** Assembly should be performed by two adults. Ensure all parts are present and undamaged before starting. Follow the instructions carefully.
- **Placement:** Place the TV stand on a flat, stable surface. Avoid placing it in areas with high humidity or direct sunlight to prevent material damage.
- **Children:** Do not allow children to climb on or play with the TV stand.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged:

- 1 x TV Stand
- 1 x Accessory Kit (includes screws, dowels, etc.)
- 1 x Instructions Manual
- 1 x Allen Key

4. ASSEMBLY INSTRUCTIONS

Assembly of this TV stand is designed to be straightforward. Please follow these general guidelines:

1. **Preparation:** Clear a spacious area for assembly. Lay out all parts on a soft, clean surface to prevent scratches.
2. **Identify Parts:** All parts are labeled. Refer to the included instructions and diagrams to identify each component.
3. **Step-by-Step:** Follow the clear, illustrated instructions provided in the accessory kit. Do not skip steps.
4. **Tools:** An Allen key is included. You may also need a Phillips head screwdriver (not included).
5. **Teamwork:** For optimal ease and safety, assembly is recommended for two people and typically takes approximately one hour.
6. **Tighten Fasteners:** Once fully assembled, ensure all screws and fasteners are securely tightened. Do not overtighten.



Image: The fully assembled VASAGLE TV Stand, showcasing its rustic white and honey brown design in a living room setting.

5. USAGE

Your VASAGLE TV Stand is designed for versatile use and storage:

- **TV Placement:** The 70"L x 15.7"W tabletop can accommodate TVs up to 80 inches. Ensure the TV base fits securely within the tabletop dimensions.
- **Open Compartments:** Utilize the two open compartments for media players, game consoles, or other electronic devices that require ventilation or easy access.
- **Enclosed Cabinets:** The two side cabinets provide discreet storage for items you wish to keep out of sight, helping maintain a tidy appearance.
- **Adjustable Shelf:** The middle shelf offers three height options. It can also be removed entirely to accommodate taller items.
- **Cable Management:** Four cable holes are integrated into the back panel to help organize and route wires, preventing tangles and ensuring a cleaner look for your entertainment setup.

Double as a Storage Cabinet



Image: A close-up view of the TV stand's storage, showing open compartments and a side cabinet with its door ajar, revealing organized media and decor.



Fits up to 80" TVs




Image: The rear view of the TV stand highlighting the four cable holes designed for organizing electronic device wires.

6. MAINTENANCE

To ensure the longevity and appearance of your VASAGLE TV Stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.

- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Inspection:** Periodically check all fasteners and re-tighten if necessary to maintain stability.
- **Avoid Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.

7. TROUBLESHOOTING

If you encounter any issues with your TV stand, consider the following:

- **Wobbly Stand:** Ensure all screws and fasteners are tightened. Check that the stand is placed on a level surface. Adjust glides if present.
- **Missing Parts:** If any parts were missing upon delivery, refer to the package contents list and contact customer support for assistance.
- **Assembly Difficulty:** Review the instruction manual diagrams carefully. If a step is unclear, try re-reading it or seeking assistance from another person.

8. SPECIFICATIONS

Brand	VASAGLE
Model Number	ULTV624W201S
Color	Rustic White + Honey Brown
Material Type	Particleboard, MDF (Medium Density Fiberboard)
Item Dimensions (L x W x H)	70 x 15.7 x 23.6 inches (178 x 40 x 60 cm)
Item Weight	76.9 pounds (34.9 kg)
Max. Static Load Capacity (Tabletop)	300 lb (136 kg)
Max. Static Load Capacity (Shelf)	35 lb (16 kg)
Number of Shelves	3
UPC	194343534480



Thick, Stylish Panels



2 Colors Available

Image: A diagram illustrating the dimensions of the TV stand and its maximum static load capacities for the tabletop and shelves.

9. WARRANTY AND SUPPORT

For warranty information, missing parts, or any product-related inquiries, please contact the retailer or manufacturer directly. Keep your purchase receipt and model number (ULTV624W201S) handy for faster service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GWWGYWRX9>

More documents and user manuals: <https://manuals.plus/>