Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hupoaf V69D

Hupoaf Wireless Induction Speaker/Phone Stand V69D User Manual

Model: V69D

Introduction

Thank you for choosing the Hupoaf Wireless Induction Speaker/Phone Stand V69D. This device integrates a Bluetooth 6.0 speaker, wireless induction speaker, phone stand, LED time display, alarm clock, snooze function, power-saving mode, and colorful ambient light. Please read this manual carefully before use to ensure proper operation and to maximize your experience with the product.

Package Contents

- Hupoaf Wireless Induction Speaker/Phone Stand V69D
- Quick Start Guide
- USB-C Charging Cable
- 1 A battery (pre-installed)

Product Overview

The Hupoaf V69D is a versatile 9-in-1 device designed to enhance your mobile experience. It features:

- **Bluetooth 6.0 Speaker:** For stable wireless audio streaming.
- **Wireless Induction Speaker:** Supports both horizontal and vertical screen sensing for audio playback without Bluetooth pairing.
- **Phone Stand:** Adjustable and foldable design for optimal viewing angles.
- **LED Time Display:** Clear digital clock display.
- **Alarm Clock:** Customizable alarms with snooze function.
- **Power-Saving Function:** Optimizes battery life.
- **Colorful Ambient Light:** Dynamic RGB lighting.



Figure 1: Overview of the Hupoaf V69D 9-in-1 Phone Speaker Stand, highlighting its various functions including Bluetooth 6.0, horizontal and vertical screen sensing, colorful ambient light, phone stand, time display, alarm clock, snooze function, and energy saving.



Figure 2: The Hupoaf V69D Multifunctional Phone Stand Speaker, showcasing its compact design and integrated features.

Setup

1. Charging the Device

Before first use, fully charge the Hupoaf V69D. Connect the provided USB-C cable to the charging port on the device and the other end to a compatible USB power adapter (not included).

- The LED display may indicate charging status.
- A full charge typically takes a few hours.



Figure 3: The Hupoaf V69D features a built-in 2600mAh rechargeable battery for extended use.

2. Adjusting the Phone Stand

The phone stand is foldable and adjustable. Gently unfold the stand to your desired viewing angle. Ensure your device is securely placed in the anti-slip groove.

Your browser does not support the video tag.

Video 1: This video demonstrates how to adjust the stand and panel of the Hupoaf V69D for optimal phone placement and viewing angles.




Figure 4: Detailed view of the Hupoaf V69D components, including the sensing module, anti-slip groove, flexible angle adjustment, color

light button, USB-C port, and LED time display.

Operating Instructions

1. Power On/Off

Press and hold the power button (usually located on the device, refer to Figure 4) to turn the speaker on or off.

2. Bluetooth Mode

1. Ensure the speaker is powered on.
2. Activate Bluetooth on your smartphone or tablet.
3. Search for "Hupoaf V69D" (or similar name) in your device's Bluetooth settings.
4. Select the speaker to pair. A confirmation sound may indicate successful pairing.



Figure 5: The Hupoaf V69D utilizes advanced Bluetooth 6.0 technology for stable and efficient wireless connections.

3. Wireless Induction Mode

This mode allows audio playback by simply placing your phone on the stand, without Bluetooth pairing.

- **Horizontal Screen Sensing:** Unfold both sensing arms of the stand. Place your phone horizontally, aligning its speaker with either sensing area on the stand.
- **Vertical Screen Sensing:** Keep the sensing arms folded. Place your phone vertically, aligning its speaker with the central sensing area.

Ensure your phone's speaker is positioned directly over the induction area for optimal sound transfer.



Figure 6: Instructions for Landscape Mode induction sensing. Unfold both sensors, place the phone sideways, and point the phone speaker at either sensor to connect.

New Bluetooth 6.0 brings you a more stunning experience

Compatible with multiple devices+Powerful support



Figure 7: Instructions for Vertical Screen induction sensing. Keep sensors folded, place the phone upright, and align the phone speaker with the sensor area to connect.

Modes for You to Choose From







Figure 8: The Hupoaf V69D offers three operational modes: Induction Mode (supports both landscape and portrait), Bluetooth Mode (Bluetooth 6.0 for stable connection), and Power Saving Mode.

4. Setting Time and Alarm

The LED display shows the current time. Refer to the Quick Start Guide for specific button functions to set the time and configure alarms. The snooze function can be activated after an alarm sounds.



Figure 9: The Hupoaf V69D features an LED display for time and includes alarm clock functionality, making it suitable for bedside use.



Figure 10: The Hupoaf V69D functions as an all-in-one stand speaker, offering time display, alarm clock features, and colorful ambient lights.

5. Colorful Ambient Light

Press the dedicated color light button (refer to Figure 4 for location) to cycle through different light modes or turn the lights off. The lights can sync with music rhythms.

6. Power Saving Mode

The device automatically enters power-saving mode after a period of inactivity to conserve battery. You can also manually activate it if available, or simply turn off features not in use.

Specifications

Feature	Detail
Brand	Hupoaf
Model Number	V69D
Connectivity Technology	Bluetooth
Bluetooth Version	6.0
Speaker Maximum Output Power	150 watts
Audio Output Mode	Stereo
Battery Capacity	2600 mAh
Battery Average Life	12-15 hours (continuous playback)
Power Source	Battery Powered
Item Dimensions (D x W x H)	3"D x 2"W x 3"H

Compatible Devices	Smartphone, Tablet
Special Features	Wireless Induction (Horizontal/Vertical Sensing), LED Time Display, Alarm Clock, Snooze, Power Saving, RGB Ambient Light, Phone Stand

Maintenance

- Keep the device clean by wiping it with a soft, dry cloth.
- Avoid exposing the device to extreme temperatures, direct sunlight, or moisture.
- Do not use abrasive cleaners or solvents.
- Store in a cool, dry place when not in use for extended periods.

Troubleshooting

No Sound in Induction Mode:
Ensure your phone's speaker is directly aligned with the induction area on the stand. Adjust phone position if necessary. Check phone volume.

Bluetooth Pairing Issues:
Make sure the speaker is in Bluetooth pairing mode. Turn off and on Bluetooth on your phone. Ensure no other devices are connected to the speaker. Try restarting both devices.

Device Not Powering On:
Check battery level. Connect the device to a power source using the USB-C cable and allow it to charge for at least 30 minutes before attempting to power on again.

Alarm Not Sounding:
Verify that the alarm time is correctly set and the alarm function is enabled. Check the volume level of the speaker.

Warranty and Support

The Hupoaf V69D comes with a limited warranty. For detailed warranty information and customer support, please refer to the documentation included with your product or contact Hupoaf customer service directly. Keep your purchase receipt for warranty claims.

© 2026 Hupoaf. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GWHL1DN9

More documents and user manuals: **https://manuals.plus/**