

[Manuals.plus](#) /

› [HZD](#) /

› HZD Wireless Bluetooth Keyboard Instruction Manual

HZD HZD Wireless Bluetooth Keyboard

HZD Wireless Bluetooth Keyboard Instruction Manual

Model: HZD Wireless Bluetooth Keyboard

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the HZD Wireless Bluetooth Keyboard. This ultra-thin, lightweight, and rechargeable keyboard is designed for universal compatibility with various devices. It features a comfortable scissor-switch key mechanism, silent keys, and a 7-color backlit design to enhance your typing experience.

This manual provides detailed instructions for setting up, operating, and maintaining your keyboard, along with troubleshooting tips and product specifications.




Image: HZD Wireless Bluetooth Keyboard in Watermelon Red, showcasing its sleek design.

2. SETUP INSTRUCTIONS

2.1 Charging the Keyboard

Before first use, fully charge the keyboard. Connect the provided Type-C charging cable to the keyboard's charging port and a USB power source. The CHARGE indicator light will remain on during charging and turn off once fully charged. A full charge typically takes 2 to 3 hours.



Image: The HZD Wireless Bluetooth Keyboard connected to a Type-C charger, illustrating the charging process and battery specifications.

2.2 Bluetooth Pairing

1. Turn on the keyboard by sliding the ON/OFF switch to the 'ON' position. The POWER indicator will light up.
2. Press and hold the 'CONNECT' button for 3 seconds. The BT (Bluetooth) indicator light will start blinking, indicating the keyboard is in pairing mode.
3. On your device (tablet, smartphone, laptop), go to Bluetooth settings and enable Bluetooth.


4. Search for available devices. You should see 'Bluetooth Keyboard' in the list. Select it to connect.
5. Once connected, the BT indicator light will stop blinking and remain solid for a moment before turning off.

Istruzioni di connessione



Portare l'interruttore su ON.

Premere "CONNECT"
per 3 secondi.



Attivare il Bluetooth, cercare
"Bluetooth Keyboard" ed
effettuare la connessione.


Image: Visual guide demonstrating how to turn on the keyboard, activate pairing mode, and connect via Bluetooth on a device.

2.3 System Switching

To ensure proper functionality and key mapping, switch the keyboard to the correct operating system mode:

- For Android devices: Press **Fn + Android**
- For Windows devices: Press **Fn + Windows**
- For iOS devices: Press **Fn + iOS**

Note: This keyboard is not compatible with Mac computers.




1. Passaggio 1: Passare al sistema corrispondente. ✓
2. Passaggio 2: Passare alla lingua corrispondente.

Image: A diagram illustrating the Fn key combinations required to switch the keyboard's operating mode for Android, Windows, and iOS devices.

2.4 Language Switching

To change the input language on your device using the keyboard:

- On Android: Press **Shift + Space**
- On iOS: Press **Control + Space**
- On Windows: Press **Win + Space**, or **Shift + Alt**, or **Control + Shift**



1. Passaggio 1: Passare al sistema corrispondente.
2. Passaggio 2: Passare alla lingua corrispondente. ✓

Image: A diagram detailing the key combinations for changing the input language on Android, iOS, and Windows operating systems.

3. OPERATING INSTRUCTIONS

3.1 Automatic Sleep Mode

To conserve battery, the keyboard will automatically enter sleep mode after 10 minutes of inactivity. To reactivate it, simply press any key and wait briefly for it to reconnect.

3.2 Backlight Control

The keyboard features a 7-color backlight with three modes:

- **Always On:** Constant illumination.
- **Breathing:** Pulsating illumination effect.
- **Off:** Backlight disabled.

Use the dedicated backlight adjustment switch or key combination (refer to keyboard layout) to cycle through colors and modes.



Image: Several HZD Wireless Bluetooth Keyboards showcasing the variety of 7 backlight colors and different illumination modes.

3.3 Function Keys

The keyboard includes various function keys for quick access to common commands:

Function	Description
Home	Return to home screen
Search	Activate search function
Select All	Select all content
Copy	Copy selected content
Paste	Paste copied content
Cut	Cut selected content
Previous Track	Go to previous media track
Play/Pause	Play or pause media
Next Track	Go to next media track
Volume Down	Decrease volume
Volume Up	Increase volume
Brightness Down	Decrease screen brightness
Brightness Up	Increase screen brightness
Lock Screen	Lock the device screen
Backlight	Toggle backlight on/off or change mode

Function	Description
RGB	Cycle through backlight colors



Image: The HZD Wireless Bluetooth Keyboard layout, highlighting the various function keys and their associated commands for media, volume, brightness, and backlight control.

4. MAINTENANCE

4.1 Cleaning

To clean your keyboard, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the keyboard's electronics and finish.

4.2 Battery Care

To prolong battery life, avoid fully discharging the keyboard frequently. Recharge it when the POWER indicator blinks, signaling low battery. Store the keyboard in a cool, dry place away from extreme temperatures.

5. TROUBLESHOOTING

If you encounter issues with your HZD Wireless Bluetooth Keyboard, please refer to the following common solutions:

5.1 Keyboard Not Connecting/Pairing

- Ensure the keyboard is turned ON and fully charged.
- Make sure Bluetooth is enabled on your device.
- Place the keyboard within 10 meters (33 feet) of your device.
- Try unpairing and re-pairing the keyboard from your device's Bluetooth settings.
- Restart both the keyboard and your device.

5.2 Keys Not Responding or Laggy Typing

- Check the battery level; recharge if low.
- Ensure the keyboard is properly paired and connected.
- Verify that the correct operating system mode is selected (Fn + Android/Windows/iOS).
- Minimize interference by moving away from other wireless devices.

5.3 Incorrect Characters or Layout

- Confirm that the keyboard is set to the correct operating system mode (Fn + Android/Windows/iOS).
- Ensure your device's input language settings match the keyboard's physical layout (Italian QWERTY). Adjust language settings on your device if necessary.
- Use the appropriate language switching shortcuts (Shift + Space, Control + Space, Win + Space, etc.) for your device's OS.

5.4 Backlight Not Working

- Check the battery level; the backlight consumes more power.
- Ensure the backlight is not turned off. Use the backlight control key to cycle through modes.

6. SPECIFICATIONS

Feature	Detail
Dimensions	25 x 15.5 x 0.5 cm (9.84 x 6.1 x 0.2 inches)
Weight	205 grams
Battery Capacity	500 mAh Lithium Battery
Charging Time	2-3 hours
Continuous Use Time	Approx. 80 hours (approx. 3 hours with backlight active)
Standby Time	Up to 130 days
Wireless Range	Up to 10 meters (33 feet)
Key Mechanism	Scissor-switch
Key Lifespan	Over 5 million keystrokes
Charging Port	Type-C
Compatibility	iOS, Android, Windows (Not compatible with Mac)



Capacità batteria
al litio: **500 mAh**



Tempo di ricarica: **2 ore**



Tempo di standby: **>130 giorni**



Indicatore batteria scarica:
POWER (lampeggiante)

Image: A visual representation of the keyboard's battery specifications, including capacity, charging time, and standby duration.

Una tastiera più sottile e leggera



Image: The HZD Wireless Bluetooth Keyboard with its ultra-thin dimensions (250mm x 155mm x 5mm) and lightweight (205g) clearly labeled.

7. WARRANTY AND SUPPORT

7.1 Product Warranty

This HZD Wireless Bluetooth Keyboard comes with a 1-year product warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

7.2 Customer Support

For any issues not resolved by the troubleshooting section, or for warranty claims, please contact the seller or manufacturer directly through your purchase platform. Provide your order number and a detailed description of the problem for efficient assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question