

[Manuals.plus](#) /

› [VASAGLE](#) /

› VASAGLE Accent Chair ULYY200LZ01S Instruction Manual

VASAGLE ULYY200LZ01S

VASAGLE Accent Chair Instruction Manual

Model: ULYY200LZ01S

INTRODUCTION

Thank you for choosing the VASAGLE Accent Chair ULYY200LZ01S. This manual provides detailed instructions for assembly, usage, maintenance, and troubleshooting to ensure safe and proper operation of your new chair. Please read this manual thoroughly before assembly and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep all packaging materials away from children to prevent choking hazards.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the chair or use it as a step stool.
- Do not exceed the maximum weight capacity of 300 lbs (136 kg).
- Keep the chair away from direct heat sources and prolonged direct sunlight to prevent material damage or fading.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

Item	Description	Quantity
Leisure Chair	Main chair frame and upholstered components	1

Item	Description	Quantity
Accessory Kit	Hardware (screws, bolts, Allen wrench)	1
Instructions	Assembly guide	1

ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. Follow these steps carefully.



Figure 1: Overview of the 3-step assembly process.

Step 1: Install Armrests

Attach the wooden armrests to the side frames of the chair. Ensure the pre-drilled holes align correctly. Use the provided screws and Allen wrench to secure them firmly. Do not overtighten.

Step 2: Attach Backrest & Cushion

Slide the upholstered backrest into its designated slots on the frame. Then, place the seat cushion onto the chair frame, ensuring it sits securely and evenly.

Step 3: Complete the Frame

Connect any remaining frame components as indicated in the detailed instructions provided in the accessory kit. Ensure all connections are stable and all fasteners are tightened. Double-check all connections for stability before using the chair.

USAGE AND ERGONOMICS

The VASAGLE Accent Chair is designed for comfortable seating in various indoor settings such as living rooms, bedrooms, reading nooks, or home offices.




Figure 2: The 105-degree ergonomic angle provides comfortable support for extended periods.

The chair features a 105-degree ergonomic angle for the backrest, promoting a relaxed posture ideal for reading or lounging. Curved armrests provide additional support and comfort for your arms.




Figure 3: Outward-angled legs enhance overall stability and balance.

The design incorporates outward-angled legs to enhance stability and prevent tipping. The seat cushion is 6.3 inches thick with supportive springs, offering lasting comfort. The upholstery is made from durable cationic fabric, providing a breathable linen-look surface.



Figure 4: Seat dimensions and cushion thickness for enhanced comfort and strength.

MAINTENANCE AND CARE

- **Cleaning:** For general cleaning, wipe the wooden frame with a soft, damp cloth. For the fabric upholstery,

spot clean with a mild detergent and a clean cloth. Blot dry immediately. Avoid harsh chemicals or abrasive cleaners.

- **Spills:** Immediately blot spills with a clean, dry cloth to prevent staining.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading and material degradation.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten as needed to maintain stability and safety.
- **Moving:** When moving the chair, lift it rather than dragging it to prevent damage to the legs and frame.

TROUBLESHOOTING

- **Chair feels wobbly:** Ensure all assembly screws and bolts are fully tightened. If the issue persists, disassemble and reassemble, paying close attention to aligning all parts correctly.
- **Parts do not fit:** Double-check that you are using the correct parts for each step as indicated in the assembly guide. Do not force parts together. If a part appears defective, contact customer support.
- **Screws are too long/short:** Verify that you are using the correct screws for the designated holes. If the provided hardware is incorrect, contact customer support for replacement parts.
- **Squeaking noises:** Tighten all fasteners. Applying a small amount of silicone lubricant to joints can also help reduce noise.

SPECIFICATIONS

Feature	Detail
Model Number	ULYY200LZ01S
Product Dimensions (D x W x H)	29.5" x 24.6" x 28.7" (75 cm x 62.5 cm x 73 cm)
Seat Depth	20.9" (53 cm)
Seat Cushion Thickness	6.3" (16 cm)
Item Weight	22 lbs (10 kg)
Maximum Weight Recommendation	300 lbs (136 kg)
Materials	Plywood, MDF, Cationic Fabric, Foam
Color	Beige
Indoor/Outdoor Usage	Indoor



Figure 5: Detailed product dimensions.

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or visit the official VASAGLE website. If you encounter any issues or have questions regarding your VASAGLE Accent Chair, please contact VASAGLE customer support for assistance.