

BLOKEES GV02

BLOKEES Naruto Shippuden GV02 Model Kit Instruction Manual

Model: GV02 - The Place The Leaves Dance Series

INTRODUCTION

This instruction manual provides essential information for the assembly, operation, and care of your BLOKEES Naruto Shippuden GV02 "The Place The Leaves Dance" surprise model kit. Each kit allows you to assemble an iconic character from the Naruto Shippuden universe, featuring upgraded articulation and character-specific accessories. The series includes characters such as Kakashi Hatake, Hinata Hyuga, Tsunade, Rock Lee, Might Guy, Tenten, Neji Hyuga, Kabuto Yakushi, and Orochimaru. Rare chase variants of Naruto Uzumaki (Sage Mode) and Jiraiya are also available.

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts.

This product contains small parts and is not suitable for children under 3 years of age. Recommended age for assembly and play is 9 years and up. Adult supervision is recommended during assembly for younger users.

- Keep all packaging materials away from children.
- Do not put parts in mouth.
- Dispose of any broken parts safely.

PACKAGE CONTENTS

Each BLOKEES Naruto Shippuden GV02 surprise model kit box includes:

- 1 x Surprise Model Kit (unassembled figure)
- Character-specific Accessories
- Special Effect Display Stand
- Collector's Card
- Instruction Booklet

A full set box contains nine individual kits, with a chance to receive a rare chase variant.



Figure 1: Packaging dimensions for single and full set boxes.

SETUP AND ASSEMBLY

Your BLOKEES model kit requires assembly. No tools, cutting, paint, or glue are required. Follow the detailed steps provided in the included instruction booklet for your specific character.

1. **Unpack Components:** Carefully open the packaging and remove all plastic parts from their runners. Ensure all pieces listed in the instruction booklet are present.
2. **Identify Parts:** Refer to the instruction booklet to identify each part. Parts are typically numbered or shaped uniquely for easy identification.
3. **Assemble Body Sections:** Begin by assembling the main body sections (torso, head, limbs) as indicated in the

manual. Parts are designed to snap together securely.

4. **Attach Accessories:** Once the main figure is assembled, attach any character-specific accessories such as weapons, special effect pieces, or additional clothing elements.
5. **Connect to Display Stand:** Secure the assembled figure onto its special effect display stand. The stand is designed to support dynamic poses.
6. **Verify Assembly:** Gently test the articulation points to ensure all parts are correctly connected and move freely within their intended range.

If you encounter difficulty, refer to the visual diagrams in your instruction booklet. Do not force parts together, as this may cause damage.

OPERATING AND POSING YOUR FIGURE

BLOKEES figures feature upgraded articulation with up to 180° joint rotation, allowing for a wide range of dynamic poses.

- **Joint Movement:** Gently manipulate the joints at the neck, shoulders, elbows, wrists, waist, hips, knees, and ankles to achieve desired poses.
- **Dynamic Stances:** Utilize the articulation to recreate iconic jutsu moves, battle stances, and memorable moments from the Naruto Shippuden series.
- **Accessory Integration:** Position character-tailored accessories (e.g., Lightning Cutter, Rasenshuriken, Gentle Step Twin Lion Fists, Hidden Shadow Snake Hands) to enhance the figure's pose.
- **Display Stand:** The special effect display stand provides stability for complex or airborne poses. Ensure the figure is securely attached to prevent accidental falls.





Figure 2: Kakashi Hatake figure demonstrating articulation and accessory use.





Figure 3: Naruto Uzumaki (Sage Mode) figure in a dynamic action pose.





Figure 4: Rock Lee figure demonstrating poseability.

MAINTENANCE

To ensure the longevity and appearance of your BLOKEES model kit, follow these maintenance guidelines:

- **Cleaning:** Dust the figure regularly with a soft, dry cloth or a soft brush. For stubborn dirt, lightly dampen a cloth with water and gently wipe the surface, then dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity to prevent discoloration or material degradation.
- **Handling:** Handle the figure by its main body parts rather than delicate accessories or thin limbs to avoid breakage.
- **Joint Care:** If joints become stiff, gently rotate them to loosen. Avoid excessive force. If a joint becomes loose, it may be possible to tighten it with a small amount of clear nail polish or a similar adhesive applied sparingly to the joint peg, allowed to dry, then reassembled.

TROUBLESHOOTING

Problem: Parts do not fit together.

Solution: Ensure you are using the correct parts as indicated in the instruction booklet. Verify the orientation of the parts. Some parts may require a firm but gentle push to snap into place. Do not force parts if they do not align correctly.

Problem: A part is missing or damaged.

Solution: Carefully check all packaging materials. If a part is genuinely missing or damaged upon opening, please contact BLOKEES customer support (see "Support" section) with your purchase details and a description of the issue.

Problem: Figure is unstable on the display stand.

Solution: Ensure the figure's feet or designated attachment points are securely connected to the display stand. Adjust the figure's pose to balance its weight distribution. The stand is designed for stability, but extreme poses may require careful balancing.

Problem: Joints are too loose or too stiff.

Solution: For stiff joints, gently work them back and forth to loosen. For loose joints, a small amount of clear nail polish applied to the peg and allowed to dry before reassembly can add friction. Apply sparingly to avoid permanent bonding.

SPECIFICATIONS

Feature	Detail
Brand	BLOKEES
Model Series	Naruto Shippuden GV02
Figure Height	Approximately 4.06 inches (10.3 cm)
Piece Count	Approx. 23–44 pieces per kit
Articulation	Up to 180° joint rotation
Material	ABS environmentally friendly plastic
Recommended Age	9 years and up
Assembly	Assembly required, no tools, cutting, paint, or glue needed
Included Components	Instruction Guide, Parts and accessories for 9 complete Models (per full set box)
Item Weight	16 ounces (full set box)

GTIN (UPC)	810181530483
Model Number	71047 GV01 (Note: GV02 series, model number may refer to a specific product variant)

WARRANTY INFORMATION

BLOKEES products are manufactured to high-quality standards. For specific warranty details, please refer to the terms and conditions provided by your retailer at the time of purchase. In most cases, issues related to manufacturing defects or missing parts should be reported to the retailer or BLOKEES customer support within a reasonable period after purchase.

SUPPORT AND CONTACT

For further assistance, questions, or to report missing/damaged parts, please contact BLOKEES customer support through their official channels or visit their brand store.
BLOKEES Official Store: [Visit the BLOKEES Store on Amazon](#)
Please have your product model number (GV02) and purchase information ready when contacting support.

© 2026 BLOKEES. All rights reserved. Naruto Shippuden ™ © Masashi Kishimoto / Shueisha, TV Tokyo, Pierrot.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GWKGGPTD>

More documents and user manuals: <https://manuals.plus/>