

QCY MeloBuds A30

QCY MeloBuds A30 Wireless Earbuds User Manual

PRODUCT OVERVIEW

The QCY MeloBuds A30 are advanced wireless earbuds designed for an immersive audio experience. They feature adaptive active noise cancellation, clear call technology, and multi-device connectivity.

Key Features

- **-60dB AI Adaptive ANC with Ultra-Wide 5.5kHz Range:** Deep noise cancellation that adjusts to your environment, including wind.
- **8-Mic AI Call Enhancement & Three Device Connection:** Ensures crystal-clear calls and seamless switching between up to three devices.
- **LDAC Hi-Res Certified Immersive Sound Experience:** Delivers high-fidelity audio with rich bass, crisp highs, and detailed mid-range.
- **Ultra-Long Battery Life and IPX5 Water Resistance:** Up to 50 hours total playtime with the charging case and protection against sweat and light splashes.
- **Intuitive Touch Control and Customizable QCY App:** Easy control of music, calls, voice assistants, and ANC modes, with personalized settings via the QCY app.

WHAT'S IN THE BOX

Verify that all items are present in the package:

- QCY MeloBuds A30 Earbuds
- Type-C Charging Cable
- User Manual
- Ear Tips (3 pairs)

Esplora di più con QCY APP





Image: Contents of the QCY MeloBuds A30 box including earbuds, charging case, USB-C cable, user manual, and three pairs of ear tips.

SETUP

Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case.
2. Connect the Type-C charging cable to the charging port on the case and to a USB power source.
3. The indicator light on the case will show charging status. A full charge typically takes approximately 2 hours for the case.



Potenza Durata

10Min ⚡
=
2H 🔋

ON ANC

6H

Single Playback

27H

Total Battery Life

ANC **OFF**

11H

Single Playback

50H

Total Battery Life

Image: The QCY MeloBuds A30 charging case with earbuds inside, illustrating the charging process and battery life.

Pairing with a Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "QCY MeloBuds A30" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear a confirmation tone.

 **Bluetooth® 6.0**



Image: QCY MeloBuds A30 earbuds and case shown with a smartphone and tablet, illustrating the multi-device connection feature.

OPERATING INSTRUCTIONS

Touch Controls

The earbuds feature intuitive touch controls. Refer to the diagram below for specific functions.



Controllo Touch Intelligente

- | | |
|--|---|
| ●● Pause / Play / Answer Call / Hang Up
Double Tap | ●●● Last Track
Triple Tap (L) |
| ●●● Next Track
Triple Tap (R) | 1.5S Reject Call
Tap and Hold 1.5s (L/R) |
| ●●● Activate Voice Assistant
Triple Tap (R) | 1.5S ANC Mode
Tap and Hold 1.5s (R)
(ANC ON - ANC OFF -
Transparency Mode) |

Image: A detailed diagram illustrating the touch control functions for the QCY MeloBuds A30 earbuds, including play/pause, track skipping, call management, voice assistant activation, and ANC mode switching.


- **Pause / Play / Answer Call / Hang Up** Double Tap (L/R earbud)
- **Next Track:** Triple Tap (R earbud)
- **Last Track:** Triple Tap (L earbud)
- **Activate Voice Assistant:** Triple Tap (R earbud)
- **Reject Call:** Tap and Hold 1.5s (L/R earbud)
- **ANC Mode Switch:** Tap and Hold 1.5s (R earbud) to cycle through ANC ON, ANC OFF, and Transparency Mode.

Active Noise Cancellation (ANC) Modes

The MeloBuds A30 offer adaptive ANC to suit your environment.

- **ANC ON:** Provides deep noise cancellation up to -60dB, ideal for noisy environments like public transport or offices.
- **Transparency Mode:** Allows you to hear your surroundings while still enjoying your audio, useful for awareness in urban areas or conversations.

- **ANC OFF:** Disables noise cancellation for standard audio playback.



ANC OFF

ON ANC

ANC Adattabile Alla Scena

Senza il tuo ambiente e regola automaticamente il livello perfetto di cancellazione del rumore.

-60dB 

5.5KHz 

Image: A woman wearing QCY MeloBuds A30 earbuds in a city setting, demonstrating the adaptive ANC feature with visual cues for ANC on and off.

Multi-Device Connection

The earbuds support simultaneous connection to up to three devices, allowing for seamless switching.

To switch between connected devices, simply play audio on the desired device. The earbuds will automatically switch to that source.

MAINTENANCE

Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and case.
- For stubborn dirt, lightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Clean the ear tips with water and mild soap if necessary, ensuring they are completely dry before reattaching.

Water Resistance (IPX5)

The QCY MeloBuds A30 are IPX5 water-resistant, meaning they can withstand sweat and light splashes. They are not designed for submersion in water.




Image: QCY MeloBuds A30 earbuds covered in water droplets, demonstrating their IPX5 sweat and splash resistance.

SPECIFICATIONS

Feature	Detail
Brand	QCY
Model Name	MeloBuds A30
Connectivity Technology	Wireless (Bluetooth 6.0)
Noise Control	Adaptive Active Noise Cancellation (-60dB, 5.5kHz range)
Microphones	8-Mic AI for Call Enhancement
Audio Codec	LDAC Hi-Res Audio
Battery Life (Earbuds)	Up to 11 hours (ANC off), 6 hours (ANC on)
Total Battery Life (with Case)	Up to 50 hours (ANC off), 27 hours (ANC on)
Water Resistance	IPX5
Driver Size	10mm Dynamic Driver
Bluetooth Range	10 meters
Control Type	Touch Control, QCY App
Compatible Devices	Cellphones, Desktops, Laptops, Tablets, Television
Charging Port	Type-C



Image: A technical diagram illustrating the precise dimensions of the QCY MeloBuds A30 earbuds and their charging case.

TROUBLESHOOTING

Common Issues and Solutions

- **No Sound/Poor Sound Quality:**
 - Ensure earbuds are charged.
 - Check Bluetooth connection; re-pair if necessary.
 - Clean ear tips and earbud mesh.
 - Adjust earbud fit.
- **Earbuds Not Pairing:**

- Ensure earbuds are in pairing mode (open case).
 - Turn off and on Bluetooth on your device.
 - Forget the device in your Bluetooth settings and try pairing again.
 - Reset the earbuds (refer to QCY App or full manual for specific reset instructions).
- **ANC Not Working Effectively:**
 - Ensure earbuds are properly seated in your ears to create a good seal.
 - Check that ANC mode is activated via touch control or the QCY App.
- **Touch Controls Unresponsive:**
 - Ensure your fingers are clean and dry.
 - Try restarting the earbuds by placing them in the case and closing it, then reopening.

WARRANTY AND SUPPORT

QCY products come with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or visit the official QCY website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact QCY customer service through their official website or the contact information provided in your product documentation.

You can also explore additional features and customize your earbuds using the official QCY App.




Image: A smartphone displaying the QCY app interface, highlighting options for battery indicator, EQ customization, firmware updates, game mode, and touch control settings.