

[Manuals.plus](#) /

› [cudinham](#) /

› cudinham X6 Mini Sticker Printer Instruction Manual

cudinham X6

cudinham X6 Mini Sticker Printer Instruction Manual

[Overview](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty](#)

[Support](#)

1. PRODUCT OVERVIEW

The cudinham X6 Mini Sticker Printer is a portable thermal printer designed for inkless printing of various items such as photos, notes, labels, and more. It connects via Bluetooth to your smartphone using the 'Tiny Print' application, offering a convenient solution for personal and organizational printing needs. This gift set includes the X6 printer, 5 rolls of adhesive printing paper, and 5 rolls of thermal printing paper.

PACKAGE INCLUDE



Image: The cudinham X6 Mini Sticker Printer gift set, showing the printer, paper rolls, USB cable, and velvet bag.

2. SETUP GUIDE

2.1 Initial Charging

Before first use, ensure the printer is fully charged using the provided USB Type-C cable. Connect the cable to the printer and a low-power USB charging port. **Do not use a fast charging adapter** to prevent potential damage.

2.2 App Installation and Connection

1. **Download the App:** Download the "Tiny Print" application from the Apple App Store (for iOS devices) or Google Play Store (for Android devices).
2. **Enable Bluetooth:** Turn on Bluetooth on your smartphone.
3. **Connect via App:** Open the "Tiny Print" app. The app will guide you to connect to the printer via Bluetooth. **Do not connect the printer through your phone's general Bluetooth settings; connect directly within the app.**


HOW TO USE X6 PRINTER



Note: Please connect via Bluetooth within the app, not in the settings.

01

Download
"Tiny Print"
app on APP
Store or
Google Play.




02

Turn on the
Bluetooth on
your phone.



03

Connect the
printer via app.
(not in Bluetooth
Setting)



04

Edit the
labels you
want & print
it.




Image: Visual guide showing the steps to download the app, enable Bluetooth, and connect the printer within the Tiny Print app.

2.3 Installing Paper Rolls

1. **Open the Lid:** Grab the small handles on both sides of the printer and pull up the lid of the paper bin.
2. **Insert Paper Roll:** Align the paper roll with the groove inside the paper bin, then insert it vertically into the printer.
3. **Position Paper:** Pull out the printing paper slightly to cover the roller.
4. **Close Lid:** Close the printer cover firmly until it clicks into place. The printer is now ready for use.

HOW TO INSTALL PAPER ROLL

01



Grab the small handles on both sides and pull up the lid of the paper bin.

02



Align the paper roll with the groove, then insert it vertically into the printer.

03



Pull out the printing paper to cover the roller.

04



Close the printer cover & prepare to print.

Image: Step-by-step visual instructions for opening the printer, inserting a paper roll, positioning the paper, and closing the lid.

3. OPERATING INSTRUCTIONS

3.1 Basic Printing

Once connected to the "Tiny Print" app, you can select various functions to print. The app provides options for photo printing, graphic editing, materials, sticky notes, and more. You can edit the content within the app, preview it, and then initiate printing.

BLUETOOTH & APP CONNECTED



Tips: Please connect Bluetooth within the "Tiny Print" APP





Bluetooth 5.0



GET IT ON
Google Play
(No payment required)



Download on the
App Store
(No payment required)



Tips:

Please use a low-power USB charging port to charge; do not use a fast charging adapter.

Image: A smartphone displaying the 'Tiny Print' app interface connected to the cudinhham X6 printer, illustrating the Bluetooth connection and printing function.

3.2 App Features

The "Tiny Print" app includes several features to enhance your printing experience:

- **Free Zoom and Drag:** Adjust the size and position of your content before printing.
- **OCR Functions:** Optical Character Recognition allows you to convert images of text into editable text.
- **Templates:** Access a variety of templates for stickers, notes, to-do lists, and more.
- **Editing Options:** Customize text, add images, and apply various design elements.



Image: A collage of smartphone screens demonstrating the multi-functionality of the 'Tiny Print' app, including AI painting, sticky notes, and various templates.

3.3 Printing Applications

The cudinham X6 Mini Sticker Printer supports a wide range of printing applications:

- Black and white photos and pictures.
- Study notes and educational materials.
- To-do lists and shopping lists.
- Custom bookmarks, labels, and journal entries.
- Greeting cards and decorative elements.

4. MAINTENANCE

4.1 Cleaning the Print Head

- If the print quality becomes unclear after repeated use, the laser bar (print head) may need cleaning. To clean it:
1. Ensure the printer is turned off.
 2. Open the paper bin lid.
 3. Gently wipe the laser bar, located inside the paper loading compartment, with a cotton swab lightly dampened with alcohol.
 4. Allow it to dry completely before closing the lid and resuming use.

4.2 Storage

Store the printer in a cool, dry place away from direct sunlight and extreme temperatures. When not in use for extended periods, ensure the battery is partially charged (around 50%) to prolong its lifespan.

5. TROUBLESHOOTING

5.1 Printer Not Turning On

- Ensure the printer is fully charged. Connect it to a power source using the provided USB cable.
- Press and hold the power button for a few seconds.

5.2 Unable to Connect via Bluetooth

- Verify that Bluetooth is enabled on your smartphone.
- Ensure you are connecting through the "Tiny Print" app and not your phone's general Bluetooth settings.
- Restart both the printer and your smartphone, then try connecting again.

5.3 Poor Print Quality

- Check if the paper roll is installed correctly and is not damaged.
- Clean the print head (laser bar) as described in the Maintenance section.
- Ensure the paper type is suitable for thermal printing.

5.4 Paper Jam

- Turn off the printer immediately.
- Open the paper bin lid and carefully remove any jammed paper.
- Reinstall the paper roll correctly and close the lid.

6. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	cudinham
Model Name	X6 Gift Box
Connectivity Technology	Bluetooth 5.0
Printing Technology	Thermal (Inkless)
Printer Output	Monochrome (Black Ink)

Max Print Speed Monochrome	1 page per minute
Item Weight	12.8 ounces
Product Dimensions (D x W x H)	4.25" x 1.96" x 3.26"
Controller Type	Mobile App
Print Media	Thermal Paper
Compatible Devices	Smartphones (Android 4.0+, iOS 9.0+)
Maximum Media Size	57 x 350 mm
Battery	1200mAh Lithium-ion
Resolution	200 DPI

7. WARRANTY INFORMATION

The cudinham X6 Mini Sticker Printer comes with a **1-Year Limited Warranty**. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper maintenance.

8. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your cudinham X6 Mini Sticker Printer, please visit the official cudinham website or contact their customer service department. Refer to the product packaging or the official website for the most current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question