Suevery SV340QD

Suevery 34-inch Ultrawide Curved Monitor SV340QD User Manual

Model: SV340QD

1. Introduction

This manual provides essential instructions for the safe and efficient use of your Suevery 34-inch Ultrawide Curved Monitor. Please read this manual thoroughly before operating the device and retain it for future reference.

The Suevery SV340QD is a 34-inch ultrawide curved monitor designed to enhance your visual experience. It features a 3440x1440 UWQHD resolution, a 75Hz refresh rate, and an IPS panel for vibrant colors and wide viewing angles. The 1900R curvature provides an immersive viewing experience, ideal for both productivity and entertainment. Integrated speakers, FreeSync technology, and VESA mount compatibility further enhance its versatility.



Front view of the Suevery 34-inch Ultrawide Curved Monitor, showcasing its immersive display and key features like 1900R curvature and WQHD resolution.

2. Setup Instructions

2.1 Package Contents

Verify that all items are present in the package:

- Suevery 34-inch Ultrawide Curved Monitor
- Monitor Stand (Base and Neck)
- Power Adapter and Cable
- HDMI Cable
- DisplayPort Cable
- USB Type-C Cable (if included)
- User Manual (this document)

2.2 Stand Assembly

1. Carefully place the monitor face down on a soft, clean surface to prevent scratches.
2. Attach the stand neck to the back of the monitor, aligning the mounting holes. Secure with screws if provided.
3. Attach the stand base to the bottom of the stand neck. Tighten the thumb screw or screws to secure the base.
4. Carefully lift the assembled monitor and place it on a stable, flat surface.

2.3 VESA Mounting

The monitor supports VESA 100x100mm mounting. To use a VESA mount:

- Remove the stand if it is already attached.
- Attach your VESA-compatible monitor arm or wall mount to the four screw holes on the back of the monitor. Ensure the screws are of appropriate length and type for VESA 100x100mm.



Rear view of the monitor, showing the VESA mounting points and port locations.

2.4 Connecting Cables

Connect the necessary cables to the monitor and your computer or other devices:

- **Power Cable:** Connect the power adapter to the monitor's DC input port, then plug the power cable into a power outlet.
- **Video Cables:** Connect an HDMI cable (HDMI 2.0 supported) or a DisplayPort cable (DP 1.4 supported) from your computer's graphics card to the corresponding input ports on the monitor. The monitor has 2 HDMI ports and 2 DisplayPort inputs.
- **Audio Output:** If you wish to use external speakers or headphones, connect them to the 3.5mm audio output jack.



Detailed diagram illustrating the monitor's dimensions and various input/output ports for connectivity.

3. Operating Instructions

3.1 Power On/Off

Press the power button, usually located on the back or bottom of the monitor, to turn the monitor on or off. The power indicator light will illuminate when the monitor is on.

3.2 On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various display settings. The control buttons for the OSD menu are typically located on the back of the monitor. Use these buttons to navigate through the menu options and make adjustments.

Common OSD Settings:

- **Brightness/Contrast:** Adjust the overall luminance and contrast ratio of the display.
- **Color Settings:** Modify color temperature, gamma, and individual RGB values. The monitor supports 8-bit color depth for accurate color reproduction.
- **Input Source:** Manually select between HDMI and DisplayPort inputs.
- **Audio:** Adjust the volume of the built-in speakers or connected headphones.
- **Picture Mode:** Select from preset display modes optimized for different content (e.g., Standard, Game, Movie, Text).

3.3 Key Features

- **Ultrawide Display (21:9):** The 21:9 aspect ratio provides an expansive workspace, allowing for enhanced multitasking and a more immersive viewing experience compared to traditional 16:9 monitors.
- **1900R Curved Screen:** The 1900R curvature matches the natural curve of the human eye, reducing eye strain and providing a more comfortable and immersive visual field.
- **75Hz Refresh Rate & FreeSync:** Experience smoother visuals with a 75Hz refresh rate. FreeSync technology synchronizes the monitor's refresh rate with your graphics card's frame rate, eliminating screen tearing and stuttering for fluid motion.
- **Blue Light Reduction:** Activate the blue light reduction mode to minimize harmful blue light emissions, reducing eye fatigue during prolonged use. This feature is ideal for reading and extended work sessions.



Illustration of the blue light reduction feature, showing its effect on screen output.



Visual comparison demonstrating the smoother image quality achieved with a 75Hz refresh rate compared to 45Hz.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your monitor.

4.1 Cleaning the Screen

- Always turn off the monitor and unplug the power cord before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a specialized screen cleaner.
- Gently wipe the screen surface. Do not apply excessive pressure.
- Avoid using abrasive cleaners, alcohol, or ammonia-based solutions, as these can damage the screen.

4.2 Cleaning the Casing

- Use a soft, dry cloth to wipe the monitor casing.
- For stubborn dirt, use a cloth lightly dampened with mild detergent solution, then wipe dry.

4.3 General Care

- Avoid placing the monitor in direct sunlight or near heat sources.
- Ensure adequate ventilation around the monitor.
- Do not block the ventilation openings.
- Avoid spilling liquids onto the monitor.

5. Troubleshooting

If you encounter issues with your monitor, refer to the following common troubleshooting steps:

Problem	Possible Solution
No image on screen	Ensure the power cable is securely connected and the monitor is turned on. Check that video cables (HDMI/DP) are properly connected to both the monitor and the computer. Select the correct input source via the OSD menu.
Image is blurry or distorted	Ensure the display resolution is set to the native 3440x1440. Check the video cable for damage or loose connections. Adjust OSD settings like sharpness.
Screen flickering	Verify the refresh rate is set to 75Hz. Ensure FreeSync is enabled in both the monitor OSD and your graphics card settings. Check for external interference.
No sound from speakers	Check the monitor's volume setting in the OSD menu. Ensure your computer's audio output is directed to the monitor. If using external speakers, check their connections and power.
Monitor does not power on	Confirm the power adapter is correctly plugged into both the monitor and a working power outlet. Try a different power outlet.

If the problem persists after trying these solutions, please contact Suevery customer support.

6. Specifications

Detailed technical specifications for the Suevery 34-inch Ultrawide Curved Monitor SV340QD:

Feature	Specification
Brand	Suevery
Model Number	SV340QD
Screen Size	34 inches
Resolution	3440 x 1440 (UWQHD)
Aspect Ratio	21:9

Feature	Specification
Panel Type	IPS
Screen Surface	Non-glare
Curvature	1900R
Refresh Rate	75 Hz
Response Time	1 ms
Contrast Ratio	1000:1
Color Gamut	85% NTSC (8-bit color)
Display Type	LED
Adaptive Sync	FreeSync
Connectivity	2 x HDMI, 2 x DisplayPort, 1 x Audio Out
VESA Mount	100 x 100 mm
Tilt Adjustment	Forward 5 degrees, Backward 14 degrees
Built-in Speakers	Yes
Product Dimensions (D x W x H)	86.6 x 42 x 15.6 cm (with stand)
Product Weight	6.6 kg
Color	Black
Origin	China



21:9ウルトラワイドで、表示領域がさらに広がる

従来の16:9画面よりも一度に表示できる情報量が増え、複数ウィンドウでの作業や映像視聴もより快適。広く見やすい画面で、作業効率と没入感を同時に高めます。

Visual comparison illustrating the expanded display area of UWQHD 21:9 compared to standard FHD 16:9.

7. Warranty and Support

7.1 Manufacturer's Warranty

This Suevery monitor comes with a **3-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Suevery customer support. You can typically find contact information on the official Suevery website or through the retailer where you purchased the product. Please have your monitor model number (SV340QD) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question