

Basike Ba-FON303A

Basike Ba-FON303A OWS Bluetooth Earphones User Manual

Model: Ba-FON303A | Brand: Basike

1. INTRODUCTION

Thank you for choosing the Basike Ba-FON303A OWS Bluetooth Earphones. This manual provides detailed instructions for the proper setup, operation, maintenance, and troubleshooting of your new earphones. Please read this guide thoroughly before using the product to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Easy and Intuitive Music and Call Control:** Manage playback and calls directly from the earphones.
- **Long-lasting Battery:** Up to 8 hours of music or talk time, with 100 hours of standby.
- **Stable Bluetooth 6.1 Connection:** Ensures a reliable connection up to 10 meters.
- **Built-in Microphone and Voice Assistant:** Clear hands-free calls and voice command activation.
- **Automatic Pairing and Simple Reset:** Quick setup and easy troubleshooting.
- **Ergonomic and Comfortable Design:** Flexible stems and a secure 3-point fit, ideal for sports.
- **Sweat and Dust Resistant:** Durable for physical activities.
- **Immersive Audio:** High-fidelity sound with deep bass and crystal-clear treble.
- **Enhanced Clarity:** Professional sound with clear calls and minimal sound leakage.



Áudio Imersivo

Qualidade sonora de alta fidelidade,
com graves mais profundos e agudos
cristalinos para uma experiência superior



Figure 1: Earphone internal structure for immersive audio experience.



Ergonômico e Confortável

Encaixe perfeito na orelha com hastes flexíveis e confortáveis



Aberto



intra-auricular



Figure 2: Ergonomic open-ear design for comfort.



Resistente ao Suor e à Poeira

Perfeito para o uso durante as atividades físicas



Segurança em 3 pontos



Hastes Flexíveis

Figure 3: Earphones designed for active lifestyles, featuring sweat resistance and secure fit.



Mais Nitidez, Menos Vazamento

Som profissional com muito mais clareza em ligações
e menos vazamentos para o ambiente

Figure 4: Enhanced sound clarity and reduced sound leakage.

2.2 Package Contents

The Basike Ba-FON303A package includes:

- Basike Ba-FON303A OWS Bluetooth Earphones
- Charging Case
- USB Charging Cable

- User Manual (this document)

3. SETUP

3.1 Initial Charging

Before first use, ensure the earphones and charging case are fully charged.

- Place the earphones into the charging case.
- Connect the charging case to a power source using the provided USB cable.
- **Important:** Use a PC or notebook USB 3.0 port or a 1.0A charging adapter. Avoid using high-power cell phone chargers, as they can damage the battery and reduce product lifespan.
- Charging time for earphones is approximately 1 hour. The charging case battery is 420 mAh.



Figure 5: Charging case and earphones with battery life indicators.

3.2 Power On/Off

- **Automatic Power On:** The earphones will automatically power on when removed from the charging case.
- **Automatic Power Off:** The earphones will automatically power off and begin charging when placed back into the charging case.

3.3 Bluetooth Pairing

The earphones pair with each other automatically. To pair with your device:

1. Remove both earphones from the charging case. They will automatically enter pairing mode.
2. On your mobile phone or tablet, go to **Settings > Bluetooth**.
3. Activate Bluetooth.
4. Select "**Ba-FON303A**" from the list of available devices.
5. Once connected, you will hear a confirmation sound, and the earphones will be ready for use.



basike

iOS  

6.1 Bluetooth

basike

basike

Bluetooth 6.1: Estabilidade e Conexão

Conexão muito mais rápido e máxima estabilidade,
som sem atrasos e mais tecnológico

Figure 6: Bluetooth 6.1 connectivity and device compatibility.

4. OPERATING INSTRUCTIONS

The Ba-FON303A earphones feature intuitive touch controls.



Figure 7: Detailed touch control functions.

4.1 Music Control

- **Play/Pause:** Single tap on either earphone.
- **Next Track:** Touch and hold the right earphone.
- **Previous Track:** Touch and hold the left earphone.
- **Volume Up:** Double tap the left earphone.
- **Volume Down:** Double tap the right earphone.

4.2 Call Management

- **Answer/End Call:** Single tap on either earphone.
- **Reject Call:** Press and hold for 2 seconds on either earphone.

4.3 Voice Assistant

- **Activate Voice Assistant:** Triple tap on either earphone (when no music is playing).
- **Deactivate Voice Assistant:** Triple tap again.

5. MAINTENANCE

5.1 Cleaning

Regularly clean your earphones and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals.

5.2 Storage

When not in use, store the earphones in their charging case to protect them from dust and damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.

5.3 Battery Care

To prolong battery life, always use appropriate charging methods as described in section 3.1. Avoid fully discharging the battery frequently.

6. TROUBLESHOOTING

6.1 Reset Procedure

If you experience pairing issues or other malfunctions, performing a reset may resolve the problem:

1. Ensure the earphones are disconnected from any device.
2. Remove the earphones from the charging case.
3. Quickly double-tap either earphone, then press and hold for 2 seconds until they power off.
4. Place the earphones back into the charging case.
5. Remove them again and attempt to re-pair with your device (refer to section 3.3).

6.2 Common Issues and Solutions

- **Earphones not pairing with device:**
 - Ensure Bluetooth is enabled on your device.
 - Make sure the earphones are charged.
 - Perform a reset (see 6.1).
 - Check if the earphones are already connected to another device.

- **Only one earphone working:**

- Place both earphones back in the case, then remove them together to ensure they pair with each other.
- Perform a reset (see 6.1).

- **Low volume or poor sound quality:**

- Adjust the volume on both your device and the earphones.
- Ensure the earphones are clean and free of debris.
- Check the audio source quality.

- **Earphones not charging:**

- Ensure the charging cable is securely connected.
- Verify the power source is working.
- Use a compatible charger (PC USB 3.0 or 1.0A adapter).
- Clean the charging contacts on both the earphones and the case.

7. SPECIFICATIONS

Model Name	Ba-FON303A
Brand	Basike
Bluetooth Version	6.1
Music Playback Time	Up to 8 hours
Talk Time	Up to 8 hours
Standby Time	Up to 100 hours
Communication Range	≥ 10 meters
Earphone Charging Time	Approx. 1 hour
Earphone Battery Capacity	60 mAh
Charging Case Battery Capacity	420 mAh
Frequency Response	2.400 GHz ~ 2.480 GHz (20 KHz)
Supported Profiles	A2DP 1.3 / HFP 1.6 / HSP 1.2 / AVRCP 1.6 / D11.3
Material	ABS/SBC
Weight	115 Grams
Connectivity Technology	Wireless (Bluetooth)
Control Type	Touch, Button Control
External Test Certification	ANATEL: 04880-23-14103
Included Components	Basike FON303A Bluetooth Earphone

8. WARRANTY INFORMATION

Basike is not responsible for damages caused by improper use of the product or use with an incompatible electrical device. Please refer to your purchase documentation for specific warranty terms and conditions.

9. SUPPORT

For further assistance, please visit the official Basike store or contact customer support through your retailer.

[Visit the Basike Store on Amazon](#)

© 2026 Basike. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question