Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Donner EC7702

Donner HUSH X LIVE Headless Guitar User Manual

Model: EC7702

Introduction

The Donner HUSH X LIVE is a portable headless electric guitar designed for versatile playing and practice. It features a quick-detach modular speaker, integrated amplifier modeling, and various effects, making it suitable for practice anywhere without an external amplifier. This manual provides essential information for setting up, operating, and maintaining your instrument.

1. Setup

1.1 Unpacking and Initial Inspection

Carefully remove the guitar and all accessories from the packaging. Inspect the instrument for any signs of damage. The package includes the Donner HUSH X LIVE guitar and a gig bag.

1.2 Attaching the Modular Speaker

The HUSH X LIVE features a quick-detach modular speaker for instant playability. To attach the speaker, align it with the designated slot on the guitar body and slide it into place until it clicks securely. To detach, press the release button and slide the speaker off.



Figure 1: Attaching and detaching the modular speaker. The speaker can be quickly attached or detached for playing or travel.

1.3 String Installation and Tuning

The guitar uses a headless design. Ensure strings are properly seated and tuned using a standard guitar tuner. The neck-through body design provides tuning stability.

2. Operating

2.1 Powering On and Basic Controls

Locate the power button on the guitar. Press and hold to turn on the integrated electronics. Adjust the master volume knob to control the overall output level.

2.2 Amplifier Models and Effects

The HUSH X LIVE features 5 classic amplifier simulations and built-in effects including Delay, Reverb, Modulation, and Noise Gate. Use the dedicated knobs to select and adjust these settings.

Figure 2: Overview of amplifier models and effects controls. Adjust knobs for various tones and effects.




Figure 3: Detailed view of amplifier monitoring and effects controls, including Delay, Reverb, Modulation, and Noise Gate.

2.3 Bluetooth Connectivity for Practice

Connect your smartphone or tablet via Bluetooth to play along with backing tracks. Activate Bluetooth on your device and pair with the HUSH X LIVE. This allows for immersive practice sessions.




Figure 4: The integrated 5W speaker provides clear sound for home practice.

2.4 Silent Practice with Headphones

For silent practice, connect headphones to the 3.5mm jack. The guitar features a low-noise circuit for a clear headphone experience, allowing you to practice without disturbing others.



Figure 5: Connect headphones to the 3.5mm jack for silent practice. Headphones shown are for illustration only and not included.

3. Features and Design

3.1 HUSH X '23 Alnico V Pickups

The guitar is equipped with original HUSH X '23 Alnico V pickups, combining the brightness of single-coil pickups with the robustness of humbuckers. This provides versatile tones for clean rhythms, modern distortions, and intense lead solos.



Figure 6: The stable travel combination of the HUSH X LIVE, featuring the headless tuning system, HUSH X '23 Alnico V pickups, and a detachable stable support.

3.2 Neck-Through Body Design

Constructed with a 7-piece African mahogany neck-through body, the guitar ensures warm tone, high durability, and tuning stability. The standard "C" shaped neck profile offers smooth and comfortable playability.




Figure 7: The neck-through body construction enhances resonance and stability, while the satin finish provides a fluid playing experience.



Figure 8: Key design elements including rounded fret edges, matte body finish, and the balanced "C" shaped neck profile for comfortable playability.

4. Maintenance

4.1 Cleaning

Regularly wipe down the guitar with a soft, dry cloth to remove dust and fingerprints. For stubborn grime, use a guitar-

specific cleaning solution applied to the cloth, not directly to the instrument. Avoid abrasive cleaners.

4.2 String Replacement

Replace strings periodically to maintain optimal tone and playability. Refer to standard headless guitar string replacement procedures. Ensure you use nickel-plated steel strings as specified.

4.3 Storage

When not in use, store the guitar in its gig bag to protect it from dust, humidity fluctuations, and physical damage. Avoid exposing the guitar to extreme temperatures or direct sunlight.

5. Troubleshooting

5.1 No Sound Output

- Ensure the guitar is powered on and fully charged.
- Check the master volume knob and ensure it is not set to zero.
- If using the modular speaker, ensure it is securely attached.
- If using headphones, ensure they are fully plugged into the jack.

5.2 Bluetooth Connection Issues

- Ensure Bluetooth is enabled on your external device (phone/tablet).
- Make sure the guitar is in pairing mode (if applicable, refer to specific Bluetooth indicator).
- Try unpairing and re-pairing the device.
- Ensure no other devices are currently connected to the guitar via Bluetooth.

5.3 Unwanted Noise/Feedback

- Adjust the Noise Gate effect to reduce unwanted hum or feedback, especially with high gain settings.
- Ensure proper grounding if connected to external amplification.
- Check for loose connections or damaged cables.

6. Specifications

Feature	Specification
Model	HUSH X LIVE (EC7702)
Body Material	Mahogany
Neck Material	Canadian Maple and Maple (7-piece African mahogany neck-through)
Fretboard Material	HPL / Torrefied Steel
Pickup Configuration	H-S (Humbucker-Single Coil)
Pickups	DONNER HUSH X '23 Original Alnico V
Number of Strings	6

Feature	Specification
String Material	Nickel-plated Steel
Hand Orientation	Right
Integrated Effects	Delay, Reverb, Modulation, Noise Gate
Amplifier Models	5 (Clean, Blues, Rock, High Gain, etc.)
Bluetooth	Yes, for backing tracks
Dimensions (Package)	96 x 19.3 x 16.4 cm
Weight (Package)	5.14 kg
Included Components	Gig Bag

7. Warranty and Support

7.1 Product Warranty

This Donner HUSH X LIVE guitar comes with a 1-year warranty from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized modifications.

7.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Donner customer support through their official website or the retailer where the product was purchased. You can visit the Donner store on Amazon for more information: Donner Official Store.

© 2026 Donner. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GX5DY2XF

More documents and user manuals: **https://manuals.plus/**