

Aoxun 1

Aoxun 10-Piece Patio Furniture Set with Fire Pit Table User Manual

Model: 1 | Brand: Aoxun

INTRODUCTION

Thank you for choosing the Aoxun 10-Piece Patio Furniture Set with 44-inch Fire Pit Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor furniture set. Please read all instructions carefully before use and retain this manual for future reference.

SAFETY INFORMATION

Important Safety Warnings:

- Always keep the fire pit table away from flammable materials.
- Never leave the fire pit unattended while in use.
- Keep small parts out of reach of children during assembly.
- Do not exceed the weight limit of 80 pounds for the furniture set to prevent damage or tip-over.
- Ensure all connections are secure before using the furniture.
- Use the fire pit only in well-ventilated outdoor areas.

COMPONENTS LIST

The Aoxun 10-Piece Patio Furniture Set includes the following items:

- 1 x 3-seater Wicker Sofa
- 4 x 360° Swivel Glide Chairs
- 1 x 44-inch Fire Pit Table
- 2 x Water Patterned Tempered Glass Side Tables
- 2 x 3-in-1 Ottomans
- Cushions for all seating pieces
- Assembly hardware (screws, wrenches)



Image: Overview of the Aoxun 10-Piece Patio Furniture Set, showing the sofa, swivel chairs, fire pit table, side tables, and ottomans.

SETUP INSTRUCTIONS

Assembly of the Aoxun Patio Furniture Set is required. Please follow the detailed step-by-step instructions provided in the included assembly manual. Ensure all parts are present before beginning assembly. It is recommended to assemble the furniture on a soft, clean surface to prevent scratches.

For detailed assembly instructions, please refer to the official PDF manual: [Download Assembly Instructions \(PDF\)](#)

Product Dimensions

Product Dimension



Image: Diagram showing the dimensions of the sofa, swivel chairs, ottomans, side tables, and fire pit table.

Refer to the dimension diagram to plan your outdoor space and ensure proper placement of each furniture piece.

OPERATING INSTRUCTIONS

Fire Pit Table Operation

The 44-inch fire pit table features a pulse ignition system for easy lighting. Ensure the gas tank (not included) is properly connected and the gas valve is open. Follow the instructions on the fire pit control panel for ignition. Always keep the fire pit lid in place when not in use to protect the fire glass and burner.




Image: Close-up view of the fire pit table, highlighting the fire glass, pulse ignition mechanism, and the removable fire pit lid.

360° Swivel Glide Chairs

The four swivel glide chairs are designed for smooth 360-degree rotation and gentle rocking motion. Ensure the chairs are placed on a flat, stable surface for optimal performance and safety.

Imported Bearings for Smoother Rotation



Image: A person enjoying the smooth 360-degree swivel and gentle rocking motion of one of the patio chairs.

3-in-1 Ottomans

The two ottomans included in the set offer versatile functionality. They can be used as additional seating, comfortable footrests, or, when paired with a tray, as small coffee tables.

3-in-1 Ottoman



Image: Illustration of the 3-in-1 ottoman's versatility, showing its use as single seating, an ottoman, and a small coffee table.

MAINTENANCE

Cushion Care

The cushions are made from all-weather soft fabric that is waterproof and designed for daily outdoor use. The covers are detachable and washable for easy cleaning. For best results, hand wash or machine wash on a gentle cycle with cold water and mild detergent. Air dry only. Do not bleach or iron.

All-Weather Soft Fabric

Daily Use 5-Year-None-Fading



Waterproof

**Detachable
and washable**

24D Sponge

High Resilience

Image: Close-up of the cushion fabric, highlighting its waterproof properties, detachable zipper for washing, 24D sponge core, and high resilience.

Wicker and Frame Care

The premium rattan wicker is UV-resistant, tear-resistant, and anti-fading, designed to withstand various weather conditions. The heavy-duty steel frame provides durability. To clean, wipe down the wicker and frame with a soft cloth and mild soap and water. Rinse thoroughly and dry completely. Avoid using harsh chemicals or abrasive cleaners. For prolonged life, consider covering the furniture during extreme weather or extended periods of non-use.

Pure Natural Handmade Wicker



Anti
fading



Tear-
resistant



UV
protection



Thickness increased
by 40%



Extend lifespan
by 200%

Image: Detailed view of the hand-woven wicker material, emphasizing its anti-fading, tear-resistant, and UV-protective qualities.

Fire Pit Table Maintenance

Regularly inspect the fire pit burner and gas connections for any signs of wear or damage. Clean the fire glass and burner area as needed. Always ensure the fire pit is completely cool before cleaning or covering. Store the fire pit table with its lid on and consider a weather-resistant cover when not in use.

TROUBLESHOOTING

- **Fire Pit Not Igniting:** Check the gas tank connection and ensure the valve is fully open. Verify that the pulse igniter battery (if applicable) is functional. Clean any debris from the burner ports.
- **Unstable Furniture:** Ensure all bolts and screws are tightened securely during assembly. If the ground is uneven, use shims under the furniture legs to stabilize.
- **Wicker Damage:** For minor fraying, carefully trim loose strands. For significant damage, contact customer support for repair advice.

- **Cushion Flatness:** Over time, cushions may compress. Fluff them regularly to maintain shape and comfort.

SPECIFICATIONS

Feature	Detail
Brand	Aoxun
Model Number	1
Color	Black/Beige
Size	10 Piece 9 Seats
Item Weight	80 Pounds
Material Type	Rattan
Required Assembly	Yes
Included Components	Screws, Wrenches, Products

WARRANTY INFORMATION

Aoxun products are manufactured to high-quality standards. For specific warranty details regarding your 10-Piece Patio Furniture Set, please refer to the warranty card included with your purchase or contact Aoxun customer support directly. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or encounter any issues with your Aoxun 10-Piece Patio Furniture Set, please contact Aoxun customer support. You can typically find contact information on the product packaging, the Aoxun brand website, or through the retailer where you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GX68YCBW>

More documents and user manuals: <https://manuals.plus/>