

[Manuals.plus](#) /

› [boAt](#) /

› boAt Storm Call 4 Smartwatch User Manual

boAt Storm Call 4

boAt Storm Call 4 Smartwatch User Manual

Model: WA0077

INTRODUCTION

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your boAt Storm Call 4 Smartwatch. Please read this manual thoroughly before using your device to ensure proper function and longevity.

PACKAGE CONTENTS

- boAt Storm Call 4 Smartwatch
- Type-C Charging Cable
- User Manual (this document)

SETUP

1. Charging the Smartwatch

Before initial use, fully charge your smartwatch. The boAt Storm Call 4 features Type-C charging.

1. Connect the Type-C charging cable to the charging port on your smartwatch.
2. Connect the other end of the cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The watch display will indicate charging status. A full charge may take approximately 2 hours.

boAt

STORM CALL 4

India's First Smartwatch
with Type-C Charging



Image: The boAt Storm Call 4 Smartwatch connected to a Type-C charging cable, displaying 75% battery.

2. Pairing with Your Smartphone

To access all features, pair your smartwatch with the companion application on your smartphone.

1. Download and install the "boAt Crest" application from your smartphone's app store.
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the boAt Crest app and follow the on-screen instructions to add your device.
4. Select "Storm Call 4" from the list of available devices.
5. Confirm the pairing request on both your smartphone and smartwatch.

OPERATING INSTRUCTIONS

Display and Navigation

The smartwatch features a 1.96-inch HD display with 240x282 resolution and 500 nits peak brightness for clear visibility. Navigation is primarily done via the touchscreen and the functional crown.

- **Touchscreen:** Swipe left, right, up, or down to navigate through menus and notifications. Tap to select items.
- **Functional Crown:** Rotate the crown to scroll through lists, adjust settings, or change watch faces. Press the crown to return to the home screen or confirm selections.
- **Buttons:** Use the side buttons for specific functions such as power on/off, screen wake, or quick access to features.

Type-C Charging

India's First Type-C Powered Smartwatch



Image: The smartwatch display and functional crown.

Bluetooth Calling

The smartwatch supports Bluetooth calling, allowing you to manage calls directly from your wrist.

- Ensure your watch is connected to your smartphone via Bluetooth.
- Use the responsive dial pad on the watch to make calls.
- Answer incoming calls directly on the watch using the built-in speaker and microphone.
- Save frequently dialed contacts in the companion app for quick access.

Health Monitoring

The Storm Call 4 continuously tracks various health metrics.

- **Heart Rate Monitoring:** Real-time heart rate measurements (BPM, minimum, peak workout zones).
- **SpO2 Monitoring:** Real-time blood oxygen saturation tracking.
- **Sleep Tracking:** Monitors sleep cycles including Deep Sleep, Light Sleep, REM Sleep, and Awake time.
- **Stress Monitoring & Guided Breathing:** Tracks stress levels and offers guided breathing exercises.

Durable Design

For Everyday Wear

IP68 Dust &
Water Resistance

Premium Metal
& Silicone Straps



Image: The smartwatch displaying health and safety features during activity.

Sports Modes

The watch supports over 100 sports modes, including strength training, football, cricket, yoga, and golf. It also features auto-activity detection for running and walking.

- Select your desired sports mode from the watch menu before starting an activity.
- The watch will track calories burned and other relevant metrics for the selected activity.

Emergency SOS

For emergencies, the watch includes an SOS feature.

- Quickly tap the power button three times to dial your pre-saved emergency contact.
- Ensure an emergency contact is set up in the companion app.

Other Utilities

The smartwatch offers various additional functions:

- **Voice Assistant:** Command your voice assistant via the watch.
- **Music and Camera Controls:** Remotely control music playback and camera shutter on your smartphone.
- **Weather Updates:** Check live weather information.
- **Alarms and Timers:** Set daily alarms and timers.
- **Games:** Access built-in games.
- **Quick Replies:** Send quick replies to messages (Android only).
- **Calculator:** Basic calculator function.
- **Notification Alerts:** Receive notifications from your smartphone.
- **Reminders:** Set reminders for tasks or events.
- **Find My Phone:** Locate your paired smartphone.
- **Watch Faces:** Choose from over 100 cloud-based watch faces.
- **Menu Styles:** Select from multiple menu display styles.




Image: Overview of the smartwatch utility features.

MAINTENANCE

Water and Dust Resistance (IP68)

The boAt Storm Call 4 is IP68 rated for dust and water resistance. This means it is protected against dust ingress and can

withstand immersion in water up to 1.5 meters for 30 minutes. It is suitable for everyday use, including sweaty workouts and accidental spills. However, it is not recommended for swimming or diving.

Big Display

For Clear Visibility

1.96"
HD Display

240×282
Resolution

500nits
Brightness



Image: The smartwatch demonstrating durable design and IP68 dust and water resistance.

Cleaning

To maintain your smartwatch, clean it regularly:

- Wipe the screen and body with a soft, damp, lint-free cloth.
- Avoid using harsh chemicals or abrasive materials.
- Ensure the charging port is dry before charging.

Battery Care

The smartwatch features a Lithium Polymer battery with up to 12 days of battery life under normal usage. To optimize battery longevity:

- Avoid extreme temperatures.
- Do not allow the battery to fully discharge frequently.
- Use the provided Type-C cable for charging.
- Utilize power-saving modes when extended battery life is needed.

Long Lasting Battery

That Keeps Up

Up to 12 Days
Battery Life

Power
Saving Mode



Image: The smartwatch highlighting its long-lasting battery and power-saving mode.

TROUBLESHOOTING

Problem	Solution
Watch not turning on	Ensure the watch is fully charged. Press and hold the power button for several seconds.
Unable to pair with smartphone	• Ensure Bluetooth is enabled on your phone. • Make sure the watch is within range of your phone. • Restart both the watch and the phone. • Clear Bluetooth cache on your phone (if applicable).
Inaccurate health data	• Ensure the watch is worn snugly on your wrist, not too tight or too loose. • Clean the sensor on the back of the watch. • Avoid excessive movement during measurements.
Bluetooth calling issues	• Verify the watch is properly connected for calls in your phone's Bluetooth settings. • Check the volume settings on both the watch and phone. • Ensure the watch's microphone is not obstructed.

SPECIFICATIONS

Feature	Detail
Model Name	Storm Call
Model Number	WA0077
Display Size	1.96 Inches (4.97 cm) HD Display
Resolution	240 x 282
Brightness	500 Nits (Peak)
Connectivity	Bluetooth
Charging Type	Type-C
Battery Type	Lithium Polymer
Water Resistance	IP68 (Dust and Water Resistant)
Human Interface Input	Buttons, Dial (Functional Crown), Microphone, Touchscreen
Weight	27 Grams
Supported Application	Voice Assistant (via paired smartphone)

Feature	Detail
Compatible Devices	Smartphone

WARRANTY AND SUPPORT

Your boAt Storm Call 4 Smartwatch comes with a **1-year warranty** from the date of purchase.

For warranty claims, technical support, or further assistance, please contact boAt customer service. Refer to the official boAt website or your purchase documentation for contact details.

Manufacturer: Imagine Marketing Limited, Unit no. 204 & 205, 2nd floor, D-wing & E-wing, Corporate Avenue, Andheri Ghatkopar Link Road, Mumbai, Maharashtra-400093, India.

Country of Origin: India

© 2026 boAt. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GX9F6XY6>

More documents and user manuals: <https://manuals.plus/>