

TGLLM HJ-005

TGLLM Music Boxing Machine Instruction Manual

Model: HJ-005

1. SETUP AND INSTALLATION

The TGLLM Music Boxing Machine is designed for wall-mounted installation. Follow these steps for proper setup.

1.1 Unboxing and Components

Verify that all components are present in the package:

- Music Boxing Machine unit
- Pair of Boxing Gloves
- USB Type-C Charging Cable
- Velcro Stickers (for Method 1 & 2)
- Screws and Wall Fixing Piece (for Method 3)



Image: Overview of the TGLLM Music Boxing Machine components, including the main unit, boxing gloves, charging cable, and mounting accessories.

1.2 Installation Methods

Choose one of the following installation methods based on your wall type and preference.

Method 1: Velcro (Temporary/Adjustable)

- 1. Clean the wall surface thoroughly to ensure it is dry and free of dust.
- 2. Stick two long Velcro strips vertically on the desired wall area.
- 3. Align the corresponding Velcro strips on the back of the boxing machine.
- 4. Press the boxing machine firmly against the wall to secure it.



Image: Step-by-step illustration of attaching the boxing machine to a wall using Velcro strips for easy repositioning.

Method 2: Double-Sided Tape (Semi-Permanent)

- 1. Clean the wall surface thoroughly.
- 2. Tear off the protective film from the double-sided tape on the back of the machine.
- 3. Stick the machine firmly onto the wall.



Image: Instructions for mounting the boxing machine using double-sided adhesive tape.

Method 3: Screws (Permanent)

This method is recommended for maximum stability, especially on sturdy walls like marble, wood board, or ceramic tile.

- 1. Position the wall fixing piece on the desired location on the wall.
- 2. Mark the drilling points through the holes in the fixing piece.
- 3. Drill pilot holes if necessary, then secure the fixing piece to the wall using the provided screws.
- 4. Align the boxing machine with the fixed piece and attach it securely.

SUITABLE FOR ALL PEOPLE




Image: Guide for permanent installation of the boxing machine using screws and a wall bracket, suitable for various wall types.

2. OPERATING INSTRUCTIONS

The TGLLM Music Boxing Machine features multiple modes, speeds, and Bluetooth connectivity for an interactive training experience.

2.1 Power On/Off and Charging

- **Power On:** Long press the "On/Off" button (center button) to power on the device.
- **Power Off:** Long press the "On/Off" button again to power off the device.
- **Charging:** Connect the provided USB Type-C cable to the charging port. The machine cannot be operated while charging. Unplug the cable before use. A full charge takes approximately 2 hours and provides up to 4 hours of working time.



Image: The boxing machine highlighting its Type-C charging port and indicating 2 hours for fast charging and 4 hours of working time.

2.2 Bluetooth Connectivity

1. After powering on, the Bluetooth function is automatically activated.
2. On your mobile device, search for Bluetooth devices.
3. Connect to the device named "Bluetooth".

4. Once connected, you can play your favorite music through the machine's speakers.



Image: Visual guide for connecting a mobile device to the boxing machine via Bluetooth to play music.

2.3 Modes and Speeds

The machine offers 9 modes and 9 speeds to customize your training.

- **Speed Adjustment:** Press the "Speed" button (left button) to cycle through 9 speed levels (H01-H09). A higher number indicates faster light flashing. The default display is H01.
- **Mode Selection:** Press the "Mode" button (right button) to select from 9 light flashing modes (P01-P09). Each mode corresponds to a different division of the training area.
- **Volume Control:** Long press the "Speed" button to decrease the volume. Long press the "Mode" button to increase the volume.



Image: Close-up of the control panel showing the On/Off, Speed, and Mode buttons, along with their functions for adjusting settings.

2.4 Training Operation

When the boxing target lights up, hit it with your fist. The LED display will show the number of hits, recording your progress.

Smart Music Boxing Machine

Multiple modes and adjustable speed, suitable for both beginners and seasoned experts



9 Speeds

Adjustable speed, displaying H01-H09, higher number means light flashing faster accordingly, default display is H01

9 Modes

Adjustable mode, displaying P01-P09, 9 light flashing modes, each corresponding to the division of the training area.

Image: An individual demonstrating the use of the music boxing machine, striking an illuminated target while wearing boxing gloves.

3. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your TGLLM Music Boxing Machine.

3.1 Cleaning

- Wipe the surface of the boxing machine with a soft, damp cloth.
- Avoid using abrasive cleaners or solvents, as these can damage the material.
- Ensure the device is powered off and unplugged before cleaning.

3.2 Storage

- Store the machine in a cool, dry place away from direct sunlight and extreme temperatures.
- If using Velcro mounting, ensure the Velcro strips are clean to maintain adhesion.

4. TROUBLESHOOTING

Refer to the following common issues and solutions before contacting support.

Problem	Possible Cause	Solution
Machine does not power on.	Low battery or no charge.	Charge the device using the provided USB Type-C cable. Ensure the cable is properly connected.
Bluetooth not connecting.	Bluetooth is off on the device or phone; device is out of range; interference.	Ensure the machine is powered on and Bluetooth is enabled on your phone. Move closer to the machine. Restart both devices.
Targets not registering hits.	Insufficient force; sensor malfunction.	Ensure you are hitting the targets with adequate force. If the issue persists, contact customer support.
Machine falls off the wall.	Improper installation; unsuitable wall surface; worn out adhesive.	Re-install using a more secure method (e.g., screws). Ensure the wall surface is clean and appropriate for the chosen installation method.

5. SPECIFICATIONS

Detailed technical specifications for the TGLLM Music Boxing Machine, Model HJ-005.

Model Number: HJ-005

Brand: TGLLM

Sport Type: Boxing

Size: Large

Item Weight: 2.65 Kilograms

Number of Items: 1

Number of Packs: 1

Unit Count: 1.0 Count

Modes: 9

Speeds: 9

Connectivity: Bluetooth

Charging: USB Type-C

Battery Life: Up to 4 hours working time (2 hours charging)

Material: High-elastic foam impact surface

6. WARRANTY AND SUPPORT

6.1 Warranty Information

Please refer to the product packaging or the retailer's website for specific warranty terms and conditions. Typically, products are covered against manufacturing defects for a limited period from the date of purchase.

6.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact TGLLM customer

support through the retailer's platform or the official TGLLM website. Have your model number (HJ-005) and purchase details ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question