



[Manuals.plus](#) /

> [BUBLUE](#) /

> BUBLUE Bubot 700 Cordless Robotic Pool Cleaner Instruction Manual

## BUBLUE Bubot 700

# BUBLUE Bubot 700 Cordless Robotic Pool Cleaner Instruction Manual

Model: Bubot 700

## 1. INTRODUCTION

---


Thank you for choosing the BUBLUE Bubot 700 Cordless Robotic Pool Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read this manual thoroughly before first use and retain it for future reference.

## 2. PACKAGE CONTENTS

---

Verify that all items are present in the package:

- 1 x Bubot 700 Robotic Pool Cleaner
- 1 x Charger
- 1 x Hook
- 1 x User Manual (this document)
- 1 x Quick Start Guide



## Effortless Retrieval with Swift Drainage

Self-parking near the wall when battery is low, ensuring easy retrieval

Image: The Bubot 700 robotic pool cleaner and its included accessories: charger, hook, user manual, and quick start guide.

### 3. PRODUCT FEATURES

---

The Bubot 700 is designed for comprehensive pool cleaning with advanced features:

- **High-Performance Suction:** Equipped with Bluehole Technology and a triple-motor system for effective removal of sand, leaves, and debris.
- **4-in-1 Cleaning Coverage:** Offers Floor, Wall, and Auto modes, including waterline scrubbing and cross-platform navigation.
- **Smart Navigation:** Utilizes Bluesonic Path Technology for real-time pool mapping and optimized cleaning paths (S-Shape, N-Shape).
- **Intelligent App Control:** Connects via Bluetooth or Wi-Fi for mode selection, runtime adjustment, and path customization. Supports OTA updates.
- **Auto-Parking:** Automatically moves to the pool edge when battery is low for easy retrieval.
- **Extended Running Time:** Features a new Eco Power Mode for up to 210 minutes of operation (in floor mode).
- **Durable Design:** Constructed with UV-resistant housing and robust components for long-term performance in various pool types and materials.



Image: The Bubot 700's powerful suction system, highlighting its 2X scrubbing, 3-motor system, and 3434 GPH suction power.



- Future Resonance -

BUBLUE stands at the forefront of high-end intelligent robotics, where cutting-edge technology meets refined aesthetics.

With a passion for innovation and craftsmanship, we create thoughtfully designed products that elevate everyday living and inspire a smarter, more beautiful future.



Image: Illustration of the Bubot 700's versatile 4-in-1 cleaning capabilities, including Auto, Floor, Wall, and Cross-Platform modes for comprehensive pool coverage.

## Awards & Recognitions



Image: The Bubot 700 utilizing Bluesonic Path Technology for intelligent navigation, displaying S-Shape and N-Shape cleaning patterns.



Image: A smartphone displaying the BUBLUE app interface for controlling the Bubot 700, allowing users to select cleaning modes, adjust settings, and customize cleaning plans.

## 4. SETUP

---

### 4.1 Charging the Cleaner

Before initial use, fully charge the Bubot 700. Connect the charger to a power outlet and then to the charging port on the cleaner. The LED indicator will show charging status.

# Auto-Parks Near Wall on Low Battery

Parks near the wall for easy retrieval



Image: The Bubot 700 robotic pool cleaner connected to its charger, indicating the charging process.

## 4.2 Connecting to the BUBLUE App

For advanced control and customization, download the BUBLUE app from your device's app store. Pair the cleaner with your smartphone via Bluetooth or Wi-Fi (2.4G Wi-Fi only) before placing it in the water.

## 4.3 Placing the Cleaner in the Pool

Carefully lower the Bubot 700 into the pool. Ensure it sinks completely to the bottom before starting a cleaning cycle. The cleaner is designed for both inground and above-ground pools.

Your browser does not support the video tag.

Video: A demonstration of placing the Bubot 700 pool vacuum into an inground pool, showing it sinking and beginning operation.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Selecting Cleaning Modes

The Bubot 700 offers multiple cleaning modes:

- **Auto Mode:** Provides comprehensive cleaning of the pool floor, walls, and waterline.
- **Floor Mode:** Focuses cleaning solely on the pool floor.
- **Wall Mode:** Concentrates on cleaning pool walls and the waterline.

You can select these modes using the control knob on the cleaner or through the BUBLUE app.



Image: The control knob on the Bubot 700, illustrating the selection options for Wall Mode, Floor Mode, and Auto Mode, alongside a 5-color LED indicator for operational status.

## 5.2 Understanding LED Indicators

The 5-color LED indicator provides status information:

- **Blue:** Normal Operation (40%-100% battery)
- **Orange:** Normal Operation (20%-40% battery)
- **Yellow:** Low Power (<20% battery)
- **Green:** Charging
- **Red:** Fault

## 5.3 Auto-Parking Feature

When the battery level is low, the Bubot 700 will automatically navigate to the nearest pool wall and park itself for easy retrieval. This feature ensures you can easily access the cleaner without having to reach into the deep end.



Image: The Bubot 700 robotic pool cleaner automatically parking itself near the pool wall when its battery is low, indicated by a battery icon and an arrow.

Your browser does not support the video tag.

Video: The Bubot 700 demonstrating its wall-climbing capability and waterline cleaning, showcasing its powerful suction and movement.

## 6. MAINTENANCE

### 6.1 Cleaning the Filter Basket

Regularly clean the filter basket to maintain optimal cleaning performance. Simply remove the filter basket from the cleaner and rinse it thoroughly with clean water to remove trapped debris.



Image: A hand rinsing the filter basket of the Bubot 700 with a garden hose, demonstrating the easy maintenance process to clear debris.

### 6.2 General Care

- After each use, remove the cleaner from the pool and allow it to drain completely.
- Store the cleaner in a cool, dry place away from direct sunlight and extreme temperatures.
- Periodically inspect the tracks and brushes for wear and tear. Replace if necessary.

## 7. TROUBLESHOOTING

If you encounter issues with your Bubot 700, refer to the following common solutions:

- **Cleaner not moving or stuck:** Ensure the pool bottom is free of large obstacles. Check if the filter basket is overloaded.
- **Poor cleaning performance:** Clean the filter basket. Ensure the battery is fully charged.
- **Cleaner not charging:** Verify the charger is properly connected to both the outlet and the cleaner. Check for any damage to the charger or charging port.
- **App connectivity issues:** Ensure Bluetooth or Wi-Fi is enabled on your device and the cleaner is within range. Restart both the app and the cleaner.

For persistent issues, consult the BUBLUE app for further diagnostics or contact customer support.

## 8. SPECIFICATIONS

---

Feature	Detail
Brand	BUBLUE
Model Name	Bubot 700
Material	Plastic
Color	Light Grey
Product Dimensions (L x W x H)	18" x 17.5" x 13"
Power Source	Battery Powered
Voltage	18.25 Volts
Lithium Battery Energy Content	94.9 Watt Hours
Number of Batteries	1 D battery (included)
Battery Description	Lithium-Ion
Charging Time	3.4 Hours
Required Assembly	No

## 9. WARRANTY AND SUPPORT

---

### 9.1 Warranty Information

The BUBLUE Bubot 700 Cordless Robotic Pool Cleaner comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

### 9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Bubot 700, please contact BUBLUE customer support through the official website or the contact information provided in your Quick Start Guide.



