



[Manuals.plus](#) /

› [Waleaf](#) /

› WALEAF 70-inch Fireplace TV Stand Instruction Manual

Waleaf SF-TG70TVS-36PC-WHT

WALEAF 70-inch Fireplace TV Stand Instruction Manual

Model: SF-TG70TVS-36PC-WHT

1. INTRODUCTION

Thank you for choosing the WALEAF 70-inch Fireplace TV Stand. This product combines a modern entertainment center with an integrated electric fireplace, offering both functional storage and ambient heating. This manual provides essential information for safe assembly, operation, and maintenance of your new TV stand.

Important Note: This product is shipped in two separate packages: one for the TV stand components and one for the electric fireplace insert. These packages may arrive on different days. Please ensure you have received both packages before beginning assembly.

70 INCH FIREPLACE TV STAND



Weight
Limitation

150lbs

Come with **2** Packages



1 Fireplace

2 TV Console table




Image 1.1: Overview of the WALEAF 70-inch Fireplace TV Stand and its two-package delivery. The diagram shows the fireplace insert (37 inches wide, 14 inches high) and the TV console table (70 inches wide, 20.9 inches high, 13.78 inches deep).

2. SAFETY INFORMATION

Please read all safety warnings and instructions carefully before assembly and operation to prevent injury or damage to the product.

- **Electrical Safety:** Ensure the electric fireplace is connected to a properly grounded outlet. Do not overload electrical circuits. Keep power cords away from heated surfaces and foot traffic areas.
- **Fireplace Operation:** Do not block the air vents of the electric fireplace. Maintain adequate clearance from combustible materials. The fireplace features overheat protection, which will automatically shut off the unit if it becomes too hot.
- **Weight Limit:** The TV stand has a weight limitation of 150 lbs (68 kg). Do not exceed this weight to prevent structural damage or collapse.
- **Assembly:** Assembly is recommended for two persons due to the size and weight of the components. Follow all assembly steps precisely.

- **Placement:** Place the TV stand on a flat, stable surface. Avoid placing it in areas with high humidity or direct sunlight.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present. Refer to the parts list in your separate assembly guide for detailed identification. The product ships in two main packages:

- **Package 1:** TV Console Table Components (particleboard panels, tempered glass doors, hardware, LED light strips)
- **Package 2:** Electric Fireplace Insert (37-inch unit, remote control)

If any parts are missing or damaged, please contact customer support immediately.

4. ASSEMBLY INSTRUCTIONS

Detailed assembly instructions with diagrams are included in a separate manual within your package. Please follow those instructions carefully. The general steps are outlined below:

1. **Prepare the Area:** Clear a spacious, clean area for assembly. Lay down a blanket or cardboard to protect the floor and furniture components.
2. **Identify Parts:** Unpack all components and hardware. Match them against the parts list provided in the assembly guide.
3. **Assemble the TV Console Frame:** Follow the step-by-step instructions to construct the main frame of the TV stand using the particleboard panels and connecting hardware.
4. **Install Glass Doors:** Attach the tempered glass doors to the side cabinets. These doors feature a push-open mechanism for seamless access.
5. **Integrate Electric Fireplace:** Carefully slide the 37-inch electric fireplace insert into the designated central opening of the TV console.
6. **Install LED Light Strips:** Apply the included LED light strips to the interior of the glass cabinets as per the instructions.
7. **Cable Management:** Utilize the dual cable management ports located at the back of the unit to organize and route power cords and media cables.



Image 4.1: Key features for assembly and use, including dust-tight seal design, dual cable management, particle board top and sides, and push-open seamless doors.



Image 4.2: Illustration of the push-open seamless doors and the dual cable management port for organized wiring.

5. OPERATING INSTRUCTIONS

5.1 Electric Fireplace Operation

The electric fireplace can be operated using the control panel on the unit or the included remote control.

- **Power ON/OFF:** Press the power button to turn the fireplace on or off.
- **Heat Settings:** Select between OFF, 750 Watts, or 1500 Watts heat output. The fireplace provides supplemental heating.
- **Flame Brightness:** Adjust the flame effect brightness through 5 levels (L1-L5) to suit your preference.
- **Flame Colors:** Choose from 12 different flame colors to create various ambient effects.
- **Timer Function:** Set an automatic shut-off timer from 1 hour to 8 hours.

- **Temperature Control:** Adjust the desired temperature setting (e.g., 62°F or 82°F).



12 FLAME COLORS + 5 LEVEL BRIGHTNESS

Button & Remote Control




Image 5.1: Controls for the electric fireplace, illustrating power, heat, flame speed, dimmer, timer, and color options. It also shows the 12 flame colors and 5 brightness levels (L1-L5).

5.2 LED Lighting Operation

The integrated LED light strips in the glass cabinets offer customizable ambiance.

- **Color Selection:** The LED light strips offer 20 different color options. Use the provided remote control or integrated buttons (if applicable) to cycle through colors.
- **Brightness/Modes:** Adjust the brightness or select different lighting modes (e.g., static, fading, flashing) as desired.



Image 5.2: The TV stand illuminated by 20 different LED light colors, controlled by a remote.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your TV stand.

- **Cleaning the TV Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish or tempered glass.
- **Cleaning the Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Use a soft cloth to wipe the exterior. Do not spray liquids directly into the unit.
- **Dusting:** Regularly dust all surfaces, including the interior of the glass cabinets, to prevent dust buildup. The dust-tight seal design helps minimize dust accumulation.
- **Inspecting Connections:** Periodically check all electrical connections and hardware fasteners to ensure they are secure.

7. TROUBLESHOOTING

If you encounter issues with your WALEAF Fireplace TV Stand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, loose plug, power switch off.	Ensure the power cord is securely plugged into a grounded outlet. Check if the main power switch on the unit is ON. Test the outlet with another device.
No heat from fireplace.	Heat setting off, overheat protection activated.	Verify the heat setting is not set to OFF. If the unit recently shut off, it might be due to overheat protection; allow it to cool down before restarting. Ensure vents are not blocked.
LED cabinet lights not working.	Loose connection, power issue, remote battery.	Check the connections of the LED light strips. Ensure the power source for the LEDs is connected. Replace remote control batteries if using a remote.
Remote control not responding.	Dead batteries, obstruction.	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace/LED receiver.

If the problem persists after attempting these solutions, please contact WALEAF customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Waleaf
Model Number	SF-TG70TVS-36PC-WHT
Product Dimensions (D x W x H)	13.78" x 70" x 20.9"
Item Weight	61.3 Pounds
Material	Particleboard (frame), Tempered Glass (doors), Metal (fireplace)
Color	White+glass Door
TV Compatibility	Up to 80 inches
Weight Limitation	150 lbs (68 kg)
Fireplace Heat Output	750W / 1500W
Fireplace Flame Settings	5 Brightness Levels, 12 Color Options
Fireplace Timer	1H - 8H

Feature	Specification
LED Strip Colors	20 Color Options
Power Source	Corded Electric
Special Features	Adjustable Flame, Dimmer, LED Flame, Overheat Protection, Push-Open Doors, Dual Cable Management



Image 8.1: Visual guide for TV size compatibility, indicating the stand fits TVs up to 80 inches.



Image 8.2: Detail of the construction materials, showing the thickened top board and the durable, visible thick glass board.

9. WARRANTY AND SUPPORT

WALEAF is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For any questions, missing parts, assembly assistance, or troubleshooting not covered in this manual, please contact WALEAF customer support. Our 24-hour customer support team is available to assist you.

Contact Information: Refer to the contact details provided with your purchase or on the official WALEAF website.