Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JALL K6

JALL K6 Sunrise Alarm Clock and White Noise Machine User Manual

Model: K6 | Brand: JALL

Introduction

Thank you for choosing the JALL K6 Sunrise Alarm Clock and White Noise Machine. This device combines multiple functions to enhance your sleep and wake-up experience, including a sunrise wake-up light, white noise sound machine, 17 light modes, dimmable night light, Bluetooth speaker, and a rear USB charging port. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.
Key features include:

- Large-Screen Wake Up Light with 0-60 minute sunrise simulation.
- Display with 5 levels, including a fully off (L0) option for light-sensitive sleepers.
- 25 Calming Sleep Sounds and 7 Wake-Up Sounds.
- Adjustable 8-Hour Sleep Timer.
- 17 Light Modes (9 RGB effects + 8 Solid Colors) with 20 brightness levels.
- Bluetooth Speaker with auto time sync.
- Rear USB Charging Port (5V1A).
- Setting Memory for alarms, sounds, and brightness.

Setup

1. **Power Connection:** Connect the provided USB Type-C cable to the INPUT 5V2A port on the back of the device and plug the other end into a suitable power adapter (not included). The device requires AC power for operation.
2. **Initial Time Sync (Bluetooth):** For automatic time setting, connect your mobile device to the alarm clock via Bluetooth. The clock will automatically update its time from your phone.
3. **Manual Time Setting:** If not using Bluetooth, press and hold the "Time Set" button (refer to control diagram) to enter time setting mode. Use the +/- buttons to adjust hours and minutes, then press "Time Set" again to confirm.

4. **Backup Battery:** The device includes a CR2032 backup battery to retain your settings (alarm, sound selection, brightness) during power interruptions. This battery does not power the device for operation.




Image: The JALL K6 alarm clock showing its Bluetooth auto time sync, backup memory feature, and rear USB charging output. A phone is shown charging from the USB port.

Operating Instructions

Controls Overview

Familiarize yourself with the buttons and controls on your JALL K6 device:



Image: A detailed diagram illustrating the various buttons and controls on the JALL K6 alarm clock, including RGB, BT, Sleep Timer, Volume, White Noise, Natural Sounds, Time Set, Alarm Switch, Sunrise, Dimmer, Light +, and On/Off/Alarm Set.

- **ON/OFF/ALARM SET:** Click to turn the device on/off. Hold to set the alarm.
- **DIMMER:** Click to adjust the time display brightness (L0-L4). L0 turns the display completely off.
- **LIGHT +:** Click to adjust light brightness.
- **RGB:** Click to cycle through RGB mood lights (C01-C09). Hold to exit.
- **SOLID LIGHT:** Click to turn on solid light colors (Pink, Green, Blue, Indigo, Purple, Grey, Red, Yellow). Hold to exit.
- **SUNRISE:** Click to set the dawn duration (0-60 minutes). Hold to set the wake-up light brightness.
- **ALARM SWITCH:** Click to hold to Alarm Set. Click to stop the alarm when it goes off. Click to disable/enable the alarm.
- **BT (Bluetooth):** Click to turn Bluetooth on. Hold to exit.
- **SLEEP TIMER:** Click to set the sleep timer (10-480 minutes). Hold to exit.
- **VOLUME:** Scroll to adjust the volume.
- **WHITE NOISE:** Click to turn on and switch between 10 white noise sounds. Hold to exit.

- **NATURAL SOUNDS:** Click to turn on and switch between 15 natural sounds. Hold to exit.
- **TIME SET:** Hold to set the time.
- **SNOOZE (+/-):** Rotate to +/- in TimeSet & AlarmSet & SleepTimer & Sounds. Click to turn the Nightlight on. Hold to Snooze Set. Click to Snooze, Hold to Turn the Alarm off When the Alarm Goes off.

Setting the Alarm and Sunrise Simulation

The JALL K6 offers a customizable sunrise simulation to gently wake you up.

1. **Set Alarm Time:** Press and hold the "ON/OFF/ALARM SET" button. Use the +/- buttons to set your desired wake-up time.
2. **Set Sunrise Duration:** Press the "SUNRISE" button. Use the +/- buttons to select a sunrise duration from 0 to 60 minutes. The light will gradually brighten over this period before your alarm sounds.
3. **Choose Wake-Up Sound:** After setting the alarm time, you can select one of 7 wake-up sounds. Use the dedicated sound buttons or +/- to cycle through options like Classic Ring, Mountain Echo, Ocean Waves, etc. Adjust the volume using the volume scroll wheel.
4. **Snooze Function:** When the alarm sounds, press the "SNOOZE" button to activate a 9-minute snooze.



Image: A visual representation of the JALL K6's sunrise simulation feature, showing the light gradually brightening over 0-60 minutes to simulate a natural dawn.



Image: The JALL K6 alarm clock displaying icons for its 7 distinct wake-up sounds, including Classic Ring, Mountain Echo, Morning Forest, Ocean Waves, Canon Melody, Water Drops, and Piano Tone.




Image: A person reaching to press the snooze button on the JALL K6 alarm clock, illustrating the snooze feature.

Using the White Noise and Sleep Sounds

The JALL K6 offers 25 calming sounds to aid relaxation and sleep.

1. **Activate Sounds:** Press the "WHITE NOISE" or "NATURAL SOUNDS" button to start playing sounds.
2. **Change Sounds:** Continue pressing the respective button to cycle through the available sounds.
3. **Adjust Volume:** Use the volume scroll wheel to set your preferred sound level.
4. **Set Sleep Timer:** Press the "SLEEP TIMER" button. Use the +/- buttons to set a duration from 10 minutes to 8 hours. The sound and light will automatically turn off when the timer ends.



Image: A person sleeping peacefully next to the JALL K6 alarm clock, which displays icons representing 25 soothing sounds like white noise, rain, waves, birdsong, soft music, and campfire, along with a sleep timer.



Image: The JALL K6 alarm clock on a nightstand, detailing its 25 soothing sounds categorized into 10 Noise Sounds, 12 Nature Sounds, and 3 Gentle Melodies, along with an auto shut-off sleep timer.

Light Modes and Display Settings

Customize the ambiance with 17 light modes and adjust the display brightness.

1. **RGB Mood Lights:** Press the "RGB" button to cycle through 9 dynamic RGB effects. Hold to turn off.
2. **Solid Colors:** Press the "SOLID LIGHT" button to select from 8 static solid colors. Hold to turn off.
3. **Adjust Light Brightness:** Use the "LIGHT +" button to adjust the brightness of the active light mode (20 levels).
4. **Display Dimmer:** Press the "DIMMER" button to cycle through 5 display brightness levels (L0-L4). L0 turns the clock display completely off, ideal for light-sensitive sleepers.



Image: The JALL K6 alarm clock demonstrating its 5-level display dimmer, including the L0 setting which completely turns off the clock face for light-sensitive sleepers.



Image: The JALL K6 alarm clock showcasing its 17 light modes, including 9 RGB effects and 8 solid colors, with adjustable brightness and display levels.

Bluetooth Speaker Functionality

Use your JALL K6 as a Bluetooth speaker for audio playback.

1. **Pairing:** Press the "BT" button to activate Bluetooth. The device will enter pairing mode. On your mobile device, search for "JALL K6" (or similar) in your Bluetooth settings and connect.
2. **Audio Playback:** Once paired, you can play audio from your mobile device through the JALL K6 speaker.
3. **Volume Control:** Adjust the volume using the volume scroll wheel on the device or from your connected mobile device.
4. **Music-Sync Light Effects:** Some light modes may synchronize with the music playback.



Image: A woman using her phone to connect to the JALL K6 alarm clock, highlighting its Bluetooth speaker capabilities with stereo sound and music-sync light effects.

USB Charging Port

The JALL K6 features a rear USB-A port for charging other devices.

- **Output:** The USB charging output is 5V1A.
- **Usage:** Connect your device's charging cable to the USB-A port on the back of the JALL K6 to charge it.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Placement:** Place the device on a stable, flat surface away from direct sunlight, heat sources, and moisture.
- **Power:** Always use the recommended power adapter and cable.

Troubleshooting

Problem	Possible Solution
Device does not power on.	Ensure the USB Type-C cable is securely connected to both the device and a working power source. Verify the power adapter is functional.
Display is off.	Press the "DIMMER" button to adjust the display brightness. Ensure it is not set to L0 (fully off).
Alarm does not sound.	Check if the alarm is enabled using the "ALARM SWITCH" button. Verify the alarm time is set correctly and the volume is not muted.
Bluetooth not connecting.	Ensure Bluetooth is enabled on both the alarm clock (press "BT" button) and your mobile device. Make sure the device is within range and not connected to another device. Try restarting both devices.
Settings are lost after unplugging.	The internal CR2032 backup battery should retain settings. If settings are consistently lost, the backup battery may need replacement. Contact customer support.

Specifications

- **Model:** K6
- **Color:** Beige Linen
- **Material:** Plastic + Linen
- **Power Source:** Corded Electric (USB Type-C Input 5V2A)
- **USB Charging Output:** 5V1A
- **Dimensions:** 7 x 4 x 7 inches (approx.)
- **Weight:** 14.4 ounces
- **Display Levels:** 5 (L0-L4, L0 is fully off)
- **Light Brightness Levels:** 20
- **Light Modes:** 17 (9 RGB effects, 8 Solid Colors)
- **Sleep Sounds:** 25
- **Wake-Up Sounds:** 7
- **Sleep Timer:** 10 minutes to 8 hours
- **Sunrise Simulation:** 0-60 minutes
- **Snooze Duration:** 9 minutes (default)

Official Product Videos

JALL Natural Wake-Up Light

Your browser does not support the video tag.

Video: This video demonstrates the JALL K6's natural wake-up light feature, showing how the light gradually brightens to simulate a sunrise, providing a gentle awakening experience.

JALL Sunrise Alarm Clock White Noise Machine with Bluetooth

Your browser does not support the video tag.

Video: An overview of the JALL K6 Sunrise Alarm Clock, highlighting its white noise machine capabilities and Bluetooth connectivity for audio streaming and automatic time synchronization.

JALL K6 White Noise Sound Machine Alarm Clock

Your browser does not support the video tag.

Video: This video focuses on the JALL K6 as a white noise sound machine and alarm clock, demonstrating its various sound options and alarm functions for improved sleep and waking.

Colorful Ambient Light

Your browser does not support the video tag.

Video: A short demonstration of the JALL K6's colorful ambient light features, showcasing its various RGB effects and solid color options to create different moods.

Warranty and Support

JALL provides lifetime customer support for the K6 Sunrise Alarm Clock and White Noise Machine. If you encounter any issues or have questions not covered in this manual, please contact our support team.

Contact Information:

- For support, please visit the JALL Store on Amazon or refer to the contact details provided with your product packaging.

© 2023 JALL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GY3ZBR3H

More documents and user manuals: **https://manuals.plus/**