HOMSHADE HY11

HOMSHADE 9FT Motorized Patio Umbrella Instruction Manual

Model: HY11 | Brand: HOMSHADE

Product Overview

This manual provides instructions for the HOMSHADE 9FT Motorized Patio Umbrella, Model HY11. This umbrella features motorized operation, solar-powered LED lighting, and a durable construction designed for outdoor use.

- **Multifunctional Control:** Operates via remote control, pole-mounted controller, or manual 30° pull-open mechanism.
- **Solar-Powered Lighting:** Integrated LED lights powered by a solar panel for evening illumination.
- **Durable Fabric:** Made from 220gsm solution-dyed fabric with UPF50+ sun protection, anti-UV coating, 5-year fade resistance, and water repellency.
- **Robust Frame:** Features an 8-rib steel alloy frame and a 1.9-inch pole for stability and wind resistance up to 30 MPH.

Package Contents

Verify that all components are present before beginning assembly:

- Umbrella Canopy with integrated LED lights
- Umbrella Pole (upper and lower sections)
- Remote Control
- Pole-Mounted Smart Controller (pre-attached)
- Instruction Manual



Image: Example of package contents, including umbrella components and manual.

Setup Instructions

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble Pole:** Connect the upper and lower sections of the umbrella pole. Ensure they are securely fastened.
3. **Insert into Base:** Place the assembled pole into a suitable umbrella base (base not included). Ensure the base is heavy enough to provide stability for a 9FT umbrella. The pole diameter is 1.9 inches (48mm).
4. **Open Umbrella Manually (Initial):** Gently lift the umbrella ribs by hand to approximately 30 degrees. The canopy will then automatically open further.
5. **Solar Panel Placement:** Ensure the solar panel located at the top of the umbrella receives direct sunlight for optimal charging.



Image: Pole-mounted smart controller for operation.



Image: Demonstrating the initial 30-degree manual lift for automatic opening.




Image: Dimensions of the 9FT umbrella, showing pole height and diameter.

Operating Instructions

1. Remote Control Operation

The umbrella can be opened, closed, and its LED lights controlled using the provided remote control. Ensure the remote has working batteries.

- Press the **Open** button to extend the umbrella canopy.
- Press the **Close** button to retract the umbrella canopy.
- Press the **Light** button to turn the LED lights on or off.



Image: Remote control used to operate the umbrella and lights.

2. Pole-Mounted Controller Operation

The pole-mounted smart controller offers an alternative method for operation and light control.

- Locate the control panel on the umbrella pole.
- Use the designated buttons to open, close, and control the LED lights.



Image: Detailed view of the pole-mounted controller with buttons for umbrella and light control.

3. Manual Pull-Open Mechanism

For initial opening or in case of power issues, the umbrella can be manually opened by lifting the ribs.

- Gently pull the umbrella ribs upwards by hand to an angle of 15-30 degrees.
- The umbrella canopy will then automatically extend to its fully open position.

Your browser does not support the video tag.

Video: Demonstration of the HOMSHADE patio umbrella's operation, including opening and closing.

Your browser does not support the video tag.

Video: Overview of the HOMSHADE outdoor umbrella features and functionality.

4. Solar Lighting

The integrated LED lights are powered by a solar panel. Ensure the solar panel is exposed to direct sunlight for approximately 5 hours to achieve a full charge, providing up to 10 hours of illumination.



Image: The umbrella with its solar-powered LED lights illuminated at night.

Maintenance

- **Cleaning:** Wipe the umbrella canopy and pole with a damp cloth as needed. Avoid harsh chemicals that may damage the fabric or finish.
- **Storage:** In severe weather conditions (strong winds, heavy rain, snow) or during prolonged periods of non-use, close the umbrella and store it in a protected area to extend its lifespan.
- **Solar Panel:** Keep the solar panel clean and free of debris to ensure efficient charging.
- **Battery:** The internal battery for the motorized function and lights is designed for long-term use. If issues arise with charging or operation, ensure the solar panel is clean and receiving adequate sunlight.

Troubleshooting

- **Umbrella not opening/closing:**

- Check remote control batteries.
- Ensure the pole-mounted controller has sufficient charge (indicated by its lights).
- Verify no obstructions are preventing movement.
- Attempt manual pull-open to see if the automatic mechanism engages.

- **LED lights not working:**
  - Ensure the solar panel has received adequate sunlight for charging.
  - Check the light button on the remote or pole-mounted controller.
  - Verify connections if accessible (refer to detailed diagrams in the printed manual if available).
- **Umbrella instability:**
  - Ensure the umbrella base is appropriate for a 9FT umbrella and is adequately weighted.
  - Confirm all pole connections are secure.

Specifications

Brand	HOMSHADE
Model Number	HY11
Size	9FT
Color	Buff (as per current product variant)
Fabric Material	220gsm Solution-Dyed Fabric
UV Protection	UPF50+, Anti-UV Coating, 99.9% UV blockage
Fade Resistance	5-Year Fade Resistance
Water Resistance	Water Repellent, IPX4 Waterproof (PU Coating)
Frame Material	Alloy Steel (8 ribs, 18x12mm thicker ribs)
Pole Diameter	1.9 inches (48mm)
Wind Resistance	Up to 30 MPH
Lighting	32 LED lights, Solar-Powered (4800mAh battery, 10H runtime after 5H charge)
Opening Mechanism	Motorized (Remote, Pole Controller), Manual Lift
Product Care	Wipe With Damp Cloth



Image: Features of the umbrella fabric, including UV protection and fade resistance.



Image: Illustration of the robust 8-rib steel alloy frame and powder coating.

Warranty and Support

For warranty information or technical support, please contact HOMSHADE customer service. Refer to the contact details provided with your purchase documentation or visit the official HOMSHADE website.
The product is designed for durability, with features like a 5-year fade-resistant fabric and rust-resistant frame. For any manufacturing defects or operational issues not covered in this manual, please reach out to the manufacturer directly.



Image: Certifications indicating product quality and safety standards.

© 2024 HOMSHADE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question