



[Manuals.plus](#) /

› [SMARTSTANDARD](#) /

› SMARTSTANDARD 24" x 80" Sliding Pocket Interior Door Instruction Manual

SMARTSTANDARD P22480PDF

SMARTSTANDARD 24" x 80" Sliding Pocket Interior Door

Model: P22480PDF

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your SMARTSTANDARD 24" x 80" Sliding Pocket Interior Door. Please read all instructions carefully before beginning installation to ensure proper function and safety. Keep this manual for future reference.

SAFETY INFORMATION

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves during installation.
- Ensure the installation area is clear of obstructions and well-lit.
- Verify that the wall structure can support the weight of the door and frame kit. Consult a professional if unsure.
- Use caution when handling the door panel to prevent injury or damage.
- Keep children and pets away from the installation area.
- Do not modify the product in any way not described in this manual.

PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact customer support.

- Pocket Door Frame Kit
- Door Panel (24" W x 80" H, 1.38" thickness)
- Soft-Close Mechanism
- Three-Wheel Hangers
- Detailed Instruction Guide

SETUP AND INSTALLATION

1. Pre-Installation Checks

Before installation, ensure your rough opening meets the required dimensions. For a 24" x 80" door, the rough opening should be approximately 49" wide and 84-1/2" high. The door thickness is 1.38 inches.



Figure 1: Sizing Guide for Pocket Doors. This diagram shows the relationship between door size and the required rough opening dimensions, including door thickness and minimum rough opening height.

2. Frame Assembly and Installation

The pocket door frame kit is designed for straightforward assembly. Follow the detailed, step-by-step instruction guide included in your package. The track is trimmable to fit your specific opening requirements.

ULTIMATE SPACE-SAVING SOLUTION: POCKET vs. BARN DOOR




Figure 2: Trimmable Track Detail. The track can be cut to size for a precise fit within your wall opening.

3. Door Panel and Hardware Installation

The door panel is pre-assembled, simplifying the installation process. Attach the three-wheel hangers to the top of the door panel and then mount the door onto the installed track. Integrate the soft-close mechanism as per the instructions to ensure smooth and quiet operation.

ULTIMATE SPACE-SAVING SOLUTION:POCKET vs. BARN DOOR



Figure 3: Installation Kit Overview. Shows the ready-to-install pre-assembled panel and the detailed instruction guide for easy setup.



Figure 4: Soft-Close Mechanism and Hanger. Details of the two-way soft-close system and three-wheel hangers designed for quiet and smooth door movement.

Once installed, the door will slide completely into the wall, maximizing your usable floor space.



Figure 5: Installed Pocket Door. An example of the SMARTSTANDARD pocket door installed, showing the integration of the door and frame within the wall structure.

OPERATING INSTRUCTIONS

The SMARTSTANDARD pocket door features a quiet gliding system with a two-way soft-close mechanism. To operate, gently push or pull the door. The soft-close feature will engage automatically near the end of the door's travel, preventing slamming and ensuring a smooth, controlled stop in both opening and closing directions.

MAINTENANCE

- **Cleaning:** The door panel is made from solid core MDF and can be cleaned with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals. For painted surfaces, use a mild, non-abrasive cleaner.
- **Track and Hangers:** Periodically inspect the track and hangers for any debris or obstructions. Clean as needed to ensure smooth operation. Do not apply oil or grease to the track unless specifically recommended by the manufacturer.
- **Fasteners:** Check all fasteners and screws periodically to ensure they remain tight. Tighten any loose fasteners to maintain stability and safety.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Door does not slide smoothly	Debris in track, loose hangers, misaligned track	Clean track, check hanger attachment, verify track alignment.
Soft-close mechanism not engaging	Mechanism improperly installed or damaged	Refer to installation guide for soft-close setup. Contact support if damaged.
Door rubs against frame	Door or frame misalignment	Adjust door hangers or frame components as needed.

SPECIFICATIONS

- **Brand:** SMARTSTANDARD
- **Model Number:** P22480PDF
- **Door Panel Size:** 24" (W) x 80" (H)
- **Door Panel Thickness:** 1.38"
- **Material:** Solid Core MDF (Wood)
- **Color:** White
- **Rough Opening Width (Approx.):** 49"
- **Rough Opening Height (Approx.):** 84-1/2"
- **Included Components:** Pocket Door Frame Kit, Door Panel
- **Assembly Required:** No (for door panel), Yes (for frame kit)

WARRANTY AND SUPPORT

For warranty information or technical assistance, please refer to the documentation provided with your purchase or contact SMARTSTANDARD customer service. A professional customer service team is available to assist with any questions or issues you may encounter during installation or use.