Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOGARLABS PD11CS

HOGARLABS 32-Pint Home Dehumidifier (Model PD11CS) User Manual

Model: PD11CS | Brand: HOGARLABS

1. Introduction

This manual provides essential instructions for the safe operation, installation, maintenance, and troubleshooting of your HOGARLABS 32-Pint Home Dehumidifier, Model PD11CS. Please read this manual thoroughly before using the appliance and retain it for future reference.

The HOGARLABS dehumidifier is designed to remove excess moisture from the air, helping to create a more comfortable and healthy indoor environment. It is suitable for various spaces including basements, living rooms, bedrooms, and bathrooms.



Front view of the HOGARLABS 32-Pint Home Dehumidifier.

2. Safety Information

To prevent injury to the user or others and property damage, the following instructions must be followed. Incorrect operation due to ignoring instructions may cause harm or damage.

- Always ensure the dehumidifier is placed on a level, stable surface.
- Do not operate the unit with a damaged power cord or plug.
- Keep the appliance away from heat sources and direct sunlight.
- Do not block the air inlet or outlet.
- Unplug the unit before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Setup and Placement

3.1 Unpacking

1. Carefully remove the dehumidifier from its packaging.
2. Remove all packing materials, tapes, and protective films.
3. Inspect the unit for any damage during transit. If damaged, contact customer support.

3.2 Placement

For optimal performance, place the dehumidifier in an area where the humidity is highest or where moisture control is most needed. Ensure there is at least 8 inches (20 cm) of space around the unit for proper airflow.

- **Recommended Areas:** Basements, storage rooms, bedrooms, bathrooms, and living rooms.
- **Coverage Area:** The unit is designed to effectively dehumidify areas up to 200 square feet.
- **Mobility:** The dehumidifier is equipped with 360° universal wheels for easy movement between rooms.

Benefits of Improved Air Quality

Humidity control effectively limits the growth of bacteria and mold, alleviates allergy symptoms and breathing problems, and improves air quality to maintain a healthy and comfortable environment.






The compact and portable design with 360° universal wheels allows for easy relocation.

Widely Used in Various Indoor Places

Coverage Area **2000** Sq.Ft


Living room


Bedroom


Bathroom


Basement


Wardrobe


RV




Illustration of the dehumidifier's effective coverage in different indoor environments.

4. Operating Instructions

4.1 Control Panel Overview

The dehumidifier features a top-mounted digital control panel for easy operation. The LCD display shows the current humidity value.



Detailed view of the easy-to-use control panel with various function buttons.

4.2 Power On/Off

- Press the **POWER** button to turn the unit on or off.

4.3 Operating Modes

The dehumidifier offers three distinct operating modes:

- **DEHU Mode:** In this mode, you can set your desired humidity level between 30% and 80%. The unit will

automatically cycle on and off to maintain this set humidity. The comfortable humidity range for most people is 45%-60%.

- **DRY Mode:** This unique mode is designed for quickly drying wet clothes, helping to prevent odors.
- **CONT Mode (Continuous):** Ideal for spaces with very high humidity, such as bathrooms after a shower, where continuous dehumidification is required.



Visual representation of the three operating modes and their typical applications.

4.4 Humidity Setting

- In DEHU mode, press the**HUMI** button to adjust the target humidity level.
- The unit will automatically maintain the set humidity, turning off when the level is reached and restarting if humidity rises.



The dehumidifier actively works to maintain a healthy humidity level, adjustable between 30% and 80%.

4.5 Timer Function

- Press the **TIMER** button to set a 1-24 hour timer for automatic power on or off.

4.6 Fan Speed Adjustment

- In DEHU and CONT modes, press the**SPEED** button to adjust the fan speed (Low/High).

4.7 Child Lock

- Press and hold the **LOCK** button to activate or deactivate the child lock function, preventing unintended changes to settings.



The child lock feature ensures settings remain unchanged, even with curious children nearby.

4.8 Quiet Operation

The dehumidifier operates at a low noise level, as quiet as 36 dB, making it suitable for use in bedrooms and living areas without significant disturbance.




Illustration of the dehumidifier's quiet operation, comparable to a whisper.

5. Maintenance

5.1 Water Drainage

Your dehumidifier offers two drainage options:

- **Manual Drainage (Water Tank):** The unit is equipped with a 0.66-gallon water tank. When the tank is nearly full, the dehumidifier will automatically stop operation and emit a beep alarm to alert you. Empty the water tank and reinsert it to resume operation.
- **Continuous Drainage (Drain Hose):** For extended operation without manual emptying, connect the included 3.28-foot drain hose to the continuous drainage port. Ensure the hose is directed downwards to a suitable drain.



The dehumidifier supports both manual water tank drainage and continuous drainage via a hose.

5.2 Filter Cleaning

The dehumidifier includes a detachable and washable filter screen. Regular cleaning of the filter is essential for maintaining efficiency and air quality.

1. Unplug the dehumidifier from the power outlet.
2. Remove the filter screen from the unit (refer to the diagram on the unit for location).
3. Wash the filter with clean water and a mild detergent.
4. Allow the filter to air dry completely before reinserting it into the dehumidifier.



The detachable filter screen can be easily washed to maintain air quality and unit efficiency.

6. Troubleshooting

Before contacting customer service, please refer to the following troubleshooting guide for common issues:

Problem	Possible Cause	Solution
Unit does not turn on.	No power, power cord loose, water tank full.	Check power connection. Empty water tank if full.
No dehumidification.	Room temperature too low, air filter clogged, humidity setting too high.	Ensure room temperature is above 5°C (41°F). Clean air filter. Lower humidity setting.
Unit is noisy.	Unit not on a level surface, air filter clogged.	Place unit on a flat, stable surface. Clean air filter.
Water leaks from unit.	Drain hose not properly connected, water tank not correctly inserted.	Ensure drain hose is securely connected and sloped downwards. Reinsert water tank correctly.

7. Specifications

Feature	Detail
Brand	HOGARLABS
Model Number	PD11CS
Dehumidification Capacity	32 Pints/Day (at 86°F, 80% RH)
Water Tank Capacity	0.66 Gallons
Recommended Coverage Area	Up to 200 sq. ft.
Voltage	120 Volts
Item Dimensions (D x W x H)	30D x 48.5W x 20H cm

Feature	Detail
Item Weight	11.97 kg
Noise Level	As low as 36 dB
Drain Hose Length	3.28 feet
Operating Modes	DEHU, DRY, CONT
Special Features	Adjustable Humidity Control, Automatic Moisture Removal, Bucket Storage, Child Lock, Continuous Draining, 1-24H Timer, Adjustable Fan Speed, Detachable & Washable Filter, 360° Universal Wheels

8. Warranty and Support

HOGARLABS provides the following support for your dehumidifier:

- **Warranty:** A 1-year warranty is included from the date of purchase.
- **Return Service:** A 3-month free return service is available.
- **Customer Support:** Our customer service and after-sales team are available 24 hours a day to assist with any questions or concerns. Please refer to your purchase documentation for contact details.

© 2026 HOGARLABS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GY8ZM52M

More documents and user manuals: **https://manuals.plus/**