Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zeppelin 8680-3

Zeppelin 100 Jahre Chronograph Alarm Watch Model 8680-3 User Manual

Model: 8680-3 | Brand: Zeppelin

Introduction

This manual provides detailed instructions for the Zeppelin 100 Jahre Chronograph Alarm Watch, Model 8680-3. This timepiece combines classic elegance with modern chronograph functionality, featuring a curved dial, K1 safety glass, and a reliable Swiss quartz movement. It includes chronograph and alarm functions, and its dial is covered with Super-LumiNova for enhanced readability in low light conditions.





Front view of the Zeppelin 100 Jahre Chronograph Alarm Watch, Model 8680-3, showcasing its elegant design and dial.

Setup

1. Setting Time and Date

1. Pull the crown out to position 2 (first click) to set the date. Turn the crown clockwise or counter-clockwise until the correct date is displayed.
2. Pull the crown out to position 3 (second click) to set the time. Turn the crown to move the hour and minute hands to the desired time. Push the crown back to position 1 (normal position) to start the watch.

2. Adjusting the Leather Strap

The watch features an elegant leather strap with a buckle closure. Adjust the strap by inserting the pin into the appropriate hole for a comfortable and secure fit on your wrist. Ensure it is not too tight to allow for proper circulation.

Operating Instructions

1. Chronograph Function

The chronograph allows for precise time measurement.

- **Start/Stop:** Press the upper pusher (button A) to start the chronograph. Press it again to stop.
- **Reset:** With the chronograph stopped, press the lower pusher (button B) to reset all chronograph hands to zero.

2. Alarm Function

The watch is equipped with an alarm function. Refer to the specific movement instructions for detailed alarm setting procedures, typically involving a dedicated sub-dial and pusher.

3. Luminous Dial (Super-LumiNova)

The dial is treated with Super-LumiNova, providing excellent readability in the dark. Exposure to light charges the luminous material, causing it to glow blue in low-light conditions.



The watch dial glowing in the dark, demonstrating the Super-LumiNova feature for enhanced visibility.

4. Water Resistance

This watch is water resistant up to 5 ATM (50 meters). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. However, it is not recommended for swimming, showering, or diving.





Rear view of the watch, showing the engraved case back with water resistance rating and "Made in Germany" inscription.

Maintenance

1. Leather Strap Care

To ensure the longevity of your leather strap, it is recommended to remove the watch before showering or swimming. The strap can be cleaned with a damp cloth and a special leather cleaner. Avoid prolonged exposure to direct sunlight or extreme temperatures.

2. Watch Case Cleaning

Wipe the stainless steel case and K1 mineral crystal with a soft, dry cloth to remove dust and fingerprints. For more stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive materials.

3. Battery Replacement

The watch is powered by one Lithium Metal battery. When the watch stops or the functions become erratic, it is likely time for a battery replacement. It is recommended to have the battery replaced by a qualified watchmaker to ensure proper sealing and maintain water resistance.

Troubleshooting

- **Watch Not Running:**
  Ensure the crown is fully pushed in to position 1. If the watch still does not run, the battery may need replacement. See "Battery Replacement" in the Maintenance section.
- **Incorrect Time/Date:**
  Refer to "Setting Time and Date" in the Setup section to correctly adjust the watch.
- **Chronograph Hands Not Resetting to Zero:**
  If the chronograph hands do not reset to their zero position after pressing the reset pusher, a calibration may be required. Consult a professional watchmaker for adjustment.
- **Alarm Not Functioning:**
  Verify that the alarm is correctly set according to the movement's specific instructions. If the issue persists, professional inspection may be necessary.

Specifications

Model Number	8680-3
Brand	Zeppelin
Movement Type	Swiss Quartz (Ronda)
Case Material	Stainless Steel
Case Diameter	43 mm
Case Thickness	13 mm
Crystal	K1 Mineral Safety Glass
Water Resistance	5 ATM (50 Meters)
Strap Material	Leather
Clasp Type	Buckle
Dial Color	Beige (with Super-LumiNova)
Band Color	Black
Functions	Chronograph, Alarm, Date, Tachymeter
Battery Type	1 Lithium Metal (included)

Item Weight	76 Grams

Warranty Information

This Zeppelin watch comes with a **2-year manufacturer's guarantee**. Please refer to the included guarantee card for specific terms and conditions. It is important to fill out the guarantee card and retain it, as it may be required for service claims.

The warranty card, indicating a 2-year international guarantee. Ensure this card is filled out and kept for service.

Support and Contact

For further assistance, technical support, or warranty claims, please contact your authorized Zeppelin retailer or the manufacturer directly.

- **Manufacturer:** Zeppelin (POINT tec Electronic GmbH)
- **Address:** Steinheilstraße 6, D-85737 Ismaning / München, Germany
- **Website:** www.pointtec.de

When contacting support, please have your watch model number (8680-3) and proof of purchase readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GY9XHZFK

More documents and user manuals: **https://manuals.plus/**