

[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Queen Over King Bunk Bed Instruction Manual - Model WL000058QKB1

Bellemave WL000058QKB1

Bellemave Queen Over King Bunk Bed Instruction Manual

Model: WL000058QKB1

Brand: Bellemave

INTRODUCTION

Thank you for choosing the Bellemave Queen Over King Bunk Bed. This manual provides detailed instructions for the safe assembly, operation, and maintenance of your new bunk bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: Fully assembled Bellemave Queen Over King Bunk Bed in black with LED lighting and storage shelf.

SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Maximum weight capacity is **500 pounds per bed**. Do not exceed this limit.
- Ensure proper assembly and follow all instructions to prevent instability or collapse.
- Use only recommended mattress thicknesses: **6 inches for the upper (Queen) bed** and **8 inches for the lower (King) bed** to maintain structural integrity and ensure guardrail effectiveness.
- The upper bunk is equipped with full-length guardrails. Always ensure they are securely in place.
- The ladder features EVA padding for improved grip and comfort. Always use the ladder for access to the upper bunk.
- Periodically check all connections and hardware to ensure they remain tight. Retighten as necessary.
- Do not allow children under 6 years of age on the upper bunk.
- Prohibit more than one person on the upper bunk.

- Always use the ladder for entering and leaving the upper bunk.
- Prohibit horseplay on or under the bed.
- Always use the guardrails on both sides of the upper bunk.
- The use of water or sleep flotation mattresses is prohibited.

PACKAGE CONTENTS

Your Bellemave Queen Over King Bunk Bed ships in two boxes. Please verify all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

Included Components:

- Bed Frame Sections (Metal)
- Guardrails
- Headboard and Footboard Panels (Engineered Wood)
- Ladder with EVA Anti-Slip Foam Cover
- Metal Slats for mattress support
- Storage Shelf
- LED Strip Light
- Hardware Pack (screws, bolts, washers, Allen wrench)
- Installation Manual

Tools Required (Not Included):

- Phillips Head Screwdriver

SETUP AND ASSEMBLY

Assembly of the Bellemave Queen Over King Bunk Bed is designed to be straightforward. It is recommended that two adults assemble the bed. Please follow the step-by-step instructions provided in the separate Installation Manual included in your package. Ensure you have ample space and all components laid out before starting.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Refer to the parts list in the Installation Manual to identify each piece.
2. **Assemble Lower Bed Frame:** Begin by connecting the main frame sections for the King-size lower bed. Secure all bolts loosely at first.
3. **Install Lower Bed Slats:** Place the metal slats onto the lower bed frame. Ensure they are evenly spaced and securely fastened.
4. **Assemble Upper Bed Frame:** Connect the main frame sections for the Queen-size upper bed.
5. **Install Upper Bed Slats and Guardrails:** Place the metal slats onto the upper bed frame. Attach the full-length guardrails to the upper bunk frame.
6. **Attach Storage Shelf:** Mount the single-tier storage shelf between the upper and lower bunks as indicated in the manual.
7. **Attach Ladder:** Securely attach the angled ladder to the bunk bed frame. Ensure the EVA padding is correctly positioned on the ladder rungs.
8. **Install LED Strip Light:** Adhere the LED strip light to the designated area on the storage shelf or headboard, following the specific instructions for its power connection.

9. **Final Tightening:** Once all components are in place, systematically tighten all bolts and screws using the provided Allen wrench and your Phillips head screwdriver. Do not overtighten.
10. **Place Mattresses:** Add a Queen mattress (6" recommended) to the upper bunk and a King mattress (8" recommended) to the lower bunk.




Image: Technical drawing showing the dimensions of the bunk bed in inches.




Image: Close-up of the metal slat system for mattress support.




Image: Detail of the EVA anti-slip foam cover on a ladder rung.

OPERATING INSTRUCTIONS

LED Light Strip:

The integrated LED light strip provides soft, adjustable illumination. Connect the LED strip to a suitable power source (e.g., USB adapter, not included) as per the separate LED light instructions. Use the inline controller to turn the lights on/off, adjust brightness, and change colors or modes.



Image: Close-up of the LED light strip installed beneath the storage shelf, providing ambient lighting.

Storage Shelf:

The single-tier storage shelf is located between the upper and lower bunks. It is designed to hold small items such as phones, books, glasses, or a small lamp. Do not overload the shelf or place heavy objects on it.



Image: Detail of the integrated storage shelf, showing its capacity for small personal items.

MAINTENANCE

- **Cleaning:** Wipe the metal frame and engineered wood panels with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Tighten any loose hardware to ensure the bed remains stable and secure.
- **LED Light Care:** If the LED strip becomes dusty, gently wipe it with a dry, soft cloth. Ensure the power is

disconnected before cleaning.

- **Ladder Inspection:** Check the ladder rungs and EVA padding for any signs of wear or damage. Replace if necessary to maintain safety.

TROUBLESHOOTING

Bed is wobbly or squeaks:

This bunk bed is constructed from heavy-duty steel with noise-reducing engineering. If wobbling or squeaking occurs, re-check all connections and tighten any loose bolts. Ensure the bed is placed on a flat, level surface.

LED light strip is not working:

Verify that the LED strip is properly connected to a power source and that the power source is active. Check the inline controller for any damage or loose connections. Refer to the separate LED light instructions for specific troubleshooting steps.

Missing or damaged parts:

If you discover any missing or damaged parts upon unpacking, do not proceed with assembly. Contact Bellemave customer support immediately for assistance.

SPECIFICATIONS

Model Number	WL000058QKB1
Size	Queen over King
Product Dimensions (L x W x H)	83.46" x 78.74" x 62.4"
Material	Engineered Wood, Metal
Color	Black
Maximum Weight Recommendation	500 pounds per bed
Recommended Mattress Thickness (Upper)	6 inches (Queen)
Recommended Mattress Thickness (Lower)	8 inches (King)
Special Features	LED Lighting, Storage Shelf, Guardrails, Ladder, No Box Spring Needed, Reinforced Steel Support
Assembly Required	Yes (2 adults recommended)

WARRANTY AND SUPPORT

Bellemave products are manufactured with quality and durability in mind. For specific warranty information regarding your Queen Over King Bunk Bed, please refer to the documentation included in your product packaging or visit the official Bellemave website. If you have any questions, require replacement parts, or need assistance with assembly or operation, please contact Bellemave customer support. Contact details can typically be found on the product packaging or the brand's official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GYCFBVL9>

More documents and user manuals: <https://manuals.plus/>