

Pagani Design PD-YS032

Pagani Design PDYS032 Chronograph Watch User Manual

Model: PD-YS032

[Introduction](#)

[Overview](#)

[Setup](#)

[Operation](#)

[Maintenance](#)
[Support](#)

[Specifications](#)

[Troubleshooting](#)

[Warranty &](#)

1. INTRODUCTION

Thank you for choosing the Pagani Design PDYS032 Chronograph Watch. This manual provides essential information for the proper use, care, and maintenance of your new timepiece. Please read it thoroughly to ensure optimal performance and longevity of your watch.

1.1 Package Contents

- 1 x Pagani Design PDYS032 Watch
- 1 x Original Watch Box
- 1 x User Manual
- 1 x Warranty Card



Image 1.1: The Pagani Design PDYS032 watch presented in its original box.

2. WATCH OVERVIEW

The Pagani Design PDYS032 is a sophisticated chronograph watch featuring a precise Japanese TMI VK64 quartz movement. It is designed for durability and functionality with a sapphire crystal and a fluororubber strap.

2.1 Watch Components

Familiarize yourself with the main components of your watch:

1. **Crown:** Used for setting time and date.
2. **Pushers (A & B):** Used to operate the chronograph function.
3. **Main Dial:** Displays hours, minutes, and seconds.
4. **Chronograph Minute Sub-dial:** Tracks elapsed minutes for the chronograph.
5. **24-Hour Sub-dial:** Displays time in a 24-hour format.

6. **Date Window:** Displays the current date, located at the 6 o'clock position.
7. **Luminous Markers & Hands:** Provide visibility in low-light conditions.
8. **Sapphire Crystal:** Highly scratch-resistant watch glass with anti-reflective coating.
9. **Fluororubber Strap:** Durable, oil-resistant, and sweat-resistant strap.



Image 2.1: Detailed view of the watch dial and its features.

3. SETUP

3.1 Setting the Time

1. Pull the crown out to position 2 (the outermost position). The second hand will stop.
2. Turn the crown to set the hour and minute hands to the desired time. Ensure the 24-hour sub-dial is correctly aligned for AM/PM.
3. Push the crown back into position 0 (normal position) to start the watch.

3.2 Setting the Date

1. Pull the crown out to position 1 (the first click).
2. Turn the crown clockwise or counter-clockwise (depending on the movement) to set the date.
3. Once the correct date is displayed, push the crown back into position 0.

Important: Avoid setting the date between 9:00 PM and 3:00 AM, as this can damage the movement's date mechanism. If you need to set the date during this period, first set the time outside this range, adjust the date, then reset the time.

4. OPERATING INSTRUCTIONS

4.1 Chronograph Function

The chronograph allows you to measure elapsed time.

1. **Start:** Press pusher A (top pusher) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press pusher A again to stop the chronograph. The elapsed time will be indicated by the chronograph second hand and the chronograph minute sub-dial.
3. **Reset:** Press pusher B (bottom pusher) to reset the chronograph to zero. The chronograph hands will return to their starting positions.

4.2 Luminous Function

The hands and hour markers of your PDYS032 watch are coated with a luminous material. After exposure to light, they will glow in dark conditions, allowing for easy time reading.



Image 4.1: The watch displaying its luminous function in low light.

5. MAINTENANCE AND CARE

Proper care will extend the life and maintain the appearance of your Pagani Design watch.

- **Water Resistance:** The watch is water-resistant to 100 meters (10 ATM), suitable for swimming, showering, and surfing. **Do not press any buttons or pull the crown while the watch is wet or submerged.** This watch is not suitable for diving.
- **Temperature:** Avoid exposing the watch to extreme temperatures (both high and low) as this can affect the movement and seals.
- **Cleaning:** Regularly clean the watch case and fluororubber strap with a soft, damp cloth. The fluororubber strap is resistant to oil and sweat.
- **Impacts:** Avoid strong impacts or dropping the watch.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields, which can affect the accuracy of the quartz movement.
- **Chemicals:** Avoid contact with solvents, detergents, perfumes, and cosmetic products, as they can damage the strap, case, or seals.

6. SPECIFICATIONS

Detailed technical specifications for the Pagani Design PDYS032 watch:

Feature	Specification
Model Number	PD-YS032
Movement	Japan TMI VK64 Quartz
Display Format	Analog
Case Material	Stainless Steel
Case Diameter	44 mm
Case Thickness	11.8 mm
Crystal Type	Sapphire Crystal with AR Coating
Strap Material	Fluororubber
Strap Width	26.5 mm
Water Resistance	100 Meters (10 ATM)
Special Features	Chronograph, Luminous Hands/Markers, Date Display
Weight	125.2 g

MODEL:PD-YS032



Case Thickness:11.8MM/1.18CM/0.46IN



Dial diameter :44MM/4.4CM/1.73IN



Weight :125.2G/0.27IB/4.42OZ



Max Perimeter : 255MM/25.5CM/10.04IN



Movement :JAPAN TMI VK64



Bracelet width : 26.5MM/2.65CM/1.04IN



Bracelet material :Fluororubber Strap



Original gift box



Dial Window Material Type :Synthetic
Sapphire Glass + AR Coating



Note:This data is only store measurement data
There is an error(size $\pm 1\text{MM}/0.04\text{in}$,weight $\pm 2\text{G}/0.004\text{ib}$)

Image 6.1: Dimensional diagram and key specifications of the watch.

7. TROUBLESHOOTING

If you encounter any issues with your watch, please refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Watch not running / Stops frequently	Battery depleted. Replace the battery at a qualified watch repair shop.
Incorrect time / Date not changing	Crown not fully pushed in. Ensure the crown is in position 0. Re-set time/date as per Section 3.
Chronograph hands do not reset to zero	This may indicate a need for calibration or service. Consult customer support.

Problem	Possible Cause / Solution
Condensation inside the crystal	Indicates a breach in water resistance. Avoid further water exposure and seek professional service immediately.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your Pagani Design PDYS032 watch comes with a limited warranty. Please refer to the included warranty card for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

8.2 Customer Support

Should you encounter any problems during use that are not covered in this manual, or if you require service under warranty, please contact our customer support. We are committed to providing a satisfactory solution. For assistance, please refer to the contact information provided on your warranty card or the retailer's website where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question