Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ShanWan Q37Pro

ShanWan Wireless Mini Controller Q37Pro User Manual

Model: Q37Pro

1. Introduction

Thank you for purchasing the ShanWan Wireless Mini Controller Q37Pro. This compact and versatile controller is designed for a wide range of platforms, including Nintendo Switch, PC, iOS, and Android devices. It also features a dedicated Keyboard Mode for enhanced productivity with applications like iPad Procreate. Please read this manual carefully to ensure proper use and to maximize your experience with the controller.

Package Contents

- 1x ShanWan Wireless Mini Controller Q37Pro
- 1x Lanyard
- 1x User Manual

2. Product Overview

Familiarize yourself with the controller's layout and components.



Figure 2.1: Front view of the ShanWan Wireless Mini Controller Q37Pro, showing the D-pad, joysticks, action buttons (A, B, X, Y), and central function buttons.



Figure 2.2: Side view of the controller, highlighting the L1, L2, R1, R2 shoulder buttons and the USB-C charging port.



Figure 2.3: Back view of the controller, displaying the ShanWan brand and model number Q37Pro.



Figure 2.4: Bottom edge of the controller, featuring the mode switch (X/S/K), Pair button, and Reset button.

3. Setup

3.1 Charging the Controller

The controller has a built-in 300mAh rechargeable lithium-ion battery. Before first use, or when the battery is low, charge the controller using the provided USB Type-C cable.

1. Connect one end of the USB Type-C cable to the charging port on the controller (refer to Figure 2.2).
2. Connect the other end of the cable to a USB power source (e.g., computer, USB wall adapter).
3. The charging indicator light will illuminate during charging and turn off when fully charged.

A full charge provides over 90 days of standby time.

3.2 Connecting to Devices (Pairing)

The ShanWan Q37Pro supports Bluetooth connectivity. Follow these steps to pair with your device:

1. **Select Mode:** Use the mode switch on the bottom edge of the controller (Figure 2.4) to select the appropriate mode for your device:
    - **S:** For Nintendo Switch
    - **X:** For PC (X-input)
    - **K:** For iOS/Android (Keyboard Mode)
    - **D:** For PC (D-input) / Android (Gamepad Mode)
2. **Enter Pairing Mode:** Press and hold the **Pair** button (Figure 2.4) until the indicator lights start flashing rapidly. This indicates the controller is in pairing mode.
3. **Enable Bluetooth on your device:** Go to your device's Bluetooth settings.
4. **Search for Devices:** Your device will scan for available Bluetooth devices. Look for "ShanWan Q37Pro" or a similar name.
5. **Connect:** Select the controller from the list to complete the pairing process. The indicator light on the controller will become solid when successfully connected.



Figure 3.1: The controller demonstrating compatibility with various devices including Nintendo Switch, PC, and smartphones.

4. Operating Instructions

4.1 General Gaming Use

Once paired, the controller functions as a standard gamepad for compatible games on Switch, PC, iOS, and Android. The 16 buttons and 2 joysticks provide full control for most gaming scenarios. The ergonomic design helps minimize wrist fatigue during extended use.



Figure 4.1: The controller is compatible with Nintendo Switch OLED, original Switch, Switch Lite, and Switch 2.

4.2 Keyboard Mode for iPad Procreate and Other Apps

When the controller is set to 'K' (Keyboard) mode and paired with an iOS or Android device, it can be used to streamline workflows in creative applications like Procreate. This mode allows you to map common keyboard shortcuts to the controller's buttons, enhancing efficiency.

- Adjust color balance/HSB
- Perform cut, copy, paste, undo actions
- Control brush size and other tool parameters

This allows you to use your dominant hand for drawing while your other hand operates the controller for quick commands.



Figure 4.2: Controller in use with an iPad running Procreate, demonstrating its keyboard mode functionality for efficient digital art creation.

4.3 GamepadSpace App (Ultimate Software)

For advanced customization and firmware updates, download the GamepadSpace Ultimate Software mobile application. This app allows you to:

- Perform firmware upgrades.
- Adjust stick and trigger dead zones.
- Customize vibration intensity.
- Test button functionality.
- Map buttons (Keyboard mode only).



Figure 4.3: Screenshots of the GamepadSpace mobile application, illustrating options for calibration, button mapping, and other adjustments.

5. Maintenance

To ensure the longevity and optimal performance of your ShanWan Wireless Mini Controller Q37Pro, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, solvents, or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. When not in use for extended periods, ensure it is fully charged before storage.
- **Handling:** Avoid dropping the controller or exposing it to strong impacts. Do not attempt to disassemble the controller, as this will void the warranty.

6. Troubleshooting

If you encounter issues with your controller, please refer to the following common problems and solutions:

- **Controller will not power on:**
  - Ensure the battery is charged. Connect the controller to a power source using the USB-C cable.
- **Unable to pair with device:**
  - Verify the correct mode (S, X, K, D) is selected on the controller for your device.
  - Ensure Bluetooth is enabled on your device and it is within the 10m operating range.
  - Make sure the controller is in pairing mode (flashing indicator lights).
  - Try restarting both the controller and your device.
  - Clear previous Bluetooth connections on your device if you have too many paired devices.
- **Controller disconnects frequently or experiences lag:**
  - Ensure there are no obstructions between the controller and your device.
  - Move closer to your device to ensure you are within the optimal Bluetooth range.
  - Check for other wireless interference (e.g., Wi-Fi routers, other Bluetooth devices).
  - Ensure the controller's battery is sufficiently charged.
- **Buttons or joysticks are unresponsive:**
  - Try resetting the controller by pressing the**Reset** button (Figure 2.4) with a small pin.
  - Use the GamepadSpace app to test button functionality and calibrate joysticks.
  - Ensure the controller is properly paired and the correct mode is selected.

7. Specifications

Model Number	Q37Pro
Brand	ShanWan
Connectivity Technology	Bluetooth
Compatible Devices	Nintendo Switch, PC, iOS, Android
Number of Keys/Buttons	16 buttons, 2 joysticks
Battery Capacity	300mAh Lithium-ion
Charging Port	USB Type-C
Standby Time	Over 90 days
Wireless Range	Up to 10 meters (33 feet)
Dimensions (L x W x H)	3.86" x 2.08" x 0.73" (9.8 cm x 5.3 cm x 1.85 cm)
Hand Orientation	Ambidextrous



Figure 7.1: Dimensional overview of the ShanWan Wireless Mini Controller Q37Pro.

8. Warranty and Support

ShanWan is committed to providing high-quality products and professional after-sales service. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

If you have any questions, require technical assistance, or encounter issues not covered in this manual, please contact ShanWan customer support through the retailer where you purchased the product or visit the official ShanWan store online.

For further information and support, you may visit the ShanWan Store on Amazon.

© 2023 ShanWan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GYF1DP32

More documents and user manuals: **https://manuals.plus/**