

Jojoka 5-Drawer Dresser

Jojoka 5-Drawer Dresser Instruction Manual

Model: 5-Drawer Dresser

1. INTRODUCTION

Thank you for choosing the Jojoka 5-Drawer Dresser. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new storage unit. Please read these instructions carefully before assembly and retain them for future reference.

The Jojoka 5-Drawer Dresser is designed to offer versatile storage and organization for various rooms, including bedrooms, living rooms, hallways, and entryways. It features a sturdy metal frame, a durable wood tabletop, and five fabric drawers with easy-pull handles.

2. SAFETY INFORMATION

- Always assemble the dresser on a clean, flat, and soft surface to prevent scratches.
- Ensure all parts are present and undamaged before beginning assembly. Do not use damaged parts.
- Tighten all screws and bolts securely, but do not overtighten.
- Install the included anti-tip kit to prevent accidental tipping, especially in households with children or pets. Secure the dresser to a wall stud if possible.
- Do not overload drawers. Distribute weight evenly.
- Keep small parts away from children during assembly.
- Do not stand or climb on the dresser.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- Wood Tabletop

- Fabric Drawers (5 units)
- Solid Wood Handles
- Adjustable Feet
- Removable Hooks
- Anti-Tip Kit
- Assembly Hardware (screws, Allen wrench, etc.)
- Instruction Manual

4. SETUP (ASSEMBLY INSTRUCTIONS)

Assembly is designed to be straightforward. Follow these steps carefully:

1. **Unpack and Identify Parts:** Lay out all components on a soft, clean surface. Refer to the parts list to ensure everything is present.
2. **Assemble the Metal Frame:** Connect the vertical and horizontal metal frame components using the provided screws and Allen wrench. Ensure all connections are secure.
3. **Attach the Wood Tabletop:** Place the wood tabletop onto the top of the assembled metal frame and secure it with the designated screws.
4. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the metal frame. Adjust them as needed to ensure the dresser is level and stable on your floor.
5. **Prepare Fabric Drawers:** Unfold each fabric drawer and insert the bottom panel to create its rigid structure. Attach the solid wood handles to the front of each drawer.
6. **Insert Drawers:** Slide the assembled fabric drawers into their respective slots within the metal frame.
7. **Install Anti-Tip Kit:** Secure the anti-tip kit to the back of the dresser and to a wall stud using the provided hardware. This is a critical safety step.
8. **Attach Removable Hooks:** If desired, attach the removable hooks to the side of the frame for hanging light items.




Figure 4.1: Dimensions of the Jojoka 5-Drawer Dresser, showing overall height, width, depth, and individual drawer sizes.




Figure 4.2: Visual guide to key features including the anti-tip kit and adjustable feet, important for stability and safety.

5. OPERATING (USAGE)

The Jojoka 5-Drawer Dresser is designed for efficient and versatile storage:

- **Drawer Usage:** Utilize the five fabric drawers to organize clothing, accessories, books, toys, and other household items. The drawers are designed for smooth opening and closing with solid wood handles.
- **Top Surface:** The sturdy wood tabletop provides a stable surface for displaying decorative items, lamps, or for holding frequently used items.
- **Removable Hooks:** Use the included removable hooks on the side of the frame to hang bags, scarves, or other light accessories, maximizing vertical storage.
- **Versatile Placement:** This dresser is suitable for various rooms, including bedrooms, living rooms, nurseries, and entryways, adapting to your storage needs.



Figure 5.1: The Jojoka 5-Drawer Dresser organized in a room, demonstrating its practical use for storage and display.



Figure 5.2: Overhead view of the dresser with drawers open, illustrating the internal storage capacity and organization possibilities.

Your browser does not support the video tag.

Video 5.1: Official product video demonstrating the features and usage of the Jojoka 5-Drawer Dresser, including drawer functionality and overall design.

6. MAINTENANCE

Proper care will extend the life and appearance of your dresser:

- **Cleaning the Tabletop:** The wood tabletop is waterproof and easy to clean. Wipe spills immediately with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning Fabric Drawers:** For light cleaning, use a lint roller or a soft brush to remove dust and debris. For stains, gently spot clean with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash.
- **Cleaning Metal Frame:** Wipe the metal frame with a soft, damp cloth.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

Fabric:



Figure 6.1: Detail of the fabric drawer construction, highlighting the materials for proper care.

7. TROUBLESHOOTING

If you encounter any issues with your Jojoka 5-Drawer Dresser, refer to the following common problems and solutions:

- **Dresser is Wobbly:**
Solution: Ensure all screws and bolts are securely tightened. Adjust the leveling feet on the bottom of the frame to compensate for uneven floors.
- **Drawers Do Not Slide Smoothly:**
Solution: Check that the fabric drawers are fully unfolded and the bottom panels are correctly inserted. Ensure no items are obstructing the drawer's movement within the frame. Verify the frame itself is not bent or misaligned.
- **Anti-Tip Kit Not Secure:**
Solution: Confirm that the anti-tip strap is properly attached to both the dresser frame and a wall stud. If unable to locate a wall stud, use appropriate wall anchors for your wall type.
- **Missing Parts:**
Solution: Double-check the packaging. If parts are genuinely missing, contact customer support with your purchase details.

8. SPECIFICATIONS

Brand	Jojoka
Model Name	5-Drawer Dresser
Product Dimensions (D x W x H)	11.8" x 23.6" x 47.2"
Number of Drawers	5
Material	Fabric (Polyester), Steel Frame, Wood Tabletop (MDF)
Item Weight	30 Pounds
Color	Dark Grey
Assembly Required	Yes

9. WARRANTY

Jojoka products are manufactured with quality and durability in mind. This product comes with a standard manufacturer's warranty against defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact customer support.

10. SUPPORT

For any questions, assistance with assembly, or to report missing/damaged parts, please contact Jojoka customer support:

- **Email:** support@jojoka.com (Example)
- **Website:** [Jojoka Official Store on Amazon](#)

Please have your model number (5-Drawer Dresser) and purchase date ready when contacting support.