



[Manuals.plus](#) /

> [NexLev](#) /

> NexLev Replacement Mop Cloth Pads for SC-04 Steam Cleaner - User Manual

NexLev Mop Cloth for SC-04

NexLev Replacement Mop Cloth Pads for SC-04 Steam Cleaner - User Manual

Model: Mop Cloth for SC-04

INTRODUCTION

This manual provides instructions for the proper use and maintenance of your NexLev Replacement Mop Cloth Pads, designed specifically for the NexLev 10-in-1 Steam Cleaner & Mop (SC-04). These microfiber pads are engineered for effective floor deep cleaning across various sealed surfaces.

SETUP: ATTACHING THE MOP PADS

The NexLev Replacement Mop Cloth Pads feature a Velcro-based attachment system for easy installation and removal on your SC-04 Steam Cleaner & Mop.

1. Ensure your NexLev SC-04 Steam Cleaner is turned off and unplugged before attaching or removing any accessories.
2. Align the mop pad with the base of the steam mop head.
3. Press the mop pad firmly onto the Velcro strips on the mop head until it is securely attached. Ensure the entire surface of the pad is in contact with the Velcro for optimal performance.



Image: Two NexLev Replacement Mop Cloth Pads, showing the microfiber material and design. These pads are designed for easy attachment to the SC-04 steam mop head.

OPERATING: USING THE MOP PADS FOR CLEANING

Once the mop pad is securely attached to your NexLev SC-04 Steam Cleaner, you can begin your cleaning tasks. These premium microfiber pads are designed to effectively trap dirt, dust, and grime.

- Fill the water tank of your SC-04 Steam Cleaner according to its specific instructions.
- Plug in the steam cleaner and allow it to heat up until the indicator light signals it is ready for use.
- Begin cleaning by moving the steam mop across the desired floor surface. The microfiber pad will absorb dirt and moisture.
- The pads are safe and effective for use on various sealed surfaces, including tiles, marble, laminate, hardwood, and granite, without causing scratches or streaks.



Image: A NexLev Mop Cloth Pad securely attached to a steam mop head, demonstrating its readiness for effective floor cleaning on various sealed surfaces.

MAINTENANCE: CLEANING AND CARE

To ensure the longevity and continued cleaning efficiency of your NexLev Replacement Mop Cloth Pads, proper maintenance is essential. These pads are reusable and machine washable.

1. After each cleaning session, carefully remove the dirty mop pad from the steam mop head.
2. Machine wash the mop pads with similar colors in warm water. Avoid using bleach or fabric softeners, as these can degrade the microfiber material and reduce its effectiveness.
3. Tumble dry on low heat or air dry. Do not iron.
4. Store clean, dry pads in a clean, dry place until their next use.

TROUBLESHOOTING

If you encounter issues with your mop pads, consider the following:

- **Reduced Cleaning Efficiency:** Ensure the pad is clean. A dirty or saturated pad will not clean effectively. Replace with a fresh pad or wash the current one.

- **Pad Not Staying Attached:** Check if the Velcro on both the pad and the mop head is clean and free of debris. Over time, lint or dirt can reduce Velcro adhesion.
- **Streaking on Floors:** This can occur if the pad is too dirty, or if too much cleaning solution (if used with the steam cleaner) is applied. Ensure pads are clean and only use water for steam cleaning unless specified by your steam cleaner's manual.

SPECIFICATIONS

Feature	Detail
Brand	NexLev
Model Name	Mop Cloth for SC-04
Compatibility	NexLev 10-in-1 Steam Cleaner & Mop (SC-04)
Material	Premium Microfiber
Special Feature	Removable, Reusable, Machine Washable
Surface Recommendation	Tiles, Marble, Laminate, Hardwood, Granite, Sealed Surfaces
Number of Items	2 Count
Color	White & Blue

WARRANTY AND SUPPORT

NexLev provides comprehensive support for its products, ensuring a positive user experience.

Warranty Information

Your NexLev Replacement Mop Cloth Pads are covered by a **1 Year Warranty**. This warranty includes instant resolutions and doorstep pickup services. For any warranty claims or assistance, please contact NexLev support.

Customer Support

NexLev offers a 'Total Care' approach with omnichannel support, covering sales, after-sales, original parts, and general information. Services include free pick and drop at your doorstep for eligible issues. For quick assistance, you can reach us via WhatsApp by scanning the QR code provided in our product documentation or using the contact details below:

WhatsApp Support: [+91 79772 53317](tel:+917977253317)

Phone: +91 79961 35111

Email: support@nexlev.in