

[Manuals.plus](#) /

› [WHYKJTEK](#) /

› WHYKJTEK S48 Wireless Earbuds Instruction Manual

WHYKJTEK S48

WHYKJTEK S48 Wireless Earbuds Instruction Manual

Model: S48 | Brand: WHYKJTEK

INTRODUCTION

Thank you for choosing the WHYKJTEK S48 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.4 connectivity, deep bass stereo sound, and IPX7 waterproofing. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.

WHAT'S IN THE BOX



Image: Contents of the WHYKJTEK S48 Wireless Earbuds package.

- Charging Case
- Wireless Earbuds (Left and Right)
- Extra Ear Caps (2 Pairs - S/M/L sizes)
- Type-C Charging Cable
- User Manual
- Packaging Box

SETUP

1. Charging the Earbuds and Case



Image: LED Digital Power Display indicating charging status.

1. **Initial Charge:** Before first use, fully charge the earbuds and charging case.
2. **Charging the Case:** Connect the Type-C charging cable to the charging port on the case and a power source. The LED digital display on the case will show the battery percentage.
3. **Charging the Earbuds:** Place the earbuds into the charging case. They will automatically begin

charging. The LED display will show individual earbud charging status (L and R indicators).

4. **Battery Life:** A full charge provides approximately 6 hours of playtime for the earbuds, with the charging case extending total playtime up to 50 hours. A 10-minute quick charge can provide 2 hours of playtime.

2. Pairing with Your Device




Image: One-step auto pairing guide for the S48 earbuds.

1. **Step 1:** Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode.
2. **Step 2:** On your smartphone, laptop, or other Bluetooth-enabled device, open the Bluetooth settings.
3. **Step 3:** Search for available devices and select "S48" from the list to connect. Once connected, you will hear a confirmation tone, and the device will show "Connected."
4. **Automatic Reconnection:** After the initial pairing, the earbuds will automatically connect to the last paired device when removed from the charging case.

OPERATING INSTRUCTIONS

Touch Controls



Image: Handy touch operation guide for the S48 earbuds.

Action	Control
Play/Pause	Double-tap L/R earbud
Volume Up	Single-tap R earbud
Volume Down	Single-tap L earbud
Next Track	Press and hold R earbud for 2 seconds
Previous Track	Press and hold L earbud for 2 seconds
Answer/Hang Up Call	Double-tap L/R earbud
Reject Call	Press and hold L/R earbud for 2 seconds

Action	Control
Activate Voice Assistant	Triple-tap L/R earbud


Call Functions

ENC-Crystal Clear Phone Calls

With 4 microphones, and the ENC Call Noise Reduction technology keep your call clearer. Confidently take meetings and calls anywhere

3X CLEARER

Noise: 

Voice: 



— Noise — Ambient Sound



Before noise reduction After noise reduction

Image: ENC-Crystal Clear Phone Calls feature.

The S48 earbuds feature 4 microphones and ENC (Environmental Noise Cancellation) technology. This enhances voice pickup and minimizes background noise during calls, ensuring crystal-clear conversations even in noisy environments.

KEY FEATURES

Premium Stereo Sound

Premium Stereo Sound

13.4mm Bigger Dynamic Driver, Deep Bass+, HiFi Stereo sound



ENC Noise
Cancellation



13.4mm
Bigger Driver



Image: Internal structure of the earbud driver for premium stereo sound.

Equipped with exclusive dual-layer 12mm dynamic drivers, the S48 earbuds deliver powerful bass, clear mids, and bright highs for an immersive Hi-Fi stereo audio experience.

Ergonomic Design & Comfort

Ergonomic design and ultra-lightweight



Ergonomic Design



4g Ultra Lightweight



S/M/L Eartips

Image: Ergonomic design and lightweight nature of the earbuds.

The earbuds feature an ergonomic design and are ultra-lightweight (4g per earbud) for a secure and comfortable fit during extended use. Multiple sizes of ear tips (S/M/L) are included to ensure a personalized fit.

IPX7 Waterproof Rating

IPX7 WATERPROOF

With **IPX7** water resistance, it can withstand exposure to sweat and rain without any damage.



Image: IPX7 Waterproof feature of the earbuds.

With an IPX7 waterproof rating, these earbuds are resistant to sweat and rain, making them suitable

for workouts and outdoor activities. Avoid submerging them in water.

Bluetooth 5.4 Connectivity



Image: Advanced Bluetooth 5.4 technology benefits.

The latest Bluetooth 5.4 technology ensures fast transmission speeds, stable connections, and optimized power consumption, providing a seamless audio experience.

Ultra-Low Latency



Image: Ultra-low latency feature for gaming and video.

With 60ms ultra-low latency technology, the earbuds minimize the gap between audio and video during playback, providing a synchronized experience for gaming and watching videos.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Ear Tips:** Remove and clean the silicone ear tips with mild soap and water, then dry thoroughly before reattaching.
- **Charging Contacts:** Ensure the charging contacts on both the earbuds and the case are clean and dry to prevent charging issues.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged. Avoid extreme temperatures.

TROUBLESHOOTING

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on your device's Bluetooth. Forget "S48" from your device's Bluetooth list and re-pair.
No sound from one earbud	Place both earbuds back in the case, close the lid, then open again. Check device's audio balance settings.
Earbuds not charging	Clean charging contacts on earbuds and case. Ensure charging cable is securely connected and power source is active.
Poor sound quality	Ensure ear tips provide a good seal. Try different sized ear tips. Clean earbuds. Move closer to the connected device to avoid interference.
Touch controls unresponsive	Ensure your fingers are clean and dry. Restart the earbuds by placing them in the case and taking them out.

SPECIFICATIONS

Feature	Detail
Model Number	S48
Bluetooth Version	5.4
Ear Placement	In Ear
Driver Size	12mm (Dual-layer diaphragm)
Battery Life (Earbuds)	Up to 6 hours
Total Playtime (with Case)	Up to 50 hours
Charging Port	Type-C
Waterproof Rating	IPX7
Noise Cancellation	ENC (Environmental Noise Cancellation) for calls
Earbud Weight	Approx. 4g per earbud
Parcel Dimensions	17.7 x 9.3 x 3.4 cm
Parcel Weight	90 g

WARRANTY AND SUPPORT

WHYKJTEK products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official WHYKJTEK website. Please retain your proof of purchase for warranty claims.