

[Manuals.plus](#) /

› [YATINEY](#) /

› YATINEY DS11DBBY1N1 TV Stand with LED Lights Instruction Manual

YATINEY DS11DBBY1N1

YATINEY DS11DBBY1N1 TV Stand with LED Lights Instruction Manual

Model: DS11DBBY1N1

1. PRODUCT OVERVIEW

The YATINEY DS11DBBY1N1 TV Stand is designed to accommodate televisions up to 50 inches, offering both functional storage and aesthetic appeal with integrated LED lighting. This entertainment center features a robust metal frame, particleboard panels, and two fabric drawers for organized storage.



Image 1.1: Assembled YATINEY DS11DBBY1N1 TV Stand with LED lighting activated.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum load capacity. The tabletop supports up to 110 lb (50 kg). Each mesh shelf supports up to 33 lb (15 kg).
- **Anti-Tip Device:** Always install the included anti-tip device to prevent accidental tipping, especially in households with children or pets.
- **Stable Placement:** Ensure the TV stand is placed on a flat, stable surface. Adjustable feet are provided for minor leveling adjustments.
- **Assembly:** Follow all assembly instructions carefully. Do not overtighten screws.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x TV Stand Frame and Panels
- 1 x Accessory Package (Hardware, Tools)
- 1 x Assembly Manual
- 1 x Light Strip (LED)
- 2 x Fabric Drawers

4. SETUP AND ASSEMBLY

A detailed illustrated instruction manual is included in the accessory package to guide you through the assembly process. The required assembly tools are also provided.

4.1 Assembly Steps Overview

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Assemble the metal frame structure according to the provided manual.
3. Attach the particleboard panels and mesh shelves to the frame.
4. Insert the two fabric drawers into their designated compartments.
5. Install the LED light strip in the desired location, typically along the inner edges of the shelves.
6. Attach the anti-tip device to the TV stand and secure it to a wall stud.
7. Adjust the feet to ensure the stand is level and stable.




Image 4.1: Product dimensions and recommended TV sizes (up to 50 inches).

4.2 Fabric Drawer Assembly

The fabric drawers are designed for easy assembly. Simply unfold the drawer body, insert the bottom panel, and attach the handle. Ensure the drawers slide smoothly into their compartments.




Image 4.2: Detail of the 3-layer fabric drawers.

5. OPERATING INSTRUCTIONS (LED LIGHTS)

The TV stand includes an adjustable LED light strip to enhance your entertainment experience.

5.1 Activating and Adjusting LED Lights

- Connect the LED light strip to a power source as indicated in the assembly manual.
- Use the provided switch or remote control (if included) to turn the lights on/off.
- Cycle through various light effects and colors to create your desired atmosphere.



RGB LED TV Stand

Multi-color lighting creates an immersive visual atmosphere.

Image 5.1: RGB LED lighting in operation.

6. MAINTENANCE

Proper maintenance ensures the longevity and appearance of your TV stand.

6.1 Cleaning

- **Panels:** The particleboard panels are designed to be easy to clean. Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Metal Frame:** Wipe the metal frame with a soft, dry or slightly damp cloth.
- **Fabric Drawers:** Spot clean fabric drawers with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash.

Sturdy Metal Mesh Shelf

Ventilated mesh design with adjustable feet supports AV gear securely.



Image 6.1: Cleaning the easy-to-clean panels.

6.2 General Care

- Periodically check all screws and fasteners to ensure they remain tight.
- Avoid exposing the stand to direct sunlight or extreme humidity for extended periods.
- Do not place hot items directly on the surface without protection.

7. TROUBLESHOOTING

If you encounter any issues with your YATINEY TV Stand, refer to the following common solutions:

- **Stand is Unstable:** Ensure all screws are tightened. Adjust the leveling feet on the bottom of the stand to compensate for uneven floors.
- **LED Lights Not Working:** Check that the power adapter is securely plugged into both the light strip and a working power outlet. Verify that the light strip is correctly connected.
- **Drawers Do Not Slide Smoothly:** Ensure the fabric drawers are fully assembled and the bottom panel is

correctly inserted. Check for any obstructions in the drawer compartments.

8. SPECIFICATIONS

Feature	Specification
Model Number	DS11DBBY1N1
Brand	YATINEY
Color	Black
Overall Dimensions (L x W x H)	43.3" x 11.8" x 21.7" (110cm x 30cm x 55cm)
Item Weight	8.1 kg
Material Type	Particleboard, Metal, Non-Woven Fabric
Number of Drawers	2
Tabletop Load Capacity	110 lb (50 kg)
Mesh Shelf Load Capacity	33 lb (15 kg)
Additional Features	RGB LED TV Stand, Easy-to-Clean Panels, Sturdy Metal Mesh Shelf, Adjustable Feet

Easy-to-Clean Panels

Quality particleboard for effortless cleaning with a simple wipe.



Image 8.1: Detail of the sturdy metal mesh shelf and adjustable feet.

9. WARRANTY AND SUPPORT

Specific warranty information for the YATINEY DS11DBBY1N1 TV Stand is not provided within this manual. For details regarding warranty coverage, returns, or technical support, please refer to the product's purchase documentation or contact the retailer/manufacturer directly.

You may also visit the official YATINEY store for further assistance: [YATINEY Store on Amazon](#)

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question