

hughuyguyk

Generic High Pressure Water Gun with Adjustable Nozzle - User Manual

Model: hughuyguyk

INTRODUCTION

Thank you for choosing the Generic High Pressure Water Gun with Adjustable Nozzle. This manual provides essential information for the safe and efficient use of your new water gun. Please read it thoroughly before operation and retain it for future reference.

SAFETY INSTRUCTIONS

- Always wear appropriate eye protection when operating the water gun.
- Do not point the water gun at people, animals, or electrical outlets.
- Ensure all connections are secure before turning on the water supply to prevent leaks.
- Do not modify the water gun or its components. Use only original parts.
- Keep out of reach of children.
- Avoid using the water gun with hot water or corrosive liquids.

PACKAGE CONTENTS

Verify that all items are present in your package:

- High Pressure Water Gun (x2)
- 1/2-inch Metal Connector (x2)
- Hose Clamp (x2)

Note: This manual refers to the "with 1/2inMetal-Connector 2set" model.

PRODUCT OVERVIEW

The Generic High Pressure Water Gun features a durable construction with brass and stainless steel components, designed for various cleaning and watering tasks. It includes an adjustable nozzle for multiple spray patterns and a comfortable, anti-slip grip.

Multiple Spray Patterns

Adjust the water outlet shape by rotating the nozzle for even water flow & convenient use

Adjustable Multi-Spray Modes
to Meet All Your Needs




Image 1: Overview of the High Pressure Water Gun. This image displays the full length of the water gun, highlighting its black body and brass connector, providing a general view of the product.

HIGH-PRESSURE WATER GUN NOZZLE

Crafting a Practical and Durable Cleaning Tool

01 Adjustable High Pressure, Efficient Cleaning
Simply rotate the nozzle head to switch between direct stream, fan spray, and mist modes

02 All-Brass Connectors, Durable & Leak-Proof
Constructed from thickened brass, offering durable & Leak-Proof

03 Versatile Compatibility, Easy Installation
multiple connector adapters compatible with standard household faucets and garden hoses.

04 Ergonomic Design, Comfortable Grip
Features a non-slip, textured body design that ensures a steady grip, preventing slippage

GAOYASHUI QIANG

Image 2: Key features of the High Pressure Water Gun. This image illustrates the product's high pressure capability, durable and leak-proof design, versatile compatibility with various connectors, and ergonomic grip.

SETUP INSTRUCTIONS

1. Connect the Water Gun to a Hose:

Attach the 1/2-inch metal connector to your garden hose. Ensure the connection is tight to prevent leaks. If using a hose clamp, secure it around the hose and connector for an even tighter seal.




Image 3: Illustration of the water gun's connection point and grip. This image shows the brass connector end of the water gun and a hand holding the anti-slip grip, indicating its length and comfortable design.

2. Attach the Nozzle:

The adjustable nozzle is integrated into the water gun. No separate attachment is required for the nozzle itself.

3. Turn on Water Supply:

Slowly turn on the water supply to your garden hose. Check for any leaks at the connection points. If leaks occur, tighten the connections further.

OPERATING INSTRUCTIONS

1. Adjusting Spray Patterns:

The water gun features a 360° rotatable nozzle. To change the spray pattern, simply rotate the nozzle head. You can switch between various modes:

- **Shower Mode:** Provides fine atomization and an even spray, suitable for gentle watering.
- **Fan Mode:** Offers wide-area coverage with an even spray, ideal for rinsing large surfaces.
- **Jet Mode:** Delivers a high-pressure stream for targeted cleaning of stubborn dirt.

360° Rotatable Adjustable Water Flow

Rotating nozzle adjusts water pattern,
even water output, easy to clean



Image 4: Visual representation of the multiple spray patterns. This image shows the nozzle producing a fine mist (Shower Mode), a wide fan spray (Fan Mode), and a concentrated jet stream (Jet Mode).

REMOVES DIRT WITH EASE

High-pressure cleaning for a cleaner and better life




Image 5: Close-up of the 360° rotatable adjustable water flow nozzle. This image highlights the mechanism for adjusting the spray pattern by rotating the nozzle head.

2. Using the Water Gun:

Once connected and the water supply is on, simply aim the water gun at the desired area and adjust the spray pattern as needed for your task. The ergonomic design and anti-slip grip ensure comfortable handling during extended use.

Your browser does not support the video tag.

Video 1: Demonstration of the High Pressure Water Gun in use. This video shows the water gun being used for various cleaning tasks, including washing a vehicle and watering plants, demonstrating its adjustable spray and effectiveness.

MAINTENANCE

- **Cleaning:** After each use, rinse the water gun with clean water to remove any dirt or debris.
- **Storage:** Store the water gun in a cool, dry place, away from direct sunlight and freezing temperatures.
- **Inspection:** Periodically inspect the connectors and nozzle for any signs of wear or damage. Replace worn parts as necessary.
- **Winterization:** In cold climates, ensure all water is drained from the water gun and hose before storing to prevent

damage from freezing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low water pressure or weak spray.	Insufficient water supply; nozzle partially blocked; hose kinked.	Ensure water tap is fully open. Check nozzle for obstructions and clean if necessary. Straighten any kinks in the hose.
Water leaks from connections.	Loose connections; worn washers/gaskets; incorrect connector size.	Tighten all connections. Inspect and replace any damaged washers or gaskets. Ensure you are using the correct 1/2-inch connector for your hose.
Nozzle difficult to rotate.	Mineral buildup or dirt in the nozzle mechanism.	Rinse the nozzle thoroughly with clean water. If necessary, soak the nozzle head in a descaling solution to remove mineral deposits.

SPECIFICATIONS

Feature	Detail
Model Number	hughuyguyk
Material	Brass, Stainless Steel
Item Dimensions (L x W x H)	3 x 2 x 4 inches (approximate for gun body)
Connector Type	Threaded
Thread Size	1/2 inch
Valve Type	Adjustable Valve
Number of Pieces (for this set)	2 (water guns and connectors)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer's return policy or contact the seller directly through the platform where the product was purchased. Keep your purchase receipt as proof of purchase.