

[Manuals.plus](#) /

› [DUMOS](#) /

› DUMOS 23.6" Bakers Rack with Power Outlet Instruction Manual

DUMOS DU-FK-HBJ6230-23D6GY-DJ

DUMOS 23.6" Bakers Rack with Power Outlet Instruction Manual

Model: DU-FK-HBJ6230-23D6GY-DJ

1. INTRODUCTION

Thank you for choosing the DUMOS 23.6" Bakers Rack with Power Outlet. This versatile storage unit is designed to enhance your kitchen organization, providing dedicated space for appliances, cookware, and other essentials. It features a built-in power outlet for convenience, adjustable shelving for flexible storage, and a robust construction for stability. This manual provides detailed instructions for safe assembly, proper operation, and effective maintenance to ensure long-lasting use of your product.



Image: The DUMOS 23.6" Bakers Rack in Classic Grey, showcasing its multi-tiered design and integrated power outlet.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembling or using this product. Failure to follow these instructions may result in injury or damage to the product.

- **Assembly:** Ensure all parts are present and undamaged before assembly. Do not use power tools for assembly unless specifically instructed, as this may overtighten screws and damage components.
- **Weight Capacity:** Do not exceed the maximum weight capacity for each shelf. Refer to the Specifications section for details. Distribute weight evenly.
- **Stability:** Always install the anti-tip kit provided to prevent the rack from tipping over, especially in households with children or pets. Place the rack on a flat, stable surface.
- **Electrical Safety:** The built-in power outlet is rated for 120V/15A with a maximum power of 1875 Watts. Do not overload the outlets. Do not use damaged power cords or plugs. Keep liquids away from the power strip.
- **Maintenance:** Regularly check all screws and connections to ensure they remain tight.

3. PACKAGE CONTENTS

Verify that all components are included in your package before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- Wooden Shelves (3 or 4, depending on configuration)
- Built-in Power Strip with 3 AC Outlets and 6.5ft Power Cord
- Side Mesh Storage Racks (2)
- Adjustable Feet (4)
- Anti-Tip Kit
- Assembly Hardware (screws, wrench, etc.)
- Instruction Manual



Image: The DUMOS Bakers Rack demonstrating its multi-tiered layout for versatile storage of microwave, kettle, air fryer, coffee maker, plates, bread, spice bottles, and tableware.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your DUMOS Bakers Rack. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. **Unpack and Identify Parts:** Lay out all components and hardware. Compare them with the package contents list to ensure everything is present.
2. **Assemble the Frame:** Connect the metal frame components using the provided screws and tools. Do not fully tighten screws until all parts are loosely assembled.
3. **Attach Shelves:** Slide the wooden shelves into the designated slots on the frame. The middle shelf is adjustable; choose your desired height before fully tightening.
4. **Install Side Mesh Racks:** Attach the side mesh storage racks to the frame as shown in the diagrams.
5. **Install Power Strip:** Secure the built-in power strip to the designated area on the back panel of the rack. Ensure the power cord is routed safely.
6. **Attach Adjustable Feet:** Screw the four adjustable feet into the bottom of the frame. Adjust them to level the rack on uneven floors.
7. **Secure Anti-Tip Kit:** Attach the anti-tip kit to the top rear of the rack and secure it to a wall stud using appropriate hardware. This is a critical safety step.
8. **Final Tightening:** Once all components are in place and the rack is level, fully tighten all screws.

Video: Official DUMOS Kitchen Bakers Rack Assembly Guide. This video provides a visual walkthrough of the assembly process.

Detachable & Adjustable Shelves

resize the shelves to match your storage needs



Features a middle shelf in the lower section with 2 height adjustments, perfect for organizing items of varying heights




Image: The DUMOS Bakers Rack with a visual representation of its detachable and adjustable shelves, allowing for customization of storage space.



Sturdy Wood with Texture

More Load-bearing, More Stable

Anti-tip Device

Stay safe with anti-tipping protection

Side Mesh Storage Rack

Easy Access to Frequently Used Items and Save Space

4 Adjustable Feet

Stay secure with adjustable feet

Image: Close-up details of the DUMOS Bakers Rack, highlighting the sturdy wood texture, the anti-tip device for safety, the convenient side mesh storage rack, and the adjustable feet for stability.

5. OPERATING INSTRUCTIONS

The DUMOS Bakers Rack is designed for straightforward use, focusing on convenience and organization.

5.1 Using the Built-in Power Outlet

- **Connect to Power:** Plug the rack's 6.5ft power cord into a standard 120V wall outlet.
- **Power On/Off:** Use the red on/off switch located on the power strip to control power to the 3 AC outlets. Flip the switch to 'ON' to provide power to your appliances.
- **Appliance Connection:** Plug your kitchen appliances (e.g., coffee maker, toaster, microwave) directly into the 3 AC outlets. Ensure the total wattage of connected devices does not exceed 1875 Watts.

Built-in Power Outlet

stay charged with safety



3 AC Outlets-
120V/15A



Max. Power-
1875 Watts



1 on-off Switch-
Ensure Safety



Extension Power
Cord-6.5 Ft (2 m)



Image: A detailed view of the built-in power outlet, showing the 3 AC outlets, the on/off switch, and the 6.5 ft extension power cord, emphasizing safety and convenience.

5.2 Adjusting Shelves

The middle shelf of the DUMOS Bakers Rack is adjustable to accommodate items of varying heights.

- **To Adjust:** Loosen the screws securing the middle shelf. Carefully lift and reposition the shelf to the desired height, aligning it with the pre-drilled holes in the frame.
- **Secure:** Once the shelf is at the desired height, re-tighten all screws firmly to ensure stability.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your bakers rack.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.

- **Dusting:** Regularly dust the shelves and frame to prevent buildup.
- **Hardware Check:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Power Cord Inspection:** Inspect the power cord and plug for any signs of damage. If damaged, discontinue use and contact customer support.

7. TROUBLESHOOTING

If you encounter any issues with your DUMOS Bakers Rack, refer to the following common problems and solutions:

- **Rack is Wobbly:**
 - Ensure all assembly screws are fully tightened.
 - Adjust the leveling feet at the bottom of the rack to compensate for uneven flooring.
 - Verify the rack is placed on a flat, stable surface.
- **Power Outlet Not Working:**
 - Check if the rack's main power cord is securely plugged into a functional wall outlet.
 - Ensure the red on/off switch on the power strip is in the 'ON' position.
 - Test the wall outlet with another appliance to confirm it has power.
 - Do not exceed the maximum wattage of 1875W. Unplug some devices if overloaded.
- **Missing or Damaged Parts:**
 - If you received missing or damaged parts, please contact DUMOS customer support immediately for assistance.

8. SPECIFICATIONS

Key specifications for the DUMOS 23.6" Bakers Rack with Power Outlet:

Feature	Detail
Model Name	Kitchen Bakers Rack with Power Outlet
Model Number	DU-FK-HBJ6230-23D6GY-DJ
Product Dimensions (D x W x H)	15.75"D x 23.6"W x 52.36"H
Material	Alloy Steel, Engineered Wood
Color	Classic Grey
Number of Shelves	4 (including top surface)
Power Outlet	3 AC Outlets, 120V/15A
Max Power Output	1875 Watts
Power Cord Length	6.5 ft
Item Weight	25.1 Pounds

Feature	Detail
Special Features	Adjustable Middle Shelf, Heavy Duty, Space Saving, Anti-Tip Kit, Adjustable Feet

Product Size

Designed with flexibility—Easily adjust the shelf size to fit your unique kitchen storage needs.




Image: Detailed product size diagram with measurements for height (51.8"), width (23.6"), and depth (15.7"), along with internal shelf dimensions.

9. WARRANTY AND SUPPORT

DUMOS is committed to providing high-quality products. For specific warranty information, please refer to the documentation included with your purchase or visit the official DUMOS brand store.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact DUMOS customer support:

- **Online Support:** Visit the [DUMOS Brand Store on Amazon](#) for FAQs and contact options.

© 2026 DUMOS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GYPFRHQB>

More documents and user manuals: <https://manuals.plus/>