Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JALL CH-12

JALL Digital Calendar Clock Model CH-12 User Manual

Your guide to setting up and operating your JALL Digital Calendar Clock.

1. Introduction

Thank you for choosing the JALL Digital Calendar Clock, Model CH-12. This clock is designed to clearly display the time, day, date, month, and year, making it ideal for individuals who benefit from easy-to-read displays and helpful reminders. This manual provides detailed instructions to help you set up, operate, and maintain your new clock.

2. Product Overview

2.1 Display Features

The JALL Digital Calendar Clock features a 7-inch high-resolution IPS display, providing clear and vivid colors with wide viewing angles. The time, day, date, month, and year are shown in large, bold letters and numbers for enhanced readability.



Image 2.1.1: The 7-inch display of the JALL Digital Calendar Clock, showing its dimensions and clear time/date presentation.



Image 2.1.2: The clock displaying large, bold letters and numbers for easy readability from a distance.

2.2 Key Features

- **Automatic Brightness Adjustment:** The display automatically adjusts its brightness based on ambient light conditions (day/night).
- **Daily Alarms and Reminders:** Set multiple alarms for various daily activities such as medication, appointments, exercises, or meal times.
- **Hourly Chime:** An optional feature that announces the time every hour.
- **Memory Function:** All settings are saved automatically and retained even after a power outage.
- **Remote Control:** For convenient adjustment of settings.



Image 2.2.1: Illustration of the clock's memory function, retaining settings even after power interruptions.

3. Setup

1. **Unpack:** Carefully remove the clock and all accessories from the packaging.

2. **Power Connection:** Plug the provided power adapter into the DC input port on the back of the clock. Then, plug the adapter into a standard electrical wall outlet.
3. **Initial Power On:** The clock will automatically power on and display the default time and date.



Image 3.1: The clock connected to power and being operated with its remote control.

4. Operating Instructions

All settings are adjusted using the included remote control.




Image 4.1: The remote control and the clock's user-friendly settings interface.

4.1 Setting Time and Date

1. Press the **MENU** button on the remote control to access the settings.
2. Use the arrow buttons (▲/▼) to navigate to**Set Date**, **Time Mode**, or **Date Mode**.
3. Press **OK** to select an option.
4. Use the arrow buttons (◄/►) and number buttons (if available) to adjust the values.
5. Press **OK** to confirm your selection.
6. Repeat for all necessary time and date settings.

4.2 Setting Alarms and Reminders

The clock supports multiple daily alarms for various reminders.

1. From the main menu, navigate to**Alarms**.
2. Select an alarm slot (e.g., Alarm 1, Alarm 2).
3. Set the desired time for the alarm.
4. Choose the alarm type or message (e.g., Medicine, Clinic, Exercise, Afternoon Tea).

5. Enable or disable the alarm.
6. Press **OK** to save.



Image 4.2.1: Examples of daily alarms and reminders that can be set on the clock.



Image 4.2.2: The clock assisting with various daily routines through its reminder functions.

4.3 Adjusting Brightness

The clock features automatic brightness adjustment. You can also manually adjust it if desired.

1. Navigate to **Auto Dimming** in the settings menu.
2. Select **On** for automatic adjustment or **Off** for manual control.
3. If **Off**, you may find options to set specific brightness levels for day and night.



Image 4.3.1: The clock's display automatically adjusting brightness for day and night viewing.

4.4 Language Settings

1. Navigate to **Language** in the settings menu.
2. Use the arrow buttons to select your preferred language.
3. Press **OK** to confirm.

4.5 Hourly Chime

The hourly chime feature provides an audible announcement of the time every hour.

1. Navigate to **Hourly Chime** in the settings menu.
2. Select **On** to enable or **Off** to disable.
3. Press **OK** to confirm.



Image 4.5.1: The hourly chime feature providing gentle time announcements.



Image 4.5.2: The hourly chime feature is beneficial for individuals with impaired vision.

4.6 Color Mode

The clock may offer different display color modes (e.g., white or yellow text).

1. Navigate to **Color Mode** in the settings menu.
2. Use the arrow buttons to cycle through available color options.
3. Press **OK** to confirm your selection.

5. Maintenance

- **Cleaning:** To clean the display and casing, gently wipe with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or spray directly onto the clock.
- **Power:** Ensure the clock remains plugged into a stable power source for continuous operation.
- **Placement:** Place the clock on a stable, flat surface away from direct sunlight, extreme temperatures, and high humidity.

6. Troubleshooting

Problem	Possible Cause	Solution
Clock does not turn on.	No power supply.	Check if the power adapter is securely plugged into the clock and the wall outlet. Try a different outlet.
Display is too dim or too bright.	Brightness settings are incorrect or automatic dimming is not optimal for environment.	Adjust the brightness settings in the menu. Ensure 'Auto Dimming' is set appropriately for your preference.
Alarms are not sounding.	Alarm is disabled or volume is too low.	Check alarm settings to ensure it is enabled and the time is correct. Verify volume settings if applicable.
Remote control is not working.	Batteries are dead or remote is not aimed correctly.	Replace remote control batteries. Ensure there are no obstructions between the remote and the clock's sensor.

7. Specifications

Feature	Detail
Brand	JALL

Feature	Detail
Model Number	CH-12
Screen Size	7 inches
Product Dimensions (W x H)	7.87"W x 7.09"H
Item Weight	245 g
Color	White
Power Source	AC Adapter (Plug-in)



Image 7.1: Detailed dimensions of the JALL Digital Calendar Clock.

8. Warranty and Support

Your JALL Digital Calendar Clock is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact JALL customer service through the retailer where the product was purchased or visit the official JALL website for contact information.

© 2026 JALL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GYR2PCV8

More documents and user manuals: **https://manuals.plus/**