XIAOWTEK S58

XIAOWTEK S58 Wireless Earbuds User Manual

Model: S58

1. Product Overview

The XIAOWTEK S58 Wireless Earbuds offer a high-quality audio experience with advanced features such as Bluetooth 5.4 connectivity, active noise-cancelling microphone, and a convenient LED power display. Designed for comfort and durability, these earbuds are suitable for various activities and compatible with a wide range of devices.



Image: XIAOWTEK S58 Wireless Earbuds and charging case.

Key Features:

- **Bluetooth 5.4:** Ensures stable and efficient wireless connection.
- **Active Noise Cancelling Mic:** Provides clear calls by reducing background noise.
- **LED Power Display:** Shows battery levels for both the charging case and individual earbuds.
- **Up to 60 Hours Playback:** Extended listening time with the charging case.
- **IP7 Waterproof:** Designed to withstand water splashes and sweat.
- **Smart Touch Control:** Intuitive controls for music, calls, and voice assistant.
- **HiFi Stereo Sound:** Equipped with 13.4MM advanced drivers for powerful deep bass and crisp treble.

2. What's in the Box

Please check the package contents to ensure all items are present:

- XIAOWTEK S58 Wireless Earbuds (L/R)
- Charging Case
- Type-C Charging Cable
- User Manual (this document)



Image: The package contents including earbuds, charging case, Type-C cable, and user manual.

3. Setup

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated; the LED indicators on the earbuds will light up to confirm charging.
2. Connect the Type-C charging cable to the charging port on the case and plug the other end into a USB power adapter (not included).
3. The digital LED display on the charging case will show the current battery percentage of the case and individual earbud battery levels. The display will flash from 1 to 100 during charging.
4. Once fully charged, the LED display will show 100, and the earbud indicators will turn off.




Image: The charging case with an LED display indicating battery percentages for the case and both earbuds.

Your browser does not support the video tag.

Video: Demonstrates the XIAOWTEK S58 Wireless Earbuds, including their design and how they fit into the charging case. This video highlights the product's physical attributes and initial handling.

3.2 Pairing with Your Device

The earbuds support one-step auto-pairing for convenience.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. Enable Bluetooth on your device (smartphone, tablet, laptop).
3. Search for "S58" in the list of available Bluetooth devices.
4. Select "S58" to connect. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. After the initial pairing, the earbuds will automatically connect to the last paired device when taken out of the case.



Image: A visual representation of the one-step auto-pairing process for the earbuds with a device, highlighting Bluetooth 5.4 technology.

4. Operating Instructions

4.1 Wearing the Earbuds

Gently insert the earbuds into your ears, ensuring a comfortable and secure fit. Adjust them slightly until the sound is clear

and the fit is snug to optimize audio quality and noise isolation.

4.2 Touch Controls

The S58 earbuds feature intuitive touch controls on each earbud. The functions vary slightly between the left (L) and right (R) earbuds.




Image: Detailed diagram illustrating the touch control functions for both the left and right earbuds, including short press and press and hold actions.

Earbud Touch Control Functions

Action	Left Earbud (L)	Right Earbud (R)
Single Tap	Increase Volume	Decrease Volume
Double Tap	Play/Pause Music, Answer/End Call	
Triple Tap	Activate Voice Control (Siri/Google Assistant)	
Press and Hold (2 seconds)	Next Track, Reject Incoming Call	Previous Track, Reject Incoming Call

4.3 Single or Dual Earbud Mode

You can use either earbud independently or both together. Simply take one or both earbuds out of the charging case, and they will automatically connect to your device (if previously paired).




Image: Illustration demonstrating the flexibility of using either a single earbud or both earbuds simultaneously.

5. Maintenance

5.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Ensure charging contacts on both earbuds and the case are clean and free of debris to maintain proper charging.

5.2 Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place, away from extreme temperatures and direct sunlight.

5.3 Water Resistance

The earbuds are rated IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. This makes them suitable for workouts and light rain. However, they are not designed for swimming or prolonged submersion. Ensure the earbuds are dry before placing them back into the charging case to prevent damage.

6. Troubleshooting

- **Earbuds not pairing with device:**
  - Ensure earbuds are charged and out of the case.
  - Turn off and on your device's Bluetooth.
  - Forget "S58" from your device's Bluetooth list and try pairing again.
  - Restart your device.
- **Only one earbud working:**
  - Place both earbuds back into the charging case, close the lid, then open it again and take them out simultaneously.
  - Ensure both earbuds are charged.
- **Poor sound quality:**

- Ensure earbuds are clean and free of earwax or debris.
- Check the connection distance; move closer to your device.
- Ensure there are no obstructions between the earbuds and your device.

- **Earbuds not charging:**
  - Ensure the charging cable is securely connected to both the case and the power source.
  - Verify the charging contacts on the earbuds and inside the case are clean.
  - Try a different charging cable or power adapter.

7. Specifications

Feature	Detail
Brand	XIAOWTEK
Model Number	S58
Bluetooth Version	5.4
Bluetooth Range	Up to 15 meters (49 feet)
Earbud Battery Life	Up to 6 hours (per charge)
Total Playback Time	Up to 60 hours (with charging case)
Charging Port	USB Type-C
Water Resistance	IP7 Waterproof
Noise Control	Active Noise Cancellation (for mic)
Audio Driver Type	Dynamic Driver (13.4mm)
Control Method	Touch
Ear Placement	In Ear

8. Warranty and Support

8.1 Manufacturer's Warranty

The XIAOWTEK S58 Wireless Earbuds come with a**1-Year Manufacturer's Warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product is free from defects in material and workmanship under normal use.

The warranty does not cover:

- Damage caused by accident, abuse, misuse, flood, fire, earthquake, or other external causes.
- Damage caused by operating the product outside the permitted or intended uses described by XIAOWTEK.
- Damage caused by service performed by anyone who is not a representative of XIAOWTEK.
- Products or parts that have been modified to alter functionality or capability without the written permission of XIAOWTEK.

8.2 Customer Support

For technical support, warranty claims, or any questions regarding your XIAOWTEK S58 Wireless Earbuds, please contact our customer service team. Refer to the contact information provided on the product packaging or the official XIAOWTEK website.

© 2026 XIAOWTEK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question