Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Uliptz WH203A

Uliptz Wireless Bluetooth Headphones WH203A User Manual

Model: WH203A

1. Introduction

Thank you for choosing the Uliptz Wireless Bluetooth Headphones WH203A. These over-ear headphones are designed to provide a high-fidelity audio experience with advanced Bluetooth 6.0 technology, extended playtime, and comfortable design. This manual will guide you through the setup, operation, and maintenance of your new headphones.



Image: Exploded view of the Uliptz headphone driver, illustrating the components responsible for high-fidelity sound quality.

2. Package Contents

Please check the package for the following items:

- Uliptz Wireless Bluetooth Headphones WH203A
- USB Type-C Charging Cable
- 3.5mm Audio Cable
- User Manual (this document)

3. Product Overview

Familiarize yourself with the various parts and controls of your Uliptz headphones.



Image: Detailed view of the right earcup, highlighting the Volume Up/Next Track button, Multi-Function Button, Volume Down/Previous Track button, Type-C Charging Interface, LED Indicator, 3.5mm Audio Interface, and EQ Button.

Volume Up / **Next Track Button:** Press briefly to increase volume, press and hold to skip to the next track.

Multi-Function Button (MFB): Power On/Off, Play/Pause, Answer/End Call, Activate Voice Assistant.

Volume Down / **Previous Track Button:** Press briefly to decrease volume, press and hold to go to the previous track.

Type-C Charging Interface: For charging the headphones.

LED Indicator: Displays power, pairing, and charging status.

3.5mm Audio Interface: For wired connection.

EQ Button: Cycles through 6 different equalizer sound modes.

Microphone: Built-in for hands-free calls (works in wireless mode only).



Image: Close-up views of the headphone's design features, including comfortable memory foam earcups, an adjustable metal slider headband, a foldable design for portability, and a durable, non-breakable headband.

4. Charging the Headphones

Before first use, fully charge your headphones.

1. Connect the provided USB Type-C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show the charging status (e.g., red for charging, blue for fully charged).

A full charge takes approximately 2.5 hours and provides up to 65 hours of playtime. A quick 10-minute charge can provide up to 4 hours of playtime.



Image: A person wearing the Uliptz headphones, illustrating comfortable use during leisure, with text highlighting the "65 Hours Super-Long Playtime" and "10 Min = 4 Hrs" quick charge capability.

5. Setup and Pairing

5.1 Bluetooth Pairing

To connect your headphones wirelessly to a device:

1. Ensure the headphones are charged.
2. Press and hold the Multi-Function Button (MFB) for approximately 3-5 seconds until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "Uliptz WH203A" from the list of found devices.
5. Once connected, the LED indicator will slowly flash blue.

The headphones support Bluetooth 6.0 technology, offering a stable connection up to 10 meters. They can also be paired

with two devices simultaneously, allowing seamless switching between them.



Image: The Uliptz headphones displayed with a prominent "V6.0 Bluetooth" graphic, indicating the advanced Bluetooth version for stable and fast wireless connectivity.

5.2 Wired Connection

To use the headphones in wired mode:

1. Connect one end of the provided 3.5mm audio cable to the 3.5mm audio interface on the headphones.
2. Connect the other end to the 3.5mm audio jack of your device.

Note: The built-in microphone only functions in wireless (Bluetooth) mode.

6. Operating Instructions

6.1 Power On/Off

- **Power On:** Press and hold the MFB for 3 seconds. The LED indicator will flash blue.

- **Power Off:** Press and hold the MFB for 3 seconds. The LED indicator will turn off.

6.2 Music Playback

- **Play/Pause:** Press the MFB once.
- **Volume Up:** Press the "Volume Up / Next Track" button briefly.
- **Volume Down:** Press the "Volume Down / Previous Track" button briefly.
- **Next Track:** Press and hold the "Volume Up / Next Track" button.
- **Previous Track:** Press and hold the "Volume Down / Previous Track" button.

6.3 EQ Sound Modes

The headphones feature 6 EQ sound modes to optimize your listening experience for different music genres.

- **Change EQ Mode:** Press the EQ button to cycle through the available sound modes.

6.4 Phone Calls

- **Answer/End Call:** Press the MFB once.
- **Reject Call:** Press and hold the MFB for 2 seconds.
- **Redial Last Number:** Double-press the MFB.

6.5 Voice Assistant

- **Activate Voice Assistant:** Triple-press the MFB to activate your device's voice assistant (e.g., Siri, Google Assistant).



Image: Collage showing individuals using the Uliptz headphones in different environments, including an office setting, during travel, and while exercising at a gym, demonstrating their versatility.

7. Maintenance and Care

- Keep the headphones dry. Do not expose them to extreme temperatures or humidity.
- Clean the earcups and headband with a soft, dry cloth. Do not use abrasive cleaners.
- Store the headphones in a clean, dry place when not in use. The foldable design allows for compact storage.
- Avoid dropping or subjecting the headphones to strong impacts.

8. Troubleshooting

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged.

Problem	Solution
Cannot pair with device.	• Ensure headphones are in pairing mode (LED flashing blue/red). • Turn off and on Bluetooth on your device. • Clear previous Bluetooth connections on your device. • Move headphones closer to the device (within 10 meters).
No sound or low volume.	• Adjust volume on both headphones and connected device. • Ensure headphones are properly connected via Bluetooth or 3.5mm cable. • Check if the audio source is playing.
Microphone not working.	• Ensure headphones are in wireless (Bluetooth) mode. The microphone does not work in wired mode. • Check microphone settings on your connected device.
Sound quality issues.	• Try switching between the 6 EQ sound modes. • Ensure there are no obstructions between the headphones and the connected device. • If using wired mode, ensure the 3.5mm cable is fully inserted.

9. Specifications

Feature	Detail
Model Number	WH203A
Bluetooth Version	6.0
Bluetooth Range	Up to 10 meters
Audio Driver Size	40 mm
Impedance	32 Ohms
Frequency Response	20 Hz - 20 KHz
Sensitivity	122 dB
Battery Life (Playtime)	Up to 65 hours
Battery Charge Time	Approx. 2.5 hours
Quick Charge	10 minutes for 4 hours playtime
Charging Interface	USB Type-C
Audio Input	Bluetooth, 3.5mm Audio Jack
Microphone	Built-in (wireless mode only)
Weight	180 Grams
Noise Control	Passive Noise Cancellation

Feature	Detail
Features	Adjustable Headband, Built-In Voice Assistant, Detachable Cable, Foldable, Lightweight, 6 EQ Sound Modes

10. Warranty and Support

Uliptz products are designed for reliability and performance. For warranty information or technical support, please refer to the warranty card included in your package or visit the official Uliptz website.
If you encounter any issues not covered in this manual, please contact Uliptz customer service for assistance.

© 2026 Uliptz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GYS711MC

More documents and user manuals: **https://manuals.plus/**