Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

IDEALHOUSE eZ-WBO9nrYt3ErV-QJcue-MEczJL

IDEALHOUSE Arched Bookcase with Drawer Instruction Manual

Model: eZ-WBO9nrYt3ErV-QJcue-MEczJL | Brand: IDEALHOUSE

1. Introduction

Thank you for choosing the IDEALHOUSE Arched Bookcase with Drawer. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

2. Safety Information

Important: Failure to follow these safety instructions may result in injury or damage to the product.

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are securely fastened before use. Periodically check and tighten all connections.
- Do not overload shelves. Distribute weight evenly.
- This bookcase is equipped with an anti-tipping device. It is crucial to install this device to prevent the unit from tipping over, especially in households with children or pets.
- Keep small parts and packaging materials away from children.



Image: Close-up view of the anti-tipping device bracket, which must be securely installed to a wall stud to prevent the bookcase from tipping.

3. Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Bookcase panels (sides, shelves, back)
- Drawer components
- Hardware kit (screws, dowels, cam locks, drawer slides, anti-tipping device)
- Assembly instructions (this manual)

4. Setup and Assembly

Assembly typically requires two adults. Please follow the step-by-step diagrams provided in the separate assembly guide included with your hardware kit. A Phillips head screwdriver and a hammer may be required (not included).

Key Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface. Refer to the parts list in your assembly guide to identify each piece.
2. **Assemble Frame:** Connect the side panels to the base and top arch using the provided hardware. Ensure all connections are snug.
3. **Install Shelves:** Insert the fixed shelves into the designated slots.
4. **Assemble Drawer:** Follow the specific instructions for assembling the drawer box and installing the drawer slides.
5. **Install Drawer into Bookcase:** Carefully slide the assembled drawer into its compartment.
6. **Attach Back Panel:** Secure the back panel to the bookcase frame.
7. **Install Anti-Tipping Device:** This is a critical safety step. Securely attach the anti-tipping bracket to the top rear of the bookcase and then to a wall stud using the provided hardware.




Image: A collage highlighting key features including the anti-tipping device, metal door handles, sturdy base, and the elegant arched design, all crucial for proper setup and function.

5. Operating Instructions (Usage)

The IDEALHOUSE Arched Bookcase is designed for versatile storage and display.

- **Open Shelves:** Utilize the five open shelves for books, decorative items, plants, or small appliances. Distribute items evenly to maintain stability.
- **Storage Drawer:** The integrated drawer provides concealed storage for items you wish to keep out of sight, contributing to a tidy appearance.
- **Placement:** Position the bookcase on a level surface. Ensure it is not placed in areas of high humidity or direct sunlight to prevent material degradation.



Image: The bookcase displayed in a kitchen, showcasing its use for storing kitchenware, small appliances, and decorative items on its open shelves and within the drawer.



Image: A detailed view of the spacious drawer, illustrating its capacity for storing various household items, such as coffee beans and snacks in jars.

6. Maintenance

Proper care will extend the life and appearance of your bookcase.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.

7. Troubleshooting

If you encounter any issues with your bookcase, refer to the following common solutions:

Problem	Possible Cause	Solution
Bookcase is wobbly	Loose hardware; uneven floor	Tighten all screws. Ensure the bookcase is on a level surface; use shims if necessary. Verify anti-tipping device is installed correctly.
Drawer does not slide smoothly	Improperly installed drawer slides; obstruction	Check that drawer slides are aligned and installed correctly. Remove any obstructions from the drawer tracks.
Scratches on surface	Rough handling; abrasive cleaning	Use furniture polish or touch-up pens for minor scratches. Avoid placing sharp objects directly on surfaces.

8. Specifications

- **Model:** eZ-WBO9nrYt3ErV-QJcue-MEczJL
- **Brand:** IDEALHOUSE
- **Material:** Engineered Wood
- **Color:** Natural Wood Color
- **Product Dimensions (D x W x H):** 29.92" x 11.81" x 71.65"
- **Item Weight:** 80.6 pounds
- **Number of Shelves:** 6 (5 open, 1 within drawer compartment)
- **Number of Drawers:** 1
- **Special Feature:** Anti-Tipping Device
- **Mounting Type:** Floor Mount



Image: A technical diagram illustrating the precise dimensions of the bookcase, including overall height, width, depth, and individual shelf heights.

9. Customer Support

For further assistance, missing parts, or warranty inquiries, please contact IDEALHOUSE customer support through the retailer where the product was purchased. Please have your model number (eZ-WBO9nrYt3ErV-QJcue-MEczJL) and purchase date available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GYZBGWB7

More documents and user manuals: **https://manuals.plus/**