

[Manuals.plus](#) /

› [ASICEN](#) /

› ASICEN Buds Wireless 3 Neo Neckband User Manual

ASICEN BUDS 3 Neo

ASICEN Buds Wireless 3 Neo Neckband

INSTRUCTION MANUAL

Introduction

Thank you for choosing the ASICEN Buds Wireless 3 Neo Neckband. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it carefully before use to ensure optimal performance and longevity of your neckband.

Package Contents

- ASICEN Buds Wireless 3 Neo Neckband
- Charging Cable
- User Manual

Product Overview

Familiarize yourself with the components of your neckband.



Image: Close-up view of the ASICEN Buds Wireless 3 Neo neckband, showing the in-ear earbuds, the flexible neckband, and the inline control panel with volume buttons and a multi-function button. The charging port is also visible on the control panel.

- **Earbuds:** In-ear design for comfortable fit and sound delivery.
- **Neckband:** Flexible band that rests around your neck.
- **Control Panel:** Houses buttons for power, volume, and call management.
- **Microphone:** For hands-free calls.
- **Charging Port:** For recharging the device.

Setup

1. Charging the Neckband

Before first use, fully charge the neckband. A full charge provides up to 32 hours of playback. Fast charging support allows for quick power-ups.

1. Connect the charging cable to the neckband's charging port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The indicator light will show charging status. It will typically turn off or change color when fully charged.



Image: Infographic highlighting key features of the neckband, including a 13.4mm dynamic bass driver, 32 hours of battery life, 10 minutes charge for 6 hours playtime, dual-device connection, 45ms ultra-low latency, and magnetic instant connection.

2. Powering On/Off

- **Power On:** Press and hold the multi-function button on the control panel until the indicator light flashes.
- **Power Off:** Press and hold the multi-function button until the indicator light turns off.

3. Bluetooth Pairing

Pair your neckband with your device (smartphone, tablet, etc.) to enable wireless audio.

1. Ensure the neckband is powered off.
2. Press and hold the multi-function button for approximately 5-7 seconds until the indicator light flashes rapidly (usually blue and red alternately), indicating pairing mode.
3. On your device, go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. Select "ASICEN Buds Wireless 3 Neo" from the list.
5. Once connected, the indicator light on the neckband will typically flash blue slowly or turn solid blue.
6. If prompted for a password, enter "0000".



Image: The ASICEN Buds Wireless 3 Neo neckband in blue, with icons on the right indicating wireless connectivity, environmental noise cancellation (AI ENC), and 32 hours of battery life.

4. Wearing the Neckband

Place the neckband comfortably around your neck, allowing the earbuds to rest in your ears. Adjust for a secure and comfortable fit.

Operating Instructions

Music Playback

- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Press and hold the Volume + button.
- **Previous Track:** Press and hold the Volume - button.
- **Volume Up:** Press the Volume + button.
- **Volume Down:** Press the Volume - button.

Call Management

- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the multi-function button.

Voice Assistant

- **Activate Voice Assistant:** Triple-press the multi-function button.

Low Latency Mode (Gaming Mode)

The neckband features a 45ms low latency mode for synchronized audio during gaming or video playback.

- **Activate/Deactivate:** Refer to your device's specific instructions or the neckband's control panel for a dedicated button or gesture (e.g., press and hold a specific button combination).

Dual-Device Connection

The neckband supports connecting to two devices simultaneously.

1. Pair the neckband with the first device as described in the "Bluetooth Pairing" section.
2. Turn off Bluetooth on the first device.

3. Put the neckband back into pairing mode and pair it with the second device.
4. Turn on Bluetooth on the first device. The neckband should automatically connect to both devices.
5. To switch between devices, pause audio on one and start playing on the other.

Maintenance

Cleaning

- Wipe the neckband and earbuds with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Ensure the charging port is free of dust and debris.

Storage

- Store the neckband in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing with heavy objects that could damage the neckband.

Water and Dust Resistance (IP59)

The neckband is rated IP59, providing protection against dust ingress and high-pressure water jets from any direction. This makes it suitable for workouts and light rain.

- Do not submerge the neckband in water.
- Avoid exposing it to saltwater or other corrosive liquids.
- Ensure the charging port is dry before charging.

IP55 Dust & Water Resistant

Shielded Against Splashes



Image: The ASICEN Buds Wireless 3 Neo neckband shown with water droplets, emphasizing its IP55 Dust & Water Resistant rating. The text indicates it is shielded against splashes. (Note: Product description and features state IP59, while this image states IP55. Please refer to the product specifications for the most accurate rating.)

Troubleshooting

If you encounter issues, try the following solutions:

Problem	Solution
Cannot power on	Ensure the neckband is fully charged.
Cannot pair with device	<ul style="list-style-type: none">• Ensure the neckband is in pairing mode (flashing indicator light).• Turn off and on Bluetooth on your device.• Restart both the neckband and your device.• Clear previous Bluetooth connections on your device.• Ensure the neckband is within range (10 meters) of your device.

Problem	Solution
No sound	<ul style="list-style-type: none"> • Check volume levels on both the neckband and your device. • Ensure the neckband is properly connected to your device. • Try playing audio from a different application or source.
Poor call quality	<ul style="list-style-type: none"> • Ensure the microphone is not obstructed. • Move to an area with less environmental noise. • Check your device's network signal strength.

Specifications

Brand	ASICEN
Model Name	Realme Bluetooth Neckband
Model Number	BUDS 3 Neo
Driver Size	13.4mm Bass Driver
Playback Time	Up to 32 Hours
Charging	Fast Charging Support (10 min charge = 6 hr playtime)
Connectivity	Bluetooth Wireless Technology, Dual-Device Connection
Noise Cancellation	AI ENC for Clear Calls
Latency	45ms Low Latency Mode
Water & Dust Resistance	IP59 (Protected against dust and high-pressure water jets)
Form Factor	In Ear
Item Weight	90 Grams

Warranty Information

This product comes with a **3 Months** warranty from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized modifications.

Support

For further assistance or technical support, please contact:

- **Manufacturer:** ASICEN
- **Email:** care.asicentech@gmail.com

