Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LAUSAINT HOME GZCT010-009-GR4-V2-OS-0505

LAUSAINT HOME 8'x8' Outdoor Gazebo Instruction Manual

Model: GZCT010-009-GR4-V2-OS-0505

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your LAUSAINT HOME 8'x8' Outdoor Gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and safe use of your gazebo.

Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always secure the gazebo with ground stakes or expansion bolts to prevent wind damage.
- Remove the canopy, curtains, and netting during severe weather conditions such as strong winds, heavy rain, storms, or snow to prevent damage and extend product lifespan.
- Do not use open flames or heating appliances inside the gazebo.
- Keep children and pets away from the assembly area during installation.
- Ensure all connections are tight and secure before use.
- Periodically check all bolts and connections for tightness and re-tighten as necessary.
- This gazebo is designed for outdoor use only.
- Assembly requires at least two adults.

Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

Part	Description	Quantity
Frame Components	Galvanized steel poles, connectors, and roof supports.	Varies by model

Part	Description	Quantity
Canopy Fabric	Water-resistant and UV-protected polyester fabric for main roof and upper vent.	2 (Main, Vent)
Mosquito Netting	Zippered mesh netting for insect protection.	4 panels
Privacy Curtains	Waterproof fabric panels for privacy and additional shade.	4 panels
Hardware Kit	Includes 12pcs expansion bolts, 12pcs stakes, 4pcs ropes, and assembly tools.	1 set




Image: Included hardware for securing the gazebo, featuring expansion bolts, stakes, and ropes.

Setup and Assembly Instructions

Follow these steps for proper assembly. It is recommended to have at least two adults for assembly.

1. Frame Assembly

1. Unpack all components and lay them out on a clean, flat surface.
2. Identify all frame poles and connectors according to the parts list.
3. Begin by assembling the base frame, connecting the horizontal poles to the vertical legs.
4. Attach the roof support beams to the top of the vertical legs.
5. Secure all connections with the provided bolts and tools. Do not overtighten initially.

Your browser does not support the video tag.

Video: Overview of the LAUSAINT HOME Outdoor Patio Gazebo, showcasing its solid frame construction and overall design.

Your browser does not support the video tag.

Video: Detailed demonstration of the LAUSAINT HOME Heavy Duty Outdoor Patio Gazebo's frame assembly and structural features.

2. Canopy Installation

1. Carefully unfold the main canopy fabric and position it over the assembled roof frame.
2. Ensure the canopy is oriented correctly, with the drainage holes aligned.
3. Attach the canopy to the frame using the integrated fasteners or ties.
4. Install the smaller upper vent canopy onto the top tier of the roof frame.
5. For the upper vent canopy, ensure it is stretched tautly. Some users may find it helpful to slightly adjust the frame or use a ladder for easier installation.

Your browser does not support the video tag.

Video: Demonstration of zipping up the top cover of the gazebo, showing how to secure the canopy.

3. Netting and Curtain Attachment

1. Hang the mosquito netting panels from the designated hooks or rings on the frame.
2. Attach the privacy curtains in a similar manner.
3. Use the elastic buckles to secure the netting and curtains to the gazebo legs when not in use.



◄ Good Ventilation

Anti-mosquito ►





◄ Privacy Protection

Image: Visual representation of the gazebo's features, including good ventilation, anti-mosquito netting, and privacy protection with curtains.




Image: Detail of the convenient elastic buckles used to secure the netting and curtains, alongside a view of the thickened square tube frame.

4. Final Securing

1. Once the gazebo is fully assembled, use the provided stakes or expansion bolts to anchor the legs securely to the ground.
2. For concrete surfaces, use expansion bolts. For lawns or soil, use ground stakes.
3. Attach the ropes to the D-rings on the gazebo and secure them to additional ground anchors for extra stability in windy conditions.
4. Finally, re-check all bolts and connections to ensure they are fully tightened.

Operating Instructions

Ventilation and Airflow

The gazebo features a ventilated double-tier roof designed to improve airflow and reduce heat buildup. The mesh netting between roof tiers further promotes ventilation while helping to keep insects away.

Double roof with nettings

Keeping good air flows and repel mosquitos




Image: Close-up view of the double roof with integrated netting, illustrating its function for air circulation and insect deterrence.



Image: Diagram showing ventilation holes in the gazebo roof, designed to increase air circulation and enhance stability.

Privacy and Insect Protection

Utilize the zippered mosquito netting to create an enclosed space free from insects. The waterproof privacy curtains can be drawn for increased privacy and additional shade. When not needed, the netting and curtains can be tied back to the gazebo legs using the elastic buckles.

Hanging Accessories

The gazebo includes four built-in D-rings for attaching decorative lights or wind ropes. A central ceiling hook is provided for hanging a fan or pendant light (ensure the weight does not exceed the gazebo's capacity).




Image: Close-up of the D-rings for hanging decorations and the central ceiling hook for fans or lights.

Maintenance

- **Cleaning:** Clean the canopy fabric, netting, and curtains with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before storage.
- **Frame Care:** Wipe the metal frame with a damp cloth to remove dirt and debris. Inspect the frame for any signs of rust or damage. Apply rust-preventative paint if necessary.
- **Seasonal Storage:** For prolonged periods of non-use or during winter months, it is recommended to disassemble the gazebo and store all components in a dry, protected area.
- **Weather Precautions:** Always remove the canopy, curtains, and netting during extreme weather conditions (strong winds, heavy rain, snow) to prevent damage.
- **Fastener Check:** Periodically check all bolts, screws, and anchoring points to ensure they remain tight and secure. Re-tighten as needed.

Troubleshooting

Problem	Possible Cause	Solution
Gazebo is unstable or sways in wind.	Not properly anchored; loose connections.	Ensure all legs are securely anchored with stakes or expansion bolts. Tighten all frame connections. Use additional ropes for stability.
Water pooling on canopy.	Canopy not taut enough; drainage holes blocked.	Ensure canopy is stretched tightly over the frame. Clear any debris from drainage holes.
Difficulty attaching canopy.	Canopy orientation incorrect; frame not fully aligned.	Verify canopy orientation. Ensure frame is square and all connections are snug but not fully tightened until canopy is in place. Use a ladder for easier access.
Mosquitoes or insects entering.	Netting not fully zipped or secured.	Ensure all zippers are closed and netting is secured to the frame and ground. Check for any tears in the mesh.

Specifications

Brand: LAUSAINT HOME

Model: GZCT010-009-GR4-V2-OS-0505

Product Dimensions: 96.5"L x 96.5"W x 104.3"H (8'x8' footprint)

Internal Dimensions: Approximately 6.5' x 6.5'

Frame Material: Galvanized Steel

Canopy Material: Polyester Fabric


Water Resistance Level: 1500MM Water Resistant

UV Protection: UPF 50+

Color: Steel Gray

Assembly Required: Yes

Product Dimension



Tips: Internal dimensions are 6.5x6.5ft.

Image: Diagram illustrating the overall product dimensions of the gazebo, including height and footprint.

Warranty and Support

For warranty information, replacement parts, or customer support, please refer to the contact details provided at the point of purchase or visit the official LAUSAINT HOME website. Keep your purchase receipt as proof of purchase.
Return Policy: This product typically includes a 30-day return policy from the date of purchase. Please consult your retailer's specific return guidelines.

© 2026 LAUSAINT HOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GZKY728Z

More documents and user manuals: **https://manuals.plus/**