

[Manuals.plus](#) /

› [SoBuy](#) /

› SoBuy FSR100-E-W Slim Shoe Cabinet with LED Sensor Light User Manual

SoBuy FSR100-E-W

SoBuy FSR100-E-W Slim Shoe Cabinet with LED Sensor Light

User Manual

INTRODUCTION

Thank you for choosing the SoBuy FSR100-E-W Slim Shoe Cabinet. This manual provides detailed instructions for assembly, operation, and maintenance to ensure safe and efficient use of your product. Please read this manual thoroughly before installation and retain it for future reference.

SAFETY INFORMATION

- Always follow the assembly instructions carefully.
- Do not exceed the maximum weight capacity of 34 kg.
- Ensure the cabinet is securely installed, especially if wall-mounted, to prevent tipping.
- Keep small parts and packaging materials away from children.
- Use appropriate tools for assembly.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact SoBuy customer support.

- Cabinet panels (MDF(E1) + PB(E1))
- Assembly hardware (screws, dowels, etc.)
- LED sensor light strips
- Integrated hooks
- Felt pads
- Instruction manual

SETUP AND ASSEMBLY

Follow these steps to assemble your SoBuy FSR100-E-W shoe cabinet.

1. Unpacking and Preparation

- Carefully remove all components from the packaging.
- Lay out all parts on a clean, soft surface to prevent scratches.
- Identify each component using the provided parts list (if available in physical manual).

2. Assembly Steps

Refer to the assembly diagram for visual guidance.



Assembly diagram illustrating the step-by-step construction of the shoe cabinet.

1. Assemble the main frame of the cabinet using the designated screws and dowels.
2. Attach the bottom and top panels securely.
3. Install the flip-down shoe compartments. Ensure they open and close smoothly.
4. Attach the legs if you choose the floor-standing option.
5. Install the LED sensor light strips in the designated areas (top and bottom). Connect them according to the wiring instructions.
6. Attach the integrated hooks to the side of the cabinet.
7. Apply felt pads to the bottom of the legs or the back of the cabinet if wall-mounting.

3. Installation Options

The SoBuy FSR100-E-W offers flexible installation:

Due modalità di installazione

A parete o a pavimento – nessun foro per gli affitti, risparmio di spazio a parete per i proprietari.



The shoe cabinet can be installed as a floor-standing unit or securely mounted to a wall.

- **Floor-Standing:** Attach the provided legs to the base of the cabinet. Place the cabinet on a level surface.
- **Wall-Mounted:** Use appropriate wall anchors and screws (not always included, check package) to securely fasten the cabinet to a sturdy wall. Ensure it is level and stable. This option is ideal for narrow spaces and behind doors.

OPERATING INSTRUCTIONS

1. LED Sensor Light

The shoe cabinet is equipped with automatic LED sensor lights on the top and bottom. These lights are designed to activate when motion is detected nearby, providing illumination for easy access to your shoes.



Cercare le scarpe al buio



Luce morbida a sensore

The LED sensor light automatically illuminates when motion is detected, enhancing visibility.

- **Activation:** The lights will turn on automatically when you approach the cabinet.
- **Deactivation:** The lights will turn off after a short period of inactivity.
- **Power Source:** Ensure the LED lights are properly connected to a power source as per assembly instructions.

2. Shoe Storage

The cabinet features multiple flip-down compartments designed to store shoes efficiently.



EU 47

Per tutta la famiglia


Fino al 47, si adatta facilmente a diverse tipologie di scarpe (altezza gambale <12 cm)

The cabinet's compartments can store up to 8 pairs of shoes, including larger sizes.


- Each compartment can hold approximately 2 pairs of shoes, depending on size and style.
- The cabinet can accommodate shoes up to EU size 47 / US 13 and models with a shaft height of up to 12 cm.
- Gently open and close the compartments to prevent damage.

3. Integrated Hooks

The side hooks provide convenient storage for small items.




Ripiano superiore



Ganci laterali



Accessori di qualità



Base in metallo

Detail view of the integrated hooks, suitable for keys, bags, and other small accessories.

- Use the hooks to hang keys, small bags, umbrellas, or other entryway essentials.
- Do not overload the hooks to prevent damage or tipping.

MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Dusting:** Regularly dust the cabinet to maintain its appearance.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **LED Lights:** If the LED lights malfunction, check the power connection. If issues persist, contact customer support.


TROUBLESHOOTING

If you encounter any issues with your shoe cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cabinet is wobbly/unstable	Loose screws; uneven floor; improper wall mounting	Tighten all screws. Adjust felt pads for uneven floors. Re-secure wall mounting if applicable.
LED sensor light not working	Power connection loose; sensor obstructed; faulty light strip	Check all power connections. Ensure sensor is clear. Contact support if problem persists.
Shoe compartments not closing properly	Obstruction; misaligned hinges; overloaded	Remove any obstructions. Check hinge alignment. Do not overload compartments.

SPECIFICATIONS

Feature	Detail
Brand	SoBuy
Model Number	FSR100-E-W
Color	White
Material	Engineered Wood (MDF(E1) + PB(E1)), Metal
Product Dimensions (D x W x H)	19 x 100 x 93 cm
Item Weight	22.5 kg
Maximum Weight Capacity	34 kg
Number of Shoe Compartments	4 (each with 2 sections, totaling 8 storage areas)
Shoe Size Accommodation	Up to EU 47 / US 13, shaft height up to 12 cm
Special Features	Automatic LED Sensor Light, Integrated Hooks, Slim Design
Assembly Required	Yes
Mounting Type	Floor Standing or Wall Mount



Dimensional overview of the shoe cabinet.

WARRANTY AND SUPPORT

SoBuy is committed to providing high-quality products and customer satisfaction.

- **Warranty:** For information regarding product warranty, please refer to the purchase documentation or contact your retailer.
- **Customer Support:** If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact SoBuy customer service. You can usually find contact information on the retailer's website or by visiting the official SoBuy store page.
- **Online Store:** Visit the [SoBuy Store on Amazon](#) for more products and support.

