Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Shark BU3621UKT

Shark PowerLite BU3621UKT Cordless Clean & Empty Pet Vacuum User Manual

Introduction

The Shark PowerLite BU3621UKT is a cordless vacuum cleaner designed for powerful and convenient cleaning in homes with pets. It features an auto-empty base, anti-hair wrap technology, FloorDetect for optimized multi-surface cleaning, and sealed HEPA filtration. This manual provides instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal performance of your vacuum cleaner.



Image: The Shark PowerLite BU3621UKT in action, demonstrating its use in a typical home environment.

What's in the Box

Carefully unpack all components and inspect for any damage. Ensure all parts listed below are present.

- Shark PowerLite Handheld Vacuum Unit
- Wand
- PowerFins Floor Nozzle
- Auto-Empty Dock
- Lithium-ion Battery
- FurFins Pet Tool
- Crevice Tool
- HEPA Filter (pre-installed)



Image: An overview of the Shark PowerLite BU3621UKT components, including the main unit, auto-empty dock, and included accessories.

Setup and Assembly

Follow these steps to assemble your Shark PowerLite vacuum cleaner.

1. **Attach the Wand:** Insert the wand into the handheld vacuum unit until it clicks securely into place.
2. **Attach the Floor Nozzle:** Insert the wand into the PowerFins floor nozzle until it clicks securely into place.
3. **Install the Battery:** Slide the lithium-ion battery into the slot on the handheld vacuum unit until it clicks. Ensure it is fully seated.
4. **Position the Auto-Empty Dock:** Place the auto-empty dock on a flat, stable surface near a power outlet. Ensure there is enough space around it for the vacuum to dock easily.



Image: The fully assembled Shark PowerLite BU3621UKT vacuum cleaner, ready for use.

Operating Instructions

Charging the Battery

For optimal performance, fully charge the battery before first use. The vacuum automatically charges when docked.

- Place the assembled vacuum onto the auto-empty dock. Ensure it is properly seated.
- The charging indicator lights on the handheld unit will illuminate to show charging status.
- A full charge provides up to 40 minutes of runtime (in ECO mode with non-motorized tool).



Image: The Shark PowerLite BU3621UKT docked, illustrating its automatic charging and emptying function.

Selecting Cleaning Modes

The vacuum features three cleaning modes for different tasks and surfaces.

- **ECO Mode:** For everyday cleaning and extended runtime on all surfaces.
- **AUTO Mode:** Automatically adjusts suction power and brush-roll speed based on floor type (FloorDetect technology).
- **BOOST Mode:** Provides maximum suction for tough messes and deep cleaning.

Press the mode selection button on the handheld unit to cycle through the available modes.



Image: The control interface of the Shark PowerLite, highlighting the three selectable cleaning modes.

Using FloorDetect Technology

In AUTO mode, FloorDetect technology automatically senses the floor type and adjusts the brush-roll speed for optimized cleaning on carpets and hard floors without needing to change floorheads.



Image: Visual representation of FloorDetect technology adapting to different floor types for efficient cleaning.

Converting to Handheld Vacuum

The Shark PowerLite can be easily converted into a handheld vacuum for cleaning stairs, upholstery, and hard-to-reach areas.

1. Press the wand release button to detach the wand and floor nozzle from the handheld unit.
2. Attach desired accessory (e.g., FurFins Pet Tool, Crevice Tool) directly to the handheld unit.



Image: Demonstration of the vacuum's versatility, converting into a handheld unit for above-floor cleaning.

Using the FurFins Pet Tool

The FurFins Pet Tool is designed to effectively remove pet hair and embedded dirt from upholstery, stairs, and pet beds.

- Attach the FurFins Pet Tool directly to the handheld unit.
- Use short, overlapping strokes for best results on fabric surfaces.



Image: The FurFins Pet Tool effectively cleaning pet hair from furniture.

Maintenance

Emptying the Dust Cup (Auto-Empty Base)

The auto-empty dock automatically empties the vacuum's dust cup and stores debris for up to 30 days, providing hands-free convenience.

- After each cleaning session, dock the vacuum onto the auto-empty base.
- The base will automatically activate to suction debris from the vacuum's dust cup into its sealed container.
- When the base's container is full (approximately every 30 days, depending on usage), simply remove and empty it into a waste bin.



Image: The auto-empty base in action, demonstrating its ability to lock away dust and allergens for extended periods.

Cleaning Filters

Regularly clean the filters to maintain optimal suction power. The Shark PowerLite features sealed HEPA filtration.

- **Pre-Motor Filters:** Rinse with water monthly. Allow to air dry completely for at least 24 hours before reinstalling.
- **Post-Motor HEPA Filter:** Rinse with water annually. Allow to air dry completely for at least 24 hours before reinstalling.

Refer to the filter access points on your handheld unit for removal and reinstallation instructions.

Maintaining the Brush-roll

The PowerFins brush-roll is designed with anti-hair wrap technology to minimize hair tangles. Periodically inspect the brush-roll for any debris.

- Turn off the vacuum and disconnect it from the power source.
- Access the brush-roll by opening the cover on the floor nozzle.

- Carefully remove any string, hair, or debris that may have wrapped around the brush-roll.
- Ensure the brush-roll is free of obstructions before reassembling.



Image: The PowerFins brush-roll, showcasing its design for continuous contact and anti-hair wrap capabilities.

Troubleshooting

If you encounter any issues with your vacuum, refer to the following common problems and solutions.

- **Vacuum not turning on:** Ensure the battery is fully charged and correctly inserted. Check if the power button is pressed firmly.
- **Loss of suction:** Check if the dust cup is full or if the auto-empty base needs emptying. Clean all filters as per maintenance instructions. Check for blockages in the nozzle, wand, or hose.
- **Brush-roll not spinning:** Ensure the vacuum is in a mode that activates the brush-roll (AUTO or BOOST). Check for obstructions in the brush-roll area and clear any tangled hair or debris.
- **Vacuum not charging:** Ensure the vacuum is correctly docked on the auto-empty base and the base is plugged into

a working power outlet. Check for any debris preventing proper contact.

- **Auto-empty base not emptying:** Ensure the vacuum is fully seated on the dock. Check if the base's debris container is full or if there are any blockages in the emptying path.

Specifications

Feature	Specification
Model Number	BU3621UKT
Power (Watts)	350 W
Weight	5.87 Kilograms
Dimensions (L x W x H)	36.4L x 26.3W x 110.5H centimeters
Battery Type	Lithium-ion
Runtime	Up to 40 minutes (ECO mode, non-motorized tool)
Filter Type	HEPA
Special Features	Anti-hair wrap, HEPA, Lightweight, Cordless, Bagless

Warranty and Support

Shark offers a 5-year guarantee on this product upon registration. This demonstrates confidence in the quality and durability of the Shark PowerLite BU3621UKT.

- **Guarantee:** A free 5-year guarantee is offered upon product registration with Shark. (Note: 2 years on batteries).
- **Registration:** Visit the official Shark website to register your product and activate your guarantee.
- **Support:** For further assistance, troubleshooting, or to claim warranty service, please contact Shark customer support through their official website.



Image: The 5-year guarantee emblem, signifying product quality and manufacturer confidence.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H126S9CT

More documents and user manuals: **https://manuals.plus/**