

Jxrev W90

Jxrev W90 Wireless Earbuds Bluetooth 5.4 User Manual

Model: W90 | Brand: Jxrev

INTRODUCTION

This manual provides detailed instructions for the Jxrev W90 Wireless Earbuds. Please read this guide thoroughly to ensure proper setup, operation, and maintenance of your device. These earbuds feature Bluetooth 5.4 connectivity, IP7 waterproofing, ENC noise-canceling microphones, and a long-lasting battery.

WHAT'S IN THE BOX

- 2 x Wireless Earbuds
- 1 x Wireless Charging Case
- 1 x Type-C Charging Cable
- 1 x User Manual
- 3 x Pairs of Silicone Eartips (S, M, L)




Image: Contents of the Jxrev W90 Earbuds package.

SETUP

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided Type-C charging cable to the charging port on the case and a USB power source. The LED display on the case will show the charging status.



Image: Earbuds and charging case during charging, displaying battery levels.

2. Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "W90 Pro" or "Jxrev W90" in the list of available Bluetooth devices and select it to connect.
5. Once connected, a voice prompt will confirm successful pairing.

One-step Pairing

Auto on, auto connected when open the case.
Provide faster wireless connection to your devices



Image: One-step pairing process with a smartphone.

3. Wearing the Earbuds

Select the appropriate silicone eartips (S, M, L) for a comfortable and secure fit. Insert the earbuds into your ears and gently rotate them until they feel snug. A proper fit enhances sound quality and noise isolation.



Image: Guide for comfortable and stable earbud wear with eartip options.

OPERATING INSTRUCTIONS

Touch Controls

The Jxrev W90 earbuds feature smart touch controls for various functions:

Action	Function
Tap Once (L/R)	Play/Pause Music, Answer/End Call
Press and Hold 2s (L)	Volume Down
Press and Hold 2s (R)	Volume Up
Tap Twice (L)	Previous Track
Tap Twice (R)	Next Track
Tap Three Times (L/R)	Activate Voice Assistant (Siri, Google Assistant)
Press and Hold 3s (L/R) during call	Reject Call

Ergonomic Design & Smart Touch Control



Image: Visual guide to earbud touch controls.

LED Display

The charging case features a dual LED display that shows the remaining battery percentage of the charging case and the individual charge levels of the left and right earbuds.

Single/Twin Mode

The earbuds can be used individually (single mode) or together (twin mode). Simply take one earbud out of the case to use it alone, or both for stereo sound.

MAINTENANCE

Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free

cloth. Do not use abrasive cleaners or submerge the devices in liquid.

Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.

Water Resistance (IP7)

The Jxrev W90 earbuds are IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. This makes them suitable for sports and outdoor activities, protecting against sweat and raindrops. However, they are not designed for swimming or prolonged submersion. Ensure the earbuds are dry before placing them back in the charging case to prevent damage.



Image: Earbuds demonstrating IP7 waterproof capabilities.

TROUBLESHOOTING

Earbuds Not Pairing

- Ensure both earbuds are charged.
- Place both earbuds back into the charging case, close the lid, and then open it again to reset.
- Turn off and on your device's Bluetooth.
- Forget "W90 Pro" or "Jxrev W90" from your device's Bluetooth list and attempt to pair again.

Only One Earbud Working

- Ensure both earbuds are charged.
- Place both earbuds back into the charging case, close the lid, and then open it again. This should force them to reconnect to each other.
- If the issue persists, try resetting the earbuds by forgetting them from your device's Bluetooth settings and re-pairing.

Low Volume or Poor Sound Quality

- Adjust the volume on both your device and using the earbud touch controls.
- Ensure the earbuds are properly seated in your ears and you are using the correct size eartips for a good seal.
- Clean any debris from the earbud speakers and eartips.

- Ensure there are no obstructions between the earbuds and your connected device.

Charging Issues

- Verify the Type-C charging cable is securely connected to both the case and the power source.
- Try a different charging cable or power adapter.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.

SPECIFICATIONS

Feature	Detail
Model Number	W90
Bluetooth Version	5.4
Playtime (Single Charge)	Up to 8 hours
Total Playtime (with Charging Case)	Up to 50 hours
Charging Time	Approx. 1 hour (for full charge)
Water Resistance Rating	IP7
Microphones	4 ENC Noise Cancelling Mics
Speaker Size	14 mm
Charging Port	Type-C
Earbud Weight	Approx. 3g per earbud
Noise Control	Sound Isolation
Sensitivity	35 dB
Audio Latency	35 Milliseconds

WARRANTY AND SUPPORT

The Jxrev W90 Wireless Earbuds come with a 1-year manufacturer's warranty. For warranty claims or technical support, please contact Jxrev customer service through the retailer where you purchased the product or visit the official Jxrev website.

For additional support, you may refer to the [Jxrev Store on Amazon](#).

PRODUCT VIDEOS

Your browser does not support the video tag.

Video: Overview of Jxrev Wireless Earbuds, highlighting Bluetooth 5.4 and noise reduction features. This video is provided by a seller.

Your browser does not support the video tag.

Video: Detailed demonstration of Jxrev Wireless Earbuds, including features and usage. This video is provided by a seller.

Your browser does not support the video tag.

Video: Review and features of Kurdene Bluetooth 5.3 Wireless Earbuds, which are similar to the Jxrev W90 model. This video is provided by a seller.

© 2026 Jxrev. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0H1BBDB5T>

More documents and user manuals: <https://manuals.plus/>