

ROMP Lemon Crush

ROMP Lemon Vibrator Instruction Manual

Model: Lemon Crush

INTRODUCTION

The ROMP Lemon Vibrator, also known as Lemon Crush, is designed to provide clitoral stimulation using innovative air-powered technology. This compact and discreet device features 10 intensity levels, is fully waterproof, and is crafted from body-safe silicone for a comfortable experience. It is rechargeable and offers up to 60 minutes of use per charge.

SAFETY INFORMATION

- **For Adult Use Only:** This product is intended for adult use.
- **Body-Safe Materials:** The device is made from body-safe silicone. Discontinue use if irritation occurs.
- **Lubrication:** Always use with a water-based lubricant to ensure comfort and prolong the life of the product. Do not use with silicone-based lubricants as they may damage the silicone material.
- **Cleaning:** Clean the device thoroughly before and after each use as described in the Maintenance section.
- **Waterproof:** The device is IPX7 waterproof, suitable for use in baths or showers. Do not submerge for extended periods or beyond specified depths.
- **Charging:** Use only the provided magnetic charging cable. Do not use the device while it is charging.
- **Storage:** Store in a clean, dry place away from direct sunlight and extreme temperatures. Keep out of reach of children.
- **Medical Conditions:** If you have any medical conditions or concerns, consult a healthcare professional before using this product.

WHAT'S INCLUDED

Your ROMP Lemon Vibrator package typically includes:

- 1 x ROMP Lemon Vibrator (Lemon Crush)
- 1 x Magnetic USB Charging Cable
- 1 x User Manual (this document)



Image: The ROMP Lemon Vibrator shown with its retail packaging.

SETUP

Initial Charge

Before first use, fully charge your ROMP Lemon Vibrator. The device features a magnetic charging port for convenience.

1. Locate the magnetic charging points on the device.
2. Connect the magnetic USB charging cable to these points. Ensure a secure connection.
3. Plug the USB end of the cable into a compatible USB power source (e.g., computer, USB wall adapter).
4. The indicator light on the device will illuminate during charging. It typically takes a few hours for a full

charge.

5. Once fully charged, the indicator light may change color or turn off, depending on the model.
Disconnect the charger.



Image: The ROMP Lemon Vibrator being charged via its magnetic USB cable.

Your browser does not support the video tag.

Video: Official product video demonstrating the ROMP Lemon Vibrator, including charging and basic operation.

OPERATING INSTRUCTIONS

Power On/Off

The ROMP Lemon Vibrator features a single button for control.

- **To Power On:** Press and hold the power button for approximately 2 seconds until the device vibrates.
- **To Power Off:** Press and hold the power button for approximately 2 seconds until the device stops.

Adjusting Intensity Levels

The device offers 10 distinct intensity levels of air-powered clitoral stimulation.

- Once powered on, short press the power button to cycle through the 10 intensity levels.
- Each short press will increase the intensity. After reaching the highest level, the next press will return to the lowest level.




Image: The ROMP Lemon Vibrator highlighting its one-button control and key features like 10 intensity levels and 60-minute runtime.

Travel Lock

The ROMP Lemon Vibrator includes a travel lock feature to prevent accidental activation during transport.

- **To Activate Travel Lock:** With the device powered off, press and hold the power button for 5 seconds. The indicator light may flash to confirm activation.
- **To Deactivate Travel Lock:** Press and hold the power button for 5 seconds. The device will unlock and be ready for use.

Too Cute to Hide

Your crush that goes everywhere with you!

ROMP



Image: The ROMP Lemon Vibrator displayed with a travel lock icon, suggesting its portability.

MAINTENANCE

Cleaning

Proper cleaning ensures hygiene and extends the lifespan of your device.

- Always clean the device before and after each use.
- Wash the silicone parts with warm water and a mild, antibacterial soap or a specialized toy cleaner.
- Rinse thoroughly with clean water.
- Dry the device completely with a lint-free cloth before storing.
- Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.

Waterproof

Always down for
a pool party!

ROMP



Fully
waterproof

Image: The ROMP Lemon Vibrator shown in a waterproof setting, emphasizing its IPX7 rating.

Storage

Store your ROMP Lemon Vibrator in a safe, clean, and dry place when not in use. Keep it away from direct sunlight, extreme temperatures, and other sex toys made of different materials to prevent potential damage or discoloration.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted or travel lock is active.	Charge the device fully. Ensure the magnetic charging cable is securely connected. Deactivate the travel lock by pressing and holding the power button for 5 seconds.

Problem	Possible Cause	Solution
Device does not hold a charge.	Faulty charging cable or battery issue.	Try using a different USB power source. If the issue persists, contact customer support for assistance.
Weak or inconsistent stimulation.	Low battery or improper placement.	Ensure the device is fully charged. Adjust the position of the device for optimal contact. Cycle through intensity levels to find your preferred setting.

SPECIFICATIONS

- **Model Name:** Lemon Crush
- **Dimensions:** 3.07 x 2.09 x 1.18 inches
- **Weight:** 3.14 ounces
- **Material:** Body-safe Silicone
- **Color:** Yellow
- **Battery:** 1 Nonstandard Battery (included)
- **Runtime:** Up to 60 minutes (on a full charge)
- **Charging:** Magnetic USB charging
- **Waterproof Rating:** IPX7 (splash-proof and submersible up to 1 meter for 30 minutes)
- **Intensity Levels:** 10



Image: The ROMP Lemon Vibrator showcasing its core features including Pleasure Air Technology and body-safe silicone.

WARRANTY AND SUPPORT

Warranty Information

ROMP products typically come with a 2-year warranty. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, concerns, or technical assistance regarding your ROMP Lemon Vibrator, please contact the manufacturer, WOW Tech USA. You can typically find their contact information on the product packaging or their official website.

When contacting support, please have your product model (Lemon Crush) and purchase details ready.