

EUQQ R210

EUQQ R210 Wireless Earbuds User Manual

Model: R210

1. INTRODUCTION

Thank you for choosing the EUQQ R210 Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features such as Bluetooth 5.4 connectivity, Active Noise Cancellation (ANC), and Transparency Mode. This manual provides instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.

2. WHAT'S IN THE BOX

Carefully unpack the contents and ensure all items are present:

- 2 x EUQQ R210 Bluetooth 5.4 Earbuds
- 1 x Charging Case
- 1 x USB Type-C Charging Cable
- 3 x Pairs of Ear Tips (Sizes S/M/L)
- 1 x User Manual

Note: A power adapter/charger is not included.

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots.
2. Connect the USB Type-C charging cable to the charging port on the case and plug the other end into a USB power source (e.g., computer, wall adapter).

3. The LED display on the charging case will indicate the battery level during charging.
4. A full charge for the earbuds takes approximately 1 hour. The charging case provides an additional 36-46 hours of playtime.



Image: EUQQ R210 Earbuds placed in their charging case, showing the LED display indicating battery status.

3.2 Pairing with a Bluetooth Device

The earbuds utilize revolutionary Bluetooth 5.4 technology for stable and fast connections.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "EUQQ R210" from the list.
4. Once connected, you will hear an audible confirmation, and the earbuds will be ready for use.

The connection remains stable even in environments with multiple Bluetooth devices, with an extended range of up to 15 meters.

3.3 Fitting the Earbuds

For optimal sound quality and comfort, choose the correct ear tip size.

1. The earbuds come with three sizes of ear tips (S, M, L).
2. Try each size to find the one that provides a secure and comfortable fit, creating a good seal in your ear canal.
3. Insert the earbuds into your ears and gently twist them until they feel snug and stable.



Image: Diagram illustrating the ergonomic design and proper fit of the earbuds with various ear tip sizes (S, M, L).

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** Place the earbuds back into the charging case to automatically power them off and begin charging.

4.2 Active Noise Cancellation (ANC) and Transparency Mode

The EUQQ R210 earbuds feature both Active Noise Cancellation and Transparency Mode.

- **Active Noise Cancellation (ANC):** This mode reduces ambient noise, allowing you to focus on your audio. It is ideal for noisy environments like trains, offices, or gyms.
- **Transparency Mode:** This mode allows ambient sounds to pass through, enabling you to hear your surroundings and engage in conversations without removing the earbuds. The built-in microphones pick up external sounds and transmit them to your ears.

Refer to the touch control section (if available on the product) for specific instructions on switching between these modes.



Image: Visual representation of how Active Noise Cancellation blocks external sounds and Transparency Mode allows them through.

4.3 Audio Playback and Calls

- **Audio Quality:** Enjoy stereo surround sound with deep bass and clear highs, delivered by 13mm dynamic drivers.
- **Calls:** The integrated CVC 8.0 algorithm ensures clear call quality, even in noisy environments.

Specific touch controls for playback (play/pause, skip tracks) and call management (answer/end calls) are typically detailed in a quick start guide or on the product packaging. Please refer to those resources for precise control gestures.

5. MAINTENANCE

5.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

5.2 Water Resistance

The earbuds have an IPX7 waterproof rating, meaning they are resistant to sweat and rain. They are suitable for workouts and outdoor activities. However, they are not designed for swimming or prolonged submersion in water.

5.3 Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage.

6. TROUBLESHOOTING

6.1 Earbuds Not Pairing

- Ensure the earbuds are charged.

- Make sure Bluetooth is enabled on your device.
- Place the earbuds back in the case, close it, then open it again to re-enter pairing mode.
- Try forgetting the device in your phone's Bluetooth settings and re-pairing.

6.2 No Sound or Low Volume

- Check the volume levels on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.
- Clean any debris from the earbud speakers and ear tips.

6.3 Charging Issues

- Verify the charging cable is securely connected to both the case and the power source.
- Try a different USB Type-C cable or power adapter.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of obstruction.

7. SPECIFICATIONS

Model Name	R210
Brand	EUQQ
Connectivity Technology	Wireless (Bluetooth 5.4)
Wireless Communication Technology	Bluetooth
Bluetooth Range	Up to 15 meters
Noise Control	Active Noise Cancellation (ANC)
Ear Placement	In-Ear
Form Factor	In-Ear
Audio Driver Type	Dynamic (13mm)
Battery Life (Earbuds)	6-7 hours (single charge)
Total Playtime (with Charging Case)	Up to 46 hours
Charging Time (Earbuds)	Approximately 1 hour
Water Resistance Level	IPX7 (Waterproof)
Compatible Devices	Almost all Bluetooth-enabled devices (iOS, Android, etc.)
UPC	791162260905

8. SAFETY INFORMATION

- Do not disassemble or modify the product.
- Keep the earbuds and charging case away from extreme temperatures, direct sunlight, and open flames.
- Avoid listening at high volumes for extended periods to prevent hearing damage.
- Keep out of reach of children and pets.

- Dispose of the product responsibly according to local regulations.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact EUQQ customer service through their official website or the retailer where the product was purchased.

© 2026 EUQQ. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question