

Aeitto ICM11

Aeitto ICM11/ICM12 Countertop Ice Maker User Manual

Model: ICM11 / ICM12

INTRODUCTION

Thank you for choosing the Aeitto Countertop Ice Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new ice maker. Please read these instructions thoroughly before first use and retain for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before operating the appliance.
- Do not touch the evaporator when the ice maker is in operation.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug the appliance from the outlet when not in use, before cleaning, and before servicing.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Ensure the appliance is placed on a firm, level surface.
- Do not block any ventilation openings.
- This appliance is for household use only.

PRODUCT OVERVIEW

The Aeitto Countertop Ice Maker is designed for convenience, producing bullet-shaped ice quickly. It features a compact design, two ice size options, and an automatic self-cleaning function.

Components

- Ice Maker Unit
- Ice Basket
- Ice Scoop
- Instruction Manual

Control Panel

The control panel is located on the front of the unit and includes the following indicators and buttons:

- **POWER Indicator:** Illuminates when the unit is powered on.
- **SMALL/LARGE Indicators:** Show the selected ice cube size.
- **ADD WATER Indicator:** Illuminates when the water reservoir needs refilling.
- **ICE FULL Indicator:** Illuminates when the ice basket is full.
- **CLEAN Indicator:** Illuminates during the self-cleaning cycle.
- **SELECT Button:** Press to switch between small and large ice cube sizes.
- **ON/OFF Button:** Press to turn the unit on or off. Press and hold for 5 seconds to activate the self-cleaning function.



Image: The Aeitto ice maker unit, showing its stainless steel finish and control panel. Ice cubes are visible in the open lid.

SETUP

1. Unpacking

1. Carefully remove the ice maker from its packaging.
2. Remove all packing materials, including foam and tape.
3. Inspect the unit for any damage. If damaged, do not operate and contact customer support.

2. Placement

Place the ice maker on a stable, level surface away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit (at least 5 inches of space on all sides). The compact design (11.9"D x 7.3"W x 10.8"H) allows it to fit easily on most countertops.



Image: The ice maker displayed with its dimensions (11.9"D x 7.3"W x 10.8"H) and a separate ice basket, highlighting its portable and space-saving design.

3. Initial Cleaning

Before first use, it is recommended to clean the ice maker. Refer to the 'Automatic Self-Cleaning' section under Maintenance for detailed instructions.

OPERATING INSTRUCTIONS

1. Add Water

- Open the top lid of the ice maker.
- Fill the water reservoir with potable water up to the MAX fill line. Do not overfill.

- Close the lid.

2. Power On/Off

- Plug the power cord into a grounded electrical outlet. The POWER indicator will blink.
- Press the **ON/OFF** button to turn on the ice maker. The POWER indicator will illuminate steadily.
- To turn off the unit, press the **ON/OFF** button again.

3. Selecting Ice Size

- After powering on, the default ice size is usually small.
- Press the **SELECT** button to toggle between SMALL and LARGE ice cube sizes. The corresponding indicator light will illuminate.
- Small ice is ideal for whiskey, iced coffee, or cocktails, melting slower to balance flavors.
- Large ice is suitable for sodas, iced tea, or pitchers, cooling beverages faster.



Image: A visual comparison of the two available ice cube sizes, small (20mm*28mm) and large (23mm*30mm), with a glass of iced beverage.

4. Ice Production

- Once water is added and the unit is powered on with a size selected, the ice maker will begin its cycle.
- The first batch of ice cubes will be ready in approximately 6 minutes.
- The unit can produce up to 26 lbs of ice in 24 hours.

Portable & Space-Saving Design

Effortless Ice, Zero Space Hassle



Image: A close-up of the ice-making mechanism, showing 8 bullet-shaped ice cubes being released, with text indicating 8 cubes in 6 minutes and 26 lbs/24H production.

5. Ice Full Indicator

- When the ice basket is full, the **ICE FULL** indicator will illuminate, and the ice production cycle will pause automatically.
- Remove ice from the basket to resume ice production.

Self-Cleaning Function



Fresh Ice



Removes
Limescale



Keeps Healthy

Image: A view inside the ice maker showing the ice basket filled with ice cubes and a red sensor line, indicating the 'Ice-full Reminder' feature.

6. Add Water Indicator

- If the water level in the reservoir is too low, the **ADD WATER** indicator will illuminate, and the ice production will stop.
- Refill the water reservoir to the **MAX** line to resume operation.

MAINTENANCE

1. Automatic Self-Cleaning Function

The ice maker features an automatic self-cleaning cycle to maintain hygiene and ice purity.

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the **ON/OFF** button for 5 seconds. The **CLEAN** indicator will illuminate, and the unit will begin a 5-minute cleaning cycle.
3. After the cycle, drain the water from the unit.



Ice-full Reminder

Don't worry about the ice maker working for a long time, it will stop working when the ice production reaches the alert level, to save energy.

Image: A visual guide demonstrating the three steps for activating the self-cleaning function: adding water, pressing the ON/OFF button for 5 seconds, and the unit performing a 5-minute self-clean.

2. Regular Cleaning

- Unplug the ice maker before cleaning.
- Remove the ice basket and wash it with mild detergent and warm water. Rinse thoroughly.
- Drain any remaining water from the reservoir using the drain plug located at the bottom of the unit.
- Wipe the interior and exterior surfaces with a soft cloth and mild detergent.
- Dry all parts thoroughly before reassembling and storing.

3. Descaling

If you live in an area with hard water, descaling may be necessary to prevent mineral buildup. Descale once a month, or more often if significant mineral deposits are observed.

- Mix a solution of water and vinegar (or a commercial descaling agent) according to the product instructions.
- Pour the solution into the water reservoir.
- Run the self-cleaning cycle (see above).
- After the cycle, drain the solution and rinse the reservoir thoroughly with clean water several times to remove any residue.

4. Storage

When storing the ice maker for an extended period, ensure it is clean and dry. Store it in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; Power off; Ambient temperature too high.	Fill water reservoir; Turn on unit; Ensure proper ventilation and cooler environment.
ADD WATER indicator is on.	Water level is low.	Add water to the reservoir up to the MAX line.
ICE FULL indicator is on.	Ice basket is full.	Remove ice from the basket.
Ice cubes are too small or misshapen.	Water temperature too high; Ambient temperature too high; Insufficient water.	Use colder water; Ensure proper ventilation; Check water level.

Problem	Possible Cause	Solution
Unit is noisy.	Normal operation sounds; Unit not level.	Ensure unit is on a stable, level surface.

SPECIFICATIONS

Feature	Detail
Brand	Aeitto
Model Name	ICM12
Part Number	ICM11
Product Dimensions (D x W x H)	11.9" x 10.8" x 7.3"
Capacity	2 Pounds (Ice Basket)
Daily Ice Output	26 lbs/24H
Ice Production Time	8 cubes in 6 minutes
Ice Cube Sizes	Small (20mm*28mm), Large (23mm*30mm)
Wattage	1100 watts
Voltage	110 Volts
Refrigerant	R600a
Material Type	Stainless Steel
Included Components	Ice Maker*1, Ice Scoop*1, Basket*1

WARRANTY AND SUPPORT

This Aeitto ice maker comes with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, technical support, or any questions regarding your product, please contact Aeitto customer service. Please have your model number (ICM11 or ICM12) and proof of purchase ready when contacting support.