

[Manuals.plus](#) /

› [TOWILD](#) /

› TOWILD CL600 Rechargeable Bicycle Light Instruction Manual

## TOWILD CL600

# TOWILD CL600 Rechargeable Bicycle Light Instruction Manual

Model: CL600 | Brand: TOWILD

## INTRODUCTION

This manual provides detailed instructions for the TOWILD CL600 Rechargeable Bicycle Light. Please read this manual thoroughly before use to ensure proper operation and maintenance. The CL600 is designed for cyclists seeking a reliable and versatile front light, featuring 600 lumens brightness, a 2600mAh battery, USB-C charging, IPX6 waterproofing, and multiple lighting modes.

## SETUP

### 1. Unboxing and Components

Verify all components are present: CL600 light unit, handlebar mount, GoPro compatible mount, USB-C charging cable, and instruction manual.

## パッケージ内容



1\*ライト

1\*ハンドルバーマウント

1\*GOPRO対応マウント

1\*TYPE-C充電ケーブル

1\*取扱説明書



Image: Package contents of the TOWILD CL600 bicycle light, showing the light unit, handlebar mount, GoPro mount, USB-C cable, and user manual.

## 2. Mounting the Light

- **Handlebar Mount:** Attach the handlebar mount securely to your bicycle's handlebar. Ensure the mount is tightened sufficiently to prevent movement during riding.
- **Garmin/GoPro Compatible Mount:** The CL600 features a Garmin-compatible bracket, allowing it to be mounted above or below your handlebars, or even on a helmet, using compatible Garmin/GoPro mounts (sold separately). This provides flexibility for various cycling setups.

# 通勤&通学オススメ 高品質・自転車ライト



吊り下げもOK



 高輝度600LM	 2600mAh	 自動点灯
 5つ点灯モード	 リモート機能	 USB-C充電式

Image: The TOWILD CL600 bicycle light securely mounted on a handlebar, demonstrating its front placement.

## 互換性高いGARMINベース採用

フロントマウントやGOPROカメラ、ヘルメットなどにしっかり取付可能です。




Image: Various mounting options for the TOWILD CL600, including helmet and under-handlebar positions, highlighting its Garmin mount compatibility.

### 3. Initial Charge

Before first use, fully charge the CL600 light using the provided USB-C cable. Connect the cable to the light's USB-C port and a suitable USB power source. The battery indicator will show charging status.

## OPERATION

### 1. Power On/Off

Press and hold the power button for approximately 1 second to turn the light ON or OFF.

### 2. Changing Lighting Modes

- With the light ON, a single press of the power button cycles through the three steady brightness modes **High** (600 lumens), **Medium** (300 lumens), and **Low** (150 lumens).
- Double-click the power button to switch to the flashing modes **Night Flash** (200 lumens) and **Day Flash** (600 lumens).


最新  
進化版

# 2600mAh大容量 5つの点灯モード

高-中-低輝度の切替は一回クリックし、  
ダブルクリックすると点滅モード（2つ）に切り替えます。

モード切替スイッチ

\*長押しで点灯/消灯します



高輝度（600LM）

約2.25時間

中輝度（300LM）

約3.5時間

低輝度（150LM）

約6.5時間

点滅モード（ハイ/ロー）

約11-13時間

Image: A close-up view of the TOWILD CL600 bicycle light, highlighting the power button for mode selection and the main light lens.

# 街乗り用600ルーメン 自転車LEDライト

 高輝度600LM	 2600mAh	 自動点灯
 5つ点灯モード	 リモート機能	 USB-C充電式



Image: A table detailing the TOWILD CL600's lighting modes (Low, Medium, High, Night Flash, Day Flash), their respective brightness levels (150LM to 600LM), and approximate runtimes (2.25 to 13 hours).

### 3. Smart Mode (Vibration Sensor)

- The CL600 features a smart mode with a vibration sensor. When activated (indicated by a blue light), the light will automatically turn off after approximately 120 seconds of inactivity (e.g., when stopped at a traffic light).
- Upon detecting vibration (movement), the light will automatically turn back on.

# 振動感知で自動点灯消灯

振動感知センサーを装備し、手動で電源オフ/オンはもちろん、スマートモードで走行環境によって、止まる時にライトを自動的に消灯することが可能です。再走行する（振動感知がある）とライトが自動的に点灯します。

振動センサー  
(スマートモード)

振動



静止



Image: The TOWILD CL600 bicycle light mounted on a handlebar, with an arrow indicating the vibration sensor for its smart mode functionality.

## 振動感知で自動点灯消灯

振動感知センサーを装備し、スマートモードで走行環境によって、止まる時（2分後）にライトが自動的に消灯し、再走行する（振動感知がある）と自動的に再点灯します。



Image: A visual representation of the TOWILD CL600's automatic on/off feature, showing the light turning off when stationary and turning back on when vibration is detected.

### 4. Battery Indicator

The indicator light on the device displays the battery level:

- **Green (steady):** 100-30% charge.
- **Green (flashing):** Below 30% charge.
- **Red & Green (alternating flash):** Below 10% charge.

## モードとランタイム

モード	低	中	高	ナイト フラッシュ	デイ フラッシュ
輝度	150LM	300LM	600LM	200LM	600LM
稼働時間	6.5時間	3.5時間	2.25時間	13時間	11時間



Image: A diagram illustrating the battery indicator light states for the TOWILD CL600, showing different colors and flashing patterns for various charge levels.

## MAINTENANCE

### 1. Charging

- Charge the light using the provided USB-C cable. The 2600mAh battery allows for extended use.
- Avoid overcharging or completely draining the battery to prolong its lifespan.

# 多様な使い道

## 互換性高いGARMINベース




Image: The TOWILD CL600 bicycle light being charged via a USB-C cable, demonstrating the charging port location.

## 様々な場所に大活躍



通勤通学



ロードサイクリング



アウトドア

Image: The TOWILD CL600 bicycle light being charged via USB-C from multiple power sources, including a laptop, power bank, and car charger.

## 2. Cleaning

Wipe the light's body and lens with a soft, damp cloth. Do not use abrasive cleaners or solvents.

## 3. Water Resistance

The CL600 is IPX6 waterproof, meaning it is protected against powerful water jets. It can withstand heavy rain but should not be submerged in water.



Image: The TOWILD CL600 bicycle light shown in a rainy environment, illustrating its IPX6 waterproof capability.

## 4. Storage

Store the light in a cool, dry place when not in use for extended periods. Charge it periodically (every 3-6 months) to maintain battery health.

## TROUBLESHOOTING

- **Light not turning on:**
  - Ensure the battery is charged. Connect to a USB-C power source and check the indicator light.
  - Press and hold the power button for 1 second to ensure it's not just in standby.
- **Light not charging:**
  - Check the USB-C cable and power adapter for damage.

- Ensure the cable is fully inserted into the light's port.
- **Smart mode not working:**
  - Ensure the smart mode is activated (blue indicator light).
  - Verify the light is securely mounted and can detect vibrations.
- **Light output is dim:**
  - The battery might be low. Recharge the light.
  - Ensure the lens is clean and free from dirt or obstructions.

## SPECIFICATIONS

Feature	Detail
Model	CL600
Brand	TOWILD
Maximum Light Output	600 Lumens
Battery Capacity	2600mAh
Charging Type	USB-C
Water Resistance	IPX6
Lighting Modes	5 (High, Medium, Low, Night Flash, Day Flash)
Material	Aluminum
Item Weight	140 grams
Mounting Type	Handlebar mount, Garmin/GoPro compatible
Included Components	Japanese instruction manual
Manufacturer Model Number	CL600-01
Country of Origin	China

## WARRANTY INFORMATION

The TOWILD CL600 Bicycle Light comes with a 1-year manufacturer's warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For warranty service, please contact customer support.

## CUSTOMER SUPPORT

For any questions, concerns, or technical assistance regarding your TOWILD CL600 Bicycle Light, please contact our customer support team:

- **Email:** [support@towild.com](mailto:support@towild.com)
- **Website:** [www.towild.com](http://www.towild.com)
- **Phone:** +1-XXX-XXX-XXXX (Please refer to your regional support contact if available)

