Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bonnlo B0H1M69LLD

Bonnlo 11,000 BTU Inverter Window Air Conditioner with Heat User Manual

Model: B0H1M69LLD

Introduction

This manual provides essential information for the safe and efficient operation of your Bonnlo 11,000 BTU Inverter Window Air Conditioner with Heat. This unit is designed to provide year-round comfort, offering cooling, heating, and other modes for rooms up to 450 sq ft. Please read this manual thoroughly before installation and use, and retain it for future reference.

Important Safety Instructions

- Always ensure the unit is properly grounded.
- Do not operate the Cool/ECO mode when the outdoor temperature is below 32°F (0°C).
- Do not operate the Heat mode when the outdoor temperature is below 5°F (-15°C).
- Keep the power cord away from heated surfaces.
- Do not insert fingers or foreign objects into the air inlet or outlet.
- Unplug the unit before cleaning or performing any maintenance.
- Ensure the window installation is secure to prevent the unit from falling.

What's in the Box

Upon unpacking, verify that all components are present:

- Air Conditioner Unit
- Remote Control
- Installation Window Kit
- User Manual (this document)

Setup and Installation

The Bonnlo Inverter Window Air Conditioner is designed for easy installation. No professional installation is required.

Window Requirements

- Recommended Window Width: 24.5 inches to 36 inches
- Recommended Window Height: Minimum 15.5 inches



Image: The air conditioner unit installed in a window, illustrating the ideal window width (24.5" - 36") and minimum height (15.5") requirements. The unit's dimensions are also shown: 18.98"D x 20.47"W x 14.96"H.

Installation Steps

1. Prepare the window opening according to the specified dimensions.
2. Assemble the provided installation window kit.
3. Carefully place the air conditioner unit into the prepared window opening, ensuring it is level and securely supported.
4. Extend the side panels of the window kit to seal the gaps between the unit and the window frame.
5. Secure the unit and window kit using the provided screws and brackets to prevent movement.
6. Plug the unit into a standard 115V / 60Hz grounded electrical outlet.



Image: The Bonnlo air conditioner installed in a window, with text indicating "No professional installation required," "No damaging the wall," "Plug and use," and "Easy disassembly for house-moving."

Operating Instructions

Your Bonnlo air conditioner offers multiple control methods and operating modes for optimal comfort.

Control Methods

- **Touch Panel:** Directly on the unit.
- **Remote Control:** Use the included remote for convenient adjustments.
- **Smartphone App (WiFi Enabled):** Connect the unit to your home WiFi network to control it from your smartphone.
- **Voice Control:** Compatible with Alexa and Google Assistant for hands-free operation.



Image: A visual representation of the three control methods: the unit's control panel, the remote control, and the smartphone app interface.

Operating Modes

- **Cool Mode:** Provides 11,000 BTU of cooling capacity. Ideal for reducing room temperature.
- **Heat Mode:** Provides 11,000 BTU of heating capacity. Suitable for warming rooms during colder periods.
- **Dry Mode:** Dehumidifies the air, reducing humidity levels.
- **Fan Mode:** Circulates air without cooling or heating. Fan speed can be adjusted.
- **ECO Mode:** Optimizes energy use by cycling the compressor on and off to maintain the set temperature efficiently.
- **Sleep Mode:** Adjusts temperature gradually overnight for comfortable sleep and energy saving.

The unit features rapid cooling and heating capabilities, reaching desired temperatures quickly.



Image: The Bonnlo air conditioner with an overlay indicating "30S Fast Cooling & Heating" and gauges showing 11000 BTU for both cooling and heating.

Temperature Settings

- Adjustable temperature range: 64°F (18°C) to 86°F (30°C).
- Use the temperature up/down buttons on the control panel, remote, or app to set your desired temperature.

Timer Function

- The 24-hour programmable timer allows you to set the unit to turn on or off automatically.
- Refer to the detailed instructions in the app or remote control section for setting the timer.

Quiet Operation

The unit operates at a low noise level of approximately 40dB, ensuring a peaceful environment for work or sleep.



Image: A person sleeping comfortably in a bedroom, with the Bonnlo air conditioner operating quietly in the window, illustrating its low noise level.

Maintenance

Regular maintenance ensures optimal performance and longevity of your air conditioner.

Cleaning the Air Filter

- The unit features an easy-clean washable filter.
- The air filter should be cleaned every two weeks, or more frequently depending on usage and air quality.
- To clean, carefully remove the filter from the unit.
- Wash the filter with warm, soapy water. Rinse thoroughly and allow it to air dry completely before reinserting.
- Do not operate the unit without the filter installed.

Cleaning the Unit Exterior

- Wipe the exterior of the unit with a soft, damp cloth.
- Do not use harsh chemicals, abrasives, or solvents.

Troubleshooting

Before contacting customer support, please refer to the following common issues and solutions.

Problem	Possible Cause	Solution
Unit does not turn on	No power, tripped circuit breaker, loose plug.	Check power supply, reset circuit breaker, ensure plug is fully inserted.
Insufficient cooling/heating	Dirty air filter, blocked air intake/outlet, incorrect mode/temperature setting, room size exceeds capacity, open windows/doors.	Clean air filter, clear obstructions, verify settings, ensure room is sealed, check unit capacity for room size.
Unit is noisy	Loose installation, foreign object in fan, unit not level.	Ensure secure installation, check for obstructions, verify unit is level.
Remote control not working	Dead batteries, obstruction between remote and unit.	Replace batteries, remove obstructions, ensure remote is pointed at the unit.

Specifications

Feature	Detail
Brand	Bonnlo
Model	B0H1M69LLD
Cooling Power	11,000 BTU
Heating Power	11,000 BTU
Recommended Coverage Area	Up to 450 sq ft
Power Supply	1 Ph-115 V-60 Hz
Seasonal Energy Efficiency Ratio (SEER)	13.2
Noise Level	40 Decibels
Product Dimensions (D x W x H)	18.98" x 20.47" x 14.96"
Recommended Window Width	24.5" - 36"
Recommended Window Height	Minimum 15.5"
Control Method	App, Remote, Touch, Voice (Alexa, Google Assistant)
Inverter Type	Has Inverter
Temperature Range	64°F - 86°F
Timer Setting	Up to 24 hours

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official Bonnlo website.
If you encounter issues not covered in the troubleshooting section or require further assistance, please contact Bonnlo customer support. Contact details can typically be found on the product packaging, the official website, or the warranty card.

© 2024 Bonnlo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H1M69LLD

More documents and user manuals: **https://manuals.plus/**